FCC ID: 2BFYM-LBS175

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION: Any changes or modifications to this device not explicitly approved by manufacturer could void the user's authority to operate this equipment. This device complies with Part 15 of FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
The device has been evaluated to meet general RF exposure requirement. The device should be installed and Operated with minimum distance 20cm between the radiator and your body.

BATTERY SAFETY : This product is fitted with a Li-ion/Polymer battery. Do not damage, open or dismantle the battery and do not use it in damp and/or corrosive environments. Do not short circuit the battery. Never dispose batteries in a fire and never expose them to high temperatures. Do not expose the product to temperatures exceeding 60°C (140°F).

BATTERY DISPOSAL : The crossed-out wheelie-bin symbol means that you may not dispose of this product together with general household waste. Instead, take it to a recycling point for electrical and electronic equipment. For more information about local recycling points, contact your local authority, your household waste disposal service or the shop where you bought the product. Correct recycling of used items of electrical and electronic equipment prevents any harmful substances they contain from harming human health and polluting the environment.

Please keep this information for later reference.

WARNING
RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE.
DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

© 2025 IRIVER AUDIO
240 W 37TH ST. NEW YORK, NY 10018
THE BLUETOOTH® WORD MARK AND LOGOS ARE REGISTERED TRADEMARKS OWNED BY BLUETOOTH SIG, INC., AND ANY USE OF SUCH MARKS BY IRIVER AUDIO IS UNDER LICENSE.

ALL OTHER TRADEMARKS AND TRADE NAMES ARE THOSE OF THEIR RESPECTIVE OWNERS. ACTUAL PRODUCT MAY DIFFER SLIGHTLY FROM IMAGE SHOWN. MADE IN CHINA.

PrimeAudio®

Retro Speaker

Bluetooth

Instruction Manual

Product Diagram





Instruction Manual

BLUETOOTH® WIRELESS SPEAKER

FEATURES
- Works with all Bluetooth®-enabled devices.
- Stream audio wirelessly via Bluetooth® technology in high, uncompromising quality from up to >33ft away.
- Integrated rechargeable lithium-ion battery provides hours of playing time wherever you go.

SPECIFICATIONS
- Rechargeable Battery: Li-Ion 600mah
- Wireless Capability: Up to 33ft range

- Supply Voltage: 3.7V
- Driver Diameter: 52 mm/30 5W
- Nominal Impendance: 3Ω
- Frequency Response: 80Hz - 20kHz
- Sensitivity: 77 ± 3dB

CONTENTS
- 1 Wireless Speaker
- 1 USB Charging Cable
- 1 User Manual

CHARGING THE BATTERY
The internal Lithium-ion battery must be fully charged before first use of the speaker.
1. Insert the smaller USB TYPE-C connector of the included USB cable into the charging input port on the back of the speaker unit
2. Insert the larger USB connector into either the USB port on a computer OR into a compatible USB DC 5V wall charger (not included) to charge through a standard wall socket. The indicator lights will be red while charging, and will turn off when charging is complete.
NOTE:Please charge the speaker after turn off and do not charge the speaker when using.

WIRELESS SPEAKER OPERATION
Wireless playback Via Bluetooth
1. Make sure the battery is charged as explained above.
2. Press and hold the ⏯ button for 3 seconds to turn the speaker on, a tone will signal and ready you to connect your Bluetooth device. The red and blue lights will flash alternately.
3. Activate Bluetooth function on your smartphone/computer/audio source device = Search for Bluetooth devices and select the speaker from the list of devices, the speaker name "PrimeAudio". Another tone will indicate when connected successfully and you are now set to enjoy wireless audio from within a 33ft range of the audio device.
4. Rotate the hole end of the antenna into the antenna hole on the top of the speaker to search and use the FM function. Press the ⏯ button to switch between Bluetooth mode and FM mode.
5. Short click the " - " button to move to the previous song in Bluetooth mode or search down the channel in FM mode.
6. Press and hold the the " - " button to lower the volume.
7. Short click the " + " button to move to the next song in Bluetooth mode or search up the channel in FM mode.
8. Press and hold the the " + " button to raise the volume.
9. Speaker will turn off Automatically after 5min without connection.
10. Press and hold the ⏯ button for 3 seconds to turn the speaker off.

CAUTION
- This is not a toy. Please keep away from small children.
- Please keep the unit away from water and heat.
- Do not overcharge the battery.
- Do not operate speaker with a damaged cable.

TECHNICAL SUPPORT
Please do not attempt to fix the product yourself. If you are experiencing any problems with the product please contact our Customer Service Department. Our Customer Service Department is staffed by representatives and they will assist you with any questions you may have. For assistance operating your product, please consult the User's Manual or feel free to contact iHome technical support:

iHome LLC.
240 West 37th St., 10th Floor
New York, NY 10018, USA.
www.iwearlikeyou.com
email: support@iwearlikeyou.com
- Please keep instructions for further reference.