JHY-81

使用说明书

Wireless Bluetooth earphones

产品参数

- 传输距离 …… 10米
- 喇叭直径 …… Φ13mm
- 喇叭阻抗 …… 32Ω±15%
- 灵敏度 …… 115±3.5dB
- 频响范围 …… 20Hz-20kHz
- 电池容量（充电盒） …… 3.7V 300mAh
- 电池容量（耳机） …… 3.7V 30mAh
- 充电时间（充电盒） …… 4.5小时
- 充电时间（耳机） …… 1.5小时
- 充电盒续航时间 …… 4小时

包装清单

耳机*2

充电盒 *1

使用说明书*1

Type-C充电线*1

产品示意说明

坑充电盒充电

用Type-C充电线连接充电盒到5V电源适配器。

额定输入:5V ⎓ 30mA(耳机)　　额定输入:5V⎓300mA(充电盒)

(温馨提示：关闭充电盒，达现充电盒进行闪烁时，请及时拔充电盒充电。

LCD指示灯状态

模式	描述
打开上盖开机	蓝灯灯长亮4秒灭灯
关上上盖关机	蓝灯灯长亮4秒灭灯
耳机开机	蓝灯长亮3秒
耳机关机	红灯灭3次
耳机充电	耳机灯灭长亮，充满灭灯
充电仓充电	充电灯灭闪烁，充满长亮

产品操作说明

1. 开机

打开充电盒，耳机自动开机。

2. 关机

方法一：将耳机放回充电盒，关上充电盒盖，耳机关机。

方法二：与设备设置解开连接对应耳机，自动关机。

3. 配对

方法一：打开充电盒盖，耳机自动开机并配对；

方法二：打开蓝牙设置，搜索到“HJC-80”

进行配对，连接成功后，手机蓝牙灯长亮。

* 超出距离，或解开连接3分钟内，耳机将关闭。自动连接设备。



注意：

* 初次产品长时间不使用，应充充满电，并确保设备处于关机状态。
* 充电完成后，请将充电盒关上，避免长时间充电或过度损坏。

触控操作

恢复出厂设置

关机状态下，长按10秒清除配对列表。

清除配对列表完成后会自动重启，恢复出厂。

注意

1. 充电盒开盖后，不要自动闪烁或，耳机自动开机，连接成配对，耳机进入耳机盒内自动关，充电盒将自动关闭灯灭熄，耳机关机。
2. 禁止：高温，高湿，潮湿，强烈震动，请以下列方法保存：这些有害物质，耳机属重有毒物质可能有害物质，请使用完毕后，请勿随意丢弃，请将其回收处理。
3. 请勿将产品放置在儿童接触的地方，请勿随意拆卸。
4. 请不要自产品表面用力按压，请勿随意拆卸，请勿碰撞，请勿踩踏，请勿高温，请勿高湿，请勿打为等因素影响，可能导致数据丢失甚至，会出现短路，可能把产品中的电子元件烧毫。

警 告

1. 长时间以高音量使用耳机可能会损害您的听力。请以可使用适当音量收听，通话时间适当。
2. 请不要将其放进产品表入水中，以免造成短路。
3. 不要自行拆卸产品及耳机，以免导致部分功能受损失。
4. 请保留产品说明书以便日后查阅以及使用。
5. 请勿使用化学溶剂或清洁剂清洁产品。

Name of the Parts 部件名称	Hazardous Substances 有害物质					
	Pb 铅	Hg 汞	Cd 镉	Cr(VI) 六价铬	PBB 多溶溴素	PBDE 多溶二溴醚
Housing 外壳	O	O	O	O	O	O
Earphones 耳机/耳塞	O	O	O	O	O	O
PCBA 电路板组件	X	O	O	O	O	O
Accessories 电源线/连接线	X	O	O	O	O	O

This table is compiled according to SJ/T 11364.

本表格依据SJ/T 11364的规定编制。

O: Indicates that this hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in GB/T 26572.

（O：表示该有毒物质在所有均质材料中的含量均在SJ/T 11364有规定的限量要求以下。

X: Indicates that this hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in GB/T 26572.

（X：表示该有害物质至少在该部件的某一均质材料中含量超过GB/T 26572有关规定的限量要求。

Environment Friendly Use Period (EFUP)

环保使用期限

This logo refers to the period (10 years) during which the hazardous substances in electronic and electrical products will not leak or mutate so that the use of these substances will not result in any severe environmental pollution, any bodily injury or damage to any assets.

该标识所指期限（10年）是电子电气产品中有害物质在正常使用条件下不会发生外泄或突变，电子电气产品的环境保护和产品安全不会造成严重污染或伤害人员、财产损失的使用期限。

保修卡

尊敬的客户：本保修卡是您享有本产品保修的凭证，请您妥善保管并填写正确保修信息！

用户信息			
用户姓名		电子邮件	
联系电话		邮政编码	
通讯地址			

产品信息			
产品名称		产品型号	
产品条码/编号/批号			

销售信息			
名　称			
地　址			
联系电话		邮件编码	
销售日期		发票号码	
备　注			

合格证

产品编号 Production Number

生产日期 Production Date

检 查 员 Inspector

JHY-81

Wireless Bluetooth earphones

JHY-81

INSTRUCTIONS MANUAL

Wireless Bluetooth earphones

Product parameters

- Transmission distance …… 10 meters
- Diameter of horn …… Φ13mm
- Horn impedance …… 32Ω±15%
- Sensitivity …… 115±3.5dB
- Frequency response range …… 20Hz-20kHz
- Battery capacity (charging case) …… 3.7V 300mAh
- Battery capacity (headphone) …… 3.7V 30mAh
- Charging time(charging case) …… 4.5 hours
- Battery life (headphone) …… 4.4 hours
- Battery life with charging case …… 4.24 hours

Packing list

Headphone *2

Charging Case *1

Instructions Manual *1

Type-C Charging Cable *1

Product Schematic Description

Charge the charging case

Connect the charging case to the 5V power adapter with Type-C charging cable.

Rated input: 5V ⎓ 30mA(Headphone)　　Rated input: 5V ⎓ 300mA (charging case)

□Tips: Turn off the charging case. When the blue light of the charging case flashes, please charge the charging case in time.)

LED indicator status

Mode	Describe
Open the cover to start	Lights on for 4 seconds, lights off
Close the lid and shut down	Lights on for 4 seconds, lights off
Turn on the headset	Blue light on for 3 seconds
Headphones off	Red light flashes 3 times
Headphone charging	Headphone red light on, full off light
Charging case	Charging red light flashes,

Product operating instructions

1. Power on

Open the cover of the charging case and the headset will turn on automatically.

2. Power off

Method 1: put the headset back into the charging case, close the cover of the charging case, and turn off the headset.

Method 2: After disconnecting from device for 3 minutes, automatically power off.

3. Pairing

Method 1: open the cover of the charging case, and the headset will automatically start and pair.

Method 2: Open the list ofsmart devicesand search for"HJC-80" for pairing.

Pair: After the connection is successful, the phone displays connected.

If disconnected, automatically connect to the last paired device within 3 minutes after disconnection, and automatically connect the device.



Note:

* If the product is not used for a long time, it should be fully charged first and ensure that the device is turned off.

* After charging, please unplug the charging cable to avoid device damage caused by long-term charging.

Touch key operation

Conventional mode

Restore factory settings

In the power-off state, press and hold for 10 seconds to clear the pairing list.

After clearing the pairing list, it will automatically restart and restore the factory.

Attention

1. After the box is closed, the charging case will automatically charge the earphone and the earphone will automatically shut down.

2. It is always clean and has a long service life. If it is not used for a long time, it is recommended to charge it once every 15 days to prolonghe battery life. The charging part of the earphone tail plug is often wiped with cotton swabs and alcohol, which can help smooth charging and avoid poor contact and affect the use experience.

3. Do not disassemble products and accessories by yourself, so as not to cause damage and warranty failure.

4. Because this product adopts wireless connection, it is normal to have short and slight sound interruptions and playing music due to the influence of environment, mobile phone brand, use behavior and other factors in daily use.

Warning

1. Using earphones at high volume for a long time may damage your hearing. It is recommended to listen to music at an appropriate volume and appropriate time.
2. Please do not wash or immerse the product in water to avoid fault.
3. Do not disassemble products and accessories by yourself, so as not to cause damage and warranty failure.
4. Do not make the product subjected to strong impact or vibration to avoid damage.
5. Do not use chemical solvents or cleaning agents to clean products.

Name of the Parts	Hazardous Substances					
	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
Housing	O	O	O	O	O	O
Earphones	O	O	O	O	O	O
PCBA	X	O	O	O	O	O
Accessories	X	O	O	O	O	O

This table is compiled according to SJ/T 11364.

O: Indicates that this hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in GB/T 26572.

X: Indicates that this hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in GB/T 26572.

Environment Friendly Use Period (EFUP)

This logo refers to the period (10 years) during which the hazardous substances in electronic and electrical products will not leak or mutate so that the use of these substances will not result in any severe environmental pollution, any bodily injury or damage to any assets.

Warranty Card

Dear user, this warranty card is the proof of your future warranty application, please cooperate with the seller to fill it out and keep it for future use!

User info			
User name		Email	
Contact number		Postal code	
Mailing address			

Product information			
Product name		Product number	
Product barcode / Serial number / Batch number			

Vendor information			
Name			
Address			
Contact number		Postal code	
Sales date		Invoice number	
Remark			

Certificate of Approval

Product No. Production Number

Production Date

Inspector

JHY-81

Wireless Bluetooth earphones

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.