正

SIMPLY TECH
P.O. BOX 10018 N.Y., NY 10018

ACTIVE

USER MANUAL

TWS-SPORT

SPECIFICATIONS		CHARGING TIME	
Bluetooth	Version 5.3	Earbuds	1 Hour
Output Power Balance	±10% Offset	Charging Cases	2 Hours
Driver unit	10mm	Earbud Battery	90Mah
Frequency	20Hz-20KHz	Charging Case	400mah
Sensitivity	104±3dB	Play Time	5.5 Hours
Frequency	20Hz-20KHz	Stand-by Time	10H

SAFETY & CARE INSTRUCTIONS

Do NOT expose any portion of this product to liquid, humidity, moisture, sharp objects or extreme temperatures as this can damage it and void the warranty.
Do NOT attempt to disassemble or modify the Earbuds or Charging Case in any way
Spot Clean ONLY.
The earbuds are sweat and water-resistant but should not be submerged into water as it will damage them.

Keep out of reach of children.
This product is not a toy.

RoHS

CHARGING YOUR ACTIVE EARBUDS

1.Place each earbud into its charging slot and close the cover.
2.Use the charging cable provided and plug the other end into any USB charging port.
**To prevent damage, it is recommended to use the charging cable that is provided.
Fully charge the charging case and earbuds for a minimum of 3 hours before first use.

POWERING ON & OFF

1.Take the earbuds out from the case, they will automatically power on.
2.Place the earbuds back into the charging case, the earbuds will automatically power off.
3. To manually power on, press and hold the TOP on either one of earbuds for 4-5 seconds until the LED indicator flashes blue.
4.To manually power off, press and hold button on either one of earbuds for 4-5 seconds until the LED indicator turns off.

BLUETOOTH PAIRING WITH YOUR DEVICE

Open the charging case, remove the earbuds & they will automatically power on and pair to each other, voice will prompt 'CONNECTED'. The right earbud will automatically connect to the left earbud.
2.Pairing mode will last for 2 minutes. While in pairing mode, turn ON the Bluetooth Connection on your device, Scan/Search & select "ACTIVE Sports".
3.Once paired, ACTIVE Sports will voice prompt 'CONNECTED'.

Single Earbud Mode:
When Bluetooth connected, you can use either Earbud of the earbuds only by putting the other one back into the charging case and closing the cover.

NOTE: Power on ACTIVE Sports and they will automatically connect to the last connected device if available within the Bluetooth range.

EARBUD TAP-TOUCH FUNCTION GUIDE

NOTE: ACTIVE Sports has a sensitive tap-touch feature. There is a multi-function touch button on each earbud.

CONTENTS: 2 x Earbuds, 2 x Large Ear hooks, 2 x Small Ear hooks, 1 x Charging Case, 1 x Type C Charging Cable, 1 x Manual

TECHNICAL SUPPORT & WARRANTY INFO

This product is backed by a One Year Warranty from any defects. For warranty replacements, questions or if you have any issues about this product, contact us at help@SimplyTechCorp.com.
SimplyTech Electronics Inc declared that radio equipment is compliant with Directives 2014/53/EU, 2011/65/EU & 2012/19/EU.
EU Declaration of Conformity for this product can be viewed at www.SimplyTech Corp.com/docs.
DISTRIBUTED BY: SimplyTech Electronics, Inc. 1407 Broadway New York, NY 10018
MADE IN CHINA
Please read before using this product and retain manual for future reference.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device,pursuant to part 15 of the FCC Rules.
These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules, Operation is subject to the following two conditions:
(1)This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: Measurements of the radiated and conducted emissions are both for an unconditioned environment.The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure condition without restrictions.

背

SIMPLY TECH

ACTIVE

BEDIENUNGSANLEITUNG
DUR ARTIKELNUMMER

TWS-SPORT

TECHNISCHE DATEN		LADEZEIT	
Bluetooth	Version 5.4	Ohrstöpsel-Akku	1 STUNDE
Wiedergabe-Frequenzgang	max. 10m	Akku der Ladeschale	2 STUNDEN
Ausstoßleistungsbalance	±10mm	Ohrstöpsel-Akku	90mAh
Wandler	10	Batteriekapazität der Ladeschale	400mAh
Empfindlichkeit	104±3dB	Play Time	4.5 STUNDEN
Frequenzbereich	20Hz-20KHz	Kabel	Typ-c

ANLEITUNG - SICHERHEITSVORSCHRIFTEN

Setzen Sie keinen Teil dieses Produkts scharfen Gegenständen oder extremen Temperaturen aus, da dies zu Schäden führen und die Garantie ungültig machen kann.
Versuchen Sie NICHT, die Ohrhörer oder das Ladeetui in irgendeiner Weise zu modifizieren oder zu zerlegen.

• NUR punktuelle Reinigung
• Die Ohrstöpsel sind schweiß- und wasserfest, sollten jedoch nicht in Wasser getaucht werden, da sie dadurch beschädigt werden.

EINSCHALTEN DIE ACTIVE Sports EARBUDS

1. Legen Sie jeden Ohrhörer in seinen Ladeschlitz und schließen Sie die Abdeckung.
2. Verwenden Sie das mitgelieferte Ladekabel und schließen Sie das andere Ende an einen beliebigen USB-Ladeanschluss an.
** Um Schäden zu vermeiden, wird empfohlen, das mitgelieferte Ladekabel zu verwenden.

Laden Sie das Ladegehäuse und die Ohrhörer mindestens 3 Stunden vor dem ersten Gebrauch vollständig auf.

ON/OFF

1. Entfernen Sie die Kopfhörer aus dem Gehäuse, sie werden automatisch eingeschaltet.
2. Setzen Sie die Kopfhörer wieder in den Ladekoffer, die Kopfhörer schalten sich automatisch aus.
3. Um manuell einzuschalten, halten Sie die Taste auf einem der Kopfhörer für 4-5 Sekunden gedrückt, bis die LED-Anzeige ROT blinkt.
4. Um manuell auszuschalten, halten Sie die Taste an einem der Ohrhörer 4-5 Sekunden lang gedrückt, bis sich die LED-Anzeige ausschaltet.

4. Um das Gerät manuell auszuschalten, halten Sie die Taste an einem der Ohrhörer 3 Sekunden lang gedrückt, bis die LED-Anzeige erlischt und „Power off" anzeigt.

KOPPLUNG MIT EINEM MOBILTELEFON

1. Öffnen Sie die Ladetasche, entfernen Sie die Ohrhörer und sie werden automatisch einschalten und paaren sich, Stimme wird "CONNECTED" anfordern. Der rechte Ohrhörer wird automatisch mit dem linken Ohrhörer verbunden.
2. Der Kopplungsmodus dauert 2 Minuten.

Schalten Sie im Kopplungsmodus die Bluetooth- Verbindung auf Ihrem Gerät ein, scannen/suchen & wählen Sie ACTIVE Sports aus.
3. Sobald ACTIVE Sports gekoppelt ist, wird die Sprachansage "CONNECTED" ansprechfacht.
Ein Earbud-Modus: Wenn Bluetooth verbunden ist, können Sie entweder Earbud der Ohrhörer verwenden, indem Sie den anderen wieder in das Ladegehäuse stecken und die Abdeckung schließen

WIE BENUTZT MAN Ohrhörer MFB

WICHTIG: ACTIVE Sports hat sensible Touch-Funktion 'MFB'

TECHNISCHE HILFE & GARANTIENINFORMATIONEN

Für dieses Produkt gilt eine einjährige Garantie auf jegliche Mängel. Für Garantieleistungen, Fragen oder wenn Sie Probleme mit diesem Produkt haben, kontaktieren Sie uns unter help@SimplyTechCorp.com.
SimplyTech Electronics Inc. erklärt, dass das Funkgerät mit den Richtlinien 2011/65/EU, 2014/53/EU & 2012/19/EU konform ist.
Die EU-Konformitätserklärung für dieses Produkt kann unter www.SimplyTech-Corp.com/docs eingesehen werden.
VERTRIEBEN VON: SimplyTech Electronics, Inc. 1407 Broadway New York, NY 10018
HERGESTELLT IN CHINA
Bitte lesen Sie das Handbuch vor der Verwendung dieses Produkts und bewahren Sie es zum späteren Nachschlagen auf.