S52英文6P 正反说明书

PRODUCT INSTRUCTIONS FOR USE

I. Introduction of key and jack function

1. mode key: short press "mode" key, music / Bluetooth mode rotation. Long press to switch the Chinese / English prompt tone; The machine defaults to the Chinese speech message.
2. radio key: press "radio" to enter FM radio mode, and then press "radio" to automatically search the radio station, and save the radio station.
3. cycle key: in MP3 mode: short press the single cycle, then short press the full cycle.
4. ⏮: the song key, short press the song / a radio station, long press fast back.
5. ⏭: the next song, short press the next song / the next radio station, long press fast forward
6. ⏯: pause / play key: short press pause / play.
7. Charging interface: you can use the special USB power cable delivered by the machine to connect the USB interface of the computer for charging, or use the USB connection The mobile phone charger for charge.
8. Audio output hole: standard 3.5MM audio output interface
9. Power switch: ON or; OFF off.
10. Volume knob, adjust the volume size

11. TF card slot (64GB maximum support).
12. U disk interface: the maximum support is 64GB.
13. Number key: enter 0~9 to select digital vol3.
14. Display: display the current playback state (when charging, the indicator is always on and fully off).

II. The Bluetooth Connection Operation

After turning on the power switch, turn on the Bluetooth function of the phone, search the Bluetooth device, and click the pairing.

III. The FM Radio Tone Operation

1. short press "radio" key to turn to radio mode, then long press "radio" key to start automatic search, and automatically save the station.
2. ⏮⏭: Select the saved radio station by pressing "Last" or "Next". Or enter a number key, such as input "1071" and press the play key to play the "1071" frequency station.

IV. Technical Parameter

Bluetooth version	5.3
The TF card audio format	MP3
frequency response	120Hz - 20KHz
effective range	10 Meters
Enter the power supply	DC 5V 1000mA
Continuous continuous play time	The maximum continuous playback is about 15 hours; the maximum volume is about 3 hours.
Charging interval	About 3~5 hours can be filled.

V. Charging and use method

Plug one end of the USB power cord into the DC5V port and plug the other end into the 5V 1A or 2A charger for charging. Built-in overcharging protection circuit, can be fully charged battery for about 3~5 hours; support charging under shutdown state. If the machine is not used for a long time, charge at least once every two months to protect the battery and prolong the battery life.(When the low power is off, turn off the power switch for recharge)

- special explanation

① Products are sold without a power adapter

② Please use the power adapter with the CCC certificate and meeting the relevant standards.

Safety and use

1. Please store and use the product in the room temperature environment.
2. Do not use this product in rain or humidity.
3. Do not disassemble, repair and transform the product by yourself.
4. Do not discard the products at will to avoid product damage caused by falling.
5. this product has built-in lithium battery, do not throw away or put in the fire, so as not to cause danger.

- In case of any consequences for personal and property damage caused by improper use of the above warning, the Company will not bear any legal liability.

PRODUCT WARRANTY

TERMS OF PRODUCT SERVICE

Warranty Ports: One-Year Warranty

All accessories such as USB cable and battery are free parts that are not covered by the warranty. Special reminder:

1. This commitment is only for the case of failure during normal use
2. All parts must be the standard parts of the purchased products and within the warranty period
3. the following circumstances will not be replaced, warranty

- Appearance wear
- Non-standard parts of the purchased products
- Standard parts of the products purchased beyond the warranty period
- Using extended parts or peripheral equipment not approved by the Company
- Abnormal reasons (including bad power supply environment foreign body into the equipment, transportation, movement, knock, etc.) Damage and failure of the parts
- The equipment fails to work properly due to force majeure such as earthquake, fire and other natural disasters or accidents (stolen, lost, etc.)
- Product faults caused by illegal operation: self-disassembly, repair, installation or modification
- No product warranty card and valid purchase certificate

(The Manufacturer has the right of final interpretation)

PRODUCT WARRANTY CAR

Inspector: OK QUALIFIED

date: _____

Terms of product service

Within one year from the date of warranty of the main engine parts will not be replaced or guaranteed within the following circumstances:

- Non-standard parts of the purchased products.
- Standard parts of the products purchased beyond the warranty period.
- Damage and failure caused by abnormal reasons (including bad power supply environment, foreign objects entering equipment, transportation, movement, knock, etc.)
- All natural disasters or accidents (theft, loss, etc.) can not work normally.
- Product failure caused by illegal operation: self-disassembly, repair, installation or modification.
- No product warranty card and valid purchase certificate.

THE FOLLOWING IS FILLED OUT BY THE DEALER

product model:_____

Date of sale:_____

Dealer name:_____

official seal:_____

telephone:_____

THE FOLLOWING IS FILLED OUT BY THE USER

Dealer name:_____

user name:_____

postal address:_____

ID card:_____

telephone:_____

Please fill in each item carefully, do not alter without authorization, and take good care of this card to protect your legitimate rights and interests. For service or any questions, please contact us or the dealer.

(The manufacturer has the right of final interpretation)

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.