PHILIPS

Hearing aids

1000 Series

TAT1769

User Manual

Visit the following website to register your product and get support

www.philips.com/support

Table of contents

1 Important Safety Instructions 2
Hearing Safety 2
General information 2

2 Open Wireless Headphones 3
What's in the Box 3
Other Equipment 3
Open Wireless Headphones Overview 4

3 Getting Started 5
Charging the Battery 5
Wearing Methods 6
Pairing the Headphones with a Bluetooth Device for the First Time 6
Pairing with Another Bluetooth Device 7

4 Using the earphones 8
Connecting to a Bluetooth device 8
Power on/off 8
Managing music and calls 8
Voice assistant 9
Earphone LED status 9
Charging case LED status 9

5 Reset the headset 10

6 Technical Data 11

7 Notices 12
Declaration of conformity 12
Disposal of old product and battery 12
Removal of integrated battery 12
Compliance statement of electromagnetic field (EMF) regulations 13
Environmental information 13
Declaration of conformity 13

8 Trademark 15

9 Frequently asked questions 16

1 Important Safety Instructions

Hearing safety

Danger

- To avoid hearing damage, limit the time you use headphones at high volume and turn the volume to a safe level. The louder the volume, the shorter the safe listening time.

Please make sure to follow these guidelines when using headphones

Listen at a reasonable volume for a reasonable amount of time

After your hearing has adapted, be careful not to keep turning up the volume.

Don't turn up the volume so high that you won't hear the sounds around you.

Use headphones with caution or suspend use in potentially dangerous situations.

Excessive sound pressure from headphones can cause hearing loss

It is recommended not to wear headphones in both ears while driving. Doing so may be illegal in some areas

For safety reasons, avoid distracting yourself with music or calls while driving or in other potentially dangerous situations.

General Information

To avoid damage or malfunction:

Warn

- Do not expose the headset to high temperatures.
  - Do not drop the headset.
  - Do not expose the headset to dripping or splashing water. (Refer to the IP rating of the specific product)
  - Do not immerse the headset in water.
  - Do not change the headset when the battery or socket is wet.
  - Do not use any cleaning agent containing alcohol, ammonia, benzene or abrasives to clean the product.
  - If necessary, clean the product with a soft cloth. Wet cloth can be used with water only. Do not use any other substances.
  - Do not expose the headset/battery to high temperatures, such as direct sunlight, open flames or similar environments.
  - There is a risk of explosion if the battery is replaced incorrectly. Replace only with battery of the same type.
  - Do not swallow the battery. Also, the charging port cover must be closed.
  - Throwing the battery into a fire or hot oven, or mechanically crushing or cutting it, can cause an explosion.
  - Exposing the battery to extremely high temperatures can cause an explosion or leakage of flammable liquids or gases.
  - Leaving the battery in extremely low air pressure can cause an explosion or leakage of flammable liquids or gases.
  - To avoid the risk, the device can only be powered by an external power supply, the output of which should comply with PS1 output capacity less than 100W.

Operating and storage temperature and humidity

Store the product in an environment with a temperature between -10°C (+14°F) and 50°C (122°F) and a relative humidity of up to 90%. Low temperatures will temporarily shorten the usable battery life. Allow products with normal temperatures to reach room temperature before they are switched on.

High or low temperatures or humidity may shorten battery life.

Replacing the battery with an incorrect type may nullify a safety feature. Improper battery disposal may result in a fire, explosion or release of flammable liquid or gas.

Do not dropping or crushing the battery. Do not puncture the battery. Do not short circuit the battery and keep it away from metal objects. Do not expose the battery to water or other liquids. Do not disassemble or modify the battery.

Do not place the battery in a microwave oven. Do not place the battery in an environment with extreme low air pressure. Do not place the battery in an environment with extreme high temperature