正面　JP500/说明书/6折页/铜版纸100克/黑白印刷/ 成型尺寸 160*160mm 展开尺寸 960*160mm

JP500 Wireless Dartboard

User Manual

14+

Express setup

Mark the position of the bull's eye



Product Introduction





Can use a 5V/2A power adapter to power JP500Can be used as a connection hole for JP500 expansion devices, requiring the use of the provided transmission line

Accessories List

Tip x 30	Barrel x6	Shaft x6	Flight x6	peg x4	Screw x4

Instructions for use

1. Insert the power cord and connect it for power supply



2. Turn on the power switch



3. Download and start the client.Please scan the following QRCodeto download SDBplay 2.0

Google Play　App Store

4. The blue light stays on and establishes a connection



JP500 parameters

Product Name	Product Size	Power Input	Wire Frequency	Product Weight	Rated Power
JP500	510*510*47mm	5V2A	2.4G	3.2 Kg	10W

Function Description

Power supply

5V/2A power supply (power supply below 2A will not start properly), TYPEC interface.

Key function

Replacement button (red):

In the APP game, press to switch directly to the next player.

Back button:

In the APP game, pressing once can return to the previous dart.

MISS sensing function

When the dart fails to hit the target area, it will automatically be judged as MISS score.

Target block LED luminous function

1. After powering on and turning on the power switch, all the LED lights behind the target blocks of the product will light up, with a default light of 01 game background color.Note: If the LED of the product cannot be controlled after power failure, please restart the app and connect it to restore normal LED changes.
2. LED brightness adjustment function

反面

Wireless connection function

1. The product uses an automatic connection method through the app to seamlessly connect to the dartboard. There is no need to manually adjust any settings. Simply open the app, and it will automatically connect to the dartboard.
2. After downloading and installing the app, please ensure that all settings are enabled by default for proper functionality.

Once you open the app, it will automatically connect with the product.

- When the wireless connection is not established, the blue LED in the middle of the red button will flash.
- Once the wireless connection is successful, the blue LED will stay on.

Required Reading Items:

Troubleshooting:

Verify that the device's connection is enabled.

On your smart device, go to "Settings," remove the conencted device, and restart the app.

If the battery of your smart device is too low, please recharge it and restart the app.

If the issue persists, please click "Help" > "connection Issue" in the app for further assistance.

APP setting product model

After installing the app for the first time, you need to select the JP500 model first, otherwise the LED change function cannot be used normally.

The operation steps are as follows:

In the upper left corner of the APP lobby interface, open Settings, as shown below:



Required Reading Items

Wireless connection

Step:

1. Confirm that the phone's Bluetooth is on
2. Turn on the dart target power supply
3. Open the application to automatically connect to Bluetooth

Troubleshooting:

1. Confirm whether to enable device Bluetooth
2. On the smart device side, "set" to remove this Bluetooth device and restart the application
3. The battery of the smart device is too low. Please recharge and restart it
4. Repeating the above actions still cannot eliminate the problem. Please click "Help">"Bluetooth issue" in the application

transport

- Do not place items on the front of the dart target to prevent the scoring system from malfunctioning

install

- The inability of the dart target to be perpendicular to the ground will result in a significant decrease in the target rate
- Unstable shaking of the dart target will result in incorrect scoring
- Be sure to wipe the wall before pasting EasyFit
- It is recommended to use wall locking screws to directly fix the dart target to the wall or use wall hanging holes. This installation method does not require additional installation of foot pads and gaskets

apply

- Please use soft darts with a total weight of more than 14 grams and less than 25 grams. Do not use metal darts, as it may cause serious damage to the product or result in no score
- When the dart needle breaks, please use tweezers to remove it. If it cannot be removed, it will not affectthe use of the product
- To remove the upper target dart, please use a clockwise rotation to remove it. Do not forcefully pull the dart needle/dart rod thread and break it inside the dart body. Use a screwdriver to press the broken point and turn the thread out



- The dart needle/dart rod thread is broken in the dart body, please use screwsKnife, press down on the fracture and turn out the screw teeth
- Display the target block card key, Find the target block on the application that displays the adapter key, confirm if it is in the correct position, and ensure that the wall surface is flat
- Dart accessories are all consumables, and breakage and damage are normal phenomena and are not included in the warranty scope. This product is compatible with the "soft darts" sold on the market
- Children under 14 years old must be accompanied by a guardian for use

Manufacturer: Dongguan Jiaxu Electronic Products Co., Ltd
Service Phone: 400-960-8196

Address: No. 220, Zhen'an West Road, Chang'an Town, Dongguan City, Guangdong Province
E-mail: service@smartdartboard.com

How to get a dart

There are many ways to hold a dart, try to find the most suitable way to hold it. The key is not to let the dart lose its balance, and do not use excessive force with your fingers when holding it

Placing the dart on the index finger can maintain the balance of the dart

Gently press the thumb and flip upwards to provide slight support from other fingers

How to stand

When throwing a dart, be sure to stand steadily and support your body to step on the throwing line, but do not exceed the line

Oblique dart target

This is the most standard standing method, which is not only easy to aim, but also easy to adjust the position of both feet and center of gravity. However, the angle can easily change with the dart thrown. Please always pay attention to whether there is any deviation between the standing posture and the angle

Forward dart target

This standing posture is easy to maintain the same angle, but due to the inability to lean forward, the actual throwing distance is relatively long. It is a relatively rare standing method

Side to side dart target

This standing posture is to stand with the foot against the throwing line. The bidding line for the PDC Professional Championship is a raised platform, which can be easily maintained at the same angle. However, please note that if the center of gravity is too placed on the front foot, the rear foot may easily l eave the ground and cause instability in the standing posture



Introduction to Basic Games

There are seven built-in modes in the application software, including 01 games, cricket, bonus points, Hearts Hunter, league, practice, and party games. Contains the most basic and common games, and every novice player should try them out

01Game
Whether beginners or experts in darting without false attacks, they will challenge a mode where the basic score is deducted in reverse, and the player who deducts zero points first wins

Cricket game or name 'Mickey Mouse'
Popular options second only to 01 games. 15. 16, 17, 18, 19, 20 and Hearts are effective areas, and hitting other numbers will not be counted. Precision oriented Psychological warfare is more exciting with different modes of multi player play

Bonus game
24 darts in 8 rounds, calculate the total score. A game that beginners must learn to effectively record whether they continuously create high scores

Red Heart Hunter
Only by hitting the red heart will the score be calculated
The player with the highest total score wins, with a red heart score of 25 and a black heart score of 50

League mode
Quickly establish multiple mixed competitions of different types, most suitable for competing with friends

Practice mode
Multiple practice projects that focus not only on Hearts, but also on practicing the accuracy of various parties in a diverse way
Through practice mode training, one can become more proficient in formal competitions

party game
There is no difference between beginners and experts. Family gatherings and parties are the most popular ways to stir up the atmosphere. Don't worry if you will lose due to technical differences. Different pleasures are waiting for you to discover

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.