Rechargeable Portable Speaker SKHK-01 instruction manual

FRONT PANEL DESCRIPTION

1-LED Display Dimmer(Hidden Touch-Sensor)
2-Alarm Clock Set lcon
3-Wireless Set lcon
4-Wireless Charging Display
5-Night Light Dimmer(Hidden Touch-Sensor)
6-Function Knob
7-Battery On Display
8-Room Temperature Display

BACK PANEL DESCRIPTION

9-Wireless Charging Module ("Rubber Cross"' on Top)
10-Reset Button
11-TYPE-C Charging Input
12-USB Charging Output
13-TYPE-C Charging Output
14-Temperature Sensor

POWER AND FUNCTION KNOB

Charging status/non-charging status

Press the Function Knob (6) for 3 seconds to turn the device On. Please do the same to turn it Off.

Thanks to its internal battery, The device can work without a charger Battery icon（7）will not light up. Still,It still won't charge your phone wirelessly until the charger is back up.

FUNCTION KNOB

• Turn the device On and Off (press and hold)

• Set an alarm (click once in clock mode)

• 12-hour/24-hour time (turn left or right on clock mode)

• Cycle between Wireless, and Clock modes (quick double click)

• Pair to your smartphone, play/pause music, and adjust the volume playing via Wirele

WIRELEES FUNCTIONS

Note: The clock will adjust automatically on your device when you pair it to your smartphone via Wireless, so we recommend doing this first. Once your smartphone is synced with the device,you can also control all audio settings remotely. The control knob can also pause and unpause music by pressing it, as well as adjusting the volume by turning it.

wireless connection

If this is the first time turning the device On or a previous smartphone has disconnected, It will automatically go into pairing mode the Wireless icon（3） will start blinking. On your smartphone, go to settings and turn Wireless On. Your smartphone will start searching for nearby devices to pair with.Once paired, select SKHK-01, The Wireless(3) icon on the device will remain lit.

Disconnect

Go to your smartphone settings and click on the "i" icon next to SKHK-01; this will bring you to another screen where you can "Disconnect" or "Forget This Device." If successfully done, your device will start blinking the wireless icon（3） again and a "ready for pairing" prompt

Mode conversion

Power on defaults to wireless mode

Quickly double-tap the function knob (6) to switch from wireless mode to CLOCK MODE

WIRELESS CHARGING

This device comes equipped with wireless charging. Lay your smartphone on the Wireless Charging Module (9) on top of the device. If aligned correctly, the screen on your smartphone will light up, and so will the Wireless Charging icon (4) on the device.

Note: The phone must have wireless charging capability, and the machine needs to be plugged in.

CLOCK MODE

Do a quick double-click on the Function Knob (6) to toggle from wireless mode to Clock mode.

SET AN ALARM

Click the Function Knob (6) once, and the Alarm icon will light up;the first two numbers will also blink,letting you set the hour first. Use the hidden sensors ✋ (1) or ♀ (5) to increase or decrease the numbers. Click the knob again to set the minutes and repeat the process. Click one more time to exit.Your alarm is now set, and the display will turn to the current time.

TURN THE ALARM ON AND OFF

Long press on hidden sensor ✋ (1) to turn alarm on or off The icon (2) lights up when the alarm is on and disappears when it is off. Note:Alarms will only go off when you turn them on, but not when you turn them off.

Note: Long press on hidden sensor ✋ (1) hidden sensor to enter the snooze mode

when the alarm is On and ringing.The alarm will ring every 10 minutes; if you don't touch it, it will ring every 10 minutes (three times total).Click the Function Knob (6) or Click the   (1or5) during snooze to turn off the snooze function; there will be no more alarms

## NIGHT LIGHT/DISPLAY DIMMER/ROOM TEMPERATURE

NIGHT LIGHT

Short press hidden sensor ☕ (5) hidden sensor to turn the light on under the device. Press again to make it more intense and once more for its brightest. Pressing it one more time will turn it off. Repeat as desired.

DISPLAY DIMMER

Short press hidden sensor 👆 (1) hidden sensor to cycle through the display's four brightness stages.Repeat as desired.

Note: To ensure good contact with the hidden sensors (1 and 5), we recommend touching them with a clean finger, without gloves or anything that can scratch the display.

CELSIUS & FAHRENHEIT TEMPERATURE (CLOCK MODE ONLY)

You can display the room temperature in Celsius or Fahrenheit. To do this,Long press to hide ☕ (5) sensor to toggle between your preferred reading.

Note: The room's reading will depend on whether the device is open or enclosed. The sensor in the back collects information around it in an area of approximately 10feet.

Product Parameters

Power Supply Interface: USB Type-C

Wireless Charging Input Voltage: DC 5V

Wireless Output Power:5W/7.5W/10W/15W

Wireless Distance: 3mm-6mm (max)

FCC Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular installation. If this equipment does cause
harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
--Reorient or relocate the receiving antenna.
--Increase the separation between the equipment and receiver.
--Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
--Consult the dealer or an experienced radio/TV technician for help.
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement
This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
This device can operate without distance restriction between the radiator and user body.

For BT function, the device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

For wireless charger function, the device has been evaluated to meet general RF exposure requirement. This device must operate with a minimum distance of 20 cm between the radiator and user body.