Charging Instructions for Mic:

- Connect the Type-C end of the cable to the Type-C Charging port located at the bottom of the Mic. And the USB end of the cable to a suitable power source.
- While charging, the LED indicator on the Mic will turn red. It will turn off when fully charged.

Troubleshooting:

1. If the indicator light does not turn on, pls check if the speaker is sufficiently charged. If not, sufficiently charge the speaker. It takes around 3 to 4 hrs to charge the speaker fully.
2. If there is no sound in the microphone. Check if the mic is on. Alternatively, check if it is in the correct mode. Also check if the volume is suitably positioned.
3. If the microphone produces static noise, it may be due to ambient noises, signal interference, or microphone being too close to the speaker, etc., please re-adjust the position of the microphone.
4. If Bluetooth playback is interrupted, it may be because the source device is too far from the speaker, or there is an obstacle between the source device and the loudspeaker, affecting the signal transmission. please keep speaker within appropriate range from the source device.
5. If Bluetooth cannot be connected, it may be because the distance is too far, or there are obstacles, or the speaker is already connected to other source, please bring the source device closer to the speaker to limit obstacles, or disconnect earlier paired devices.
6. If speaker / mic does not charge, please check if charging cable is connected appropriately, and if the charging source is a suitable one.

Caution:

- Failure to follow all instructions may result in electric shock, fire and/or serious injury.
- Do not dispose of batteries in the garbage. Disposal of batteries in the garbage is unlawful in the United States, under state and federal environmental laws and regulations
- All rechargeable batteries will degrade over time, eventually limiting the battery's ability to retain a charge. This unit contains a lithium-ion rechargeable battery pack, which must be disposed of properly when it will no longer retain a charge.
- Do not expose battery to intense heat or dispose of in a fire as this might result in an explosion.
- Do not expose to intense sunlight or temperatures above 120F (49C).
- Do not expose to moisture or submerge in liquid.
- Do not disassemble the product on your own
- If unit is not working despite all trouble shooting methods, take it to a qualified technician for repairs.
- This is not a toy.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help

Product information

- Bluetooth Model: BB-2
- Speaker output: 5W
- Battery: 18650 – 800mAh; 14500 – 400mAh Lithium battery
- Charging voltage: DC5V
- Frequency range:90Hz-18KHz
- Power mode: DC charging and built-in Battery
- 3.7V high performance battery

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this device

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
For Speaker: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.
For Microphone: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

LIMITATION OF LIABILITY

Liability limited to the purchase price of this product. TV Direct LLC shall not liable for any consequential or incidental damages or any implied warranty on this product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above exclusion or limitation may not apply to you.

TV Direct LLC,
385, Fifth Avenue,
New York City, NY 10016
©2025
Item No : 03879
MADE IN CHINA

Charging Instructions for Mic:

- Connect the Type-C end of the cable to the Type-C Charging port located at the bottom of the Mic. And the USB end of the cable to a suitable power source.
- While charging, the LED indicator on the Mic will turn red. It will turn off when fully charged.

Troubleshooting:

1. If the indicator light does not turn on, pls check if the speaker is sufficiently charged. If not, sufficiently charge the speaker. It takes around 3 to 4 hrs to charge the speaker fully.
2. If there is no sound in the microphone. Check if the mic is on. Alternatively, check if it is in the correct mode. Also check if the volume is suitably positioned.
3. If the microphone produces static noise, it may be due to ambient noises, signal interference, or microphone being too close to the speaker, etc., please re-adjust the position of the microphone.
4. If Bluetooth playback is interrupted, it may be because the source device is too far from the speaker, or there is an obstacle between the source device and the loudspeaker, affecting the signal transmission. please keep speaker within appropriate range from the source device.
5. If Bluetooth cannot be connected, it may be because the distance is too far, or there are obstacles, or the speaker is already connected to other source, please bring the source device closer to the speaker to limit obstacles, or disconnect earlier paired devices.
6. If speaker / mic does not charge, please check if charging cable is connected appropriately, and if the charging source is a suitable one.

Caution:

- Failure to follow all instructions may result in electric shock, fire and/or serious injury.
- Do not dispose of batteries in the garbage. Disposal of batteries in the garbage is unlawful in the United States, under state and federal environmental laws and regulations
- All rechargeable batteries will degrade over time, eventually limiting the battery's ability to retain a charge. This unit contains a lithium-ion rechargeable battery pack, which must be disposed of properly when it will no longer retain a charge.
- Do not expose battery to intense heat or dispose of in a fire as this might result in an explosion.
- Do not expose to intense sunlight or temperatures above 120F (49C).
- Do not expose to moisture or submerge in liquid.
- Do not disassemble the product on your own
- If unit is not working despite all trouble shooting methods, take it to a qualified technician for repairs.
- This is not a toy.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help

Product information

- Bluetooth Model: BB-2
- Speaker output: 5W
- Battery: 18650 – 800mAh; 14500 – 400mAh Lithium battery
- Charging voltage: DC5V
- Frequency range:90Hz-18KHz
- Power mode: DC charging and built-in Battery
- 3.7V high performance battery

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this device

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
For Speaker: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.
For Microphone: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

LIMITATION OF LIABILITY

Liability limited to the purchase price of this product. TV Direct LLC shall not liable for any consequential or incidental damages or any implied warranty on this product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above exclusion or limitation may not apply to you.

TV Direct LLC,
385, Fifth Avenue,
New York City, NY 10016
©2025
Item No : 03879
MADE IN CHINA