K50

云台自拍杆支架



产品说明书

产品介绍



远程遥控

连接蓝牙:
向下拨动开关 开机，LED灯闪烁蓝灯即已开机然后打开手机的蓝牙选项，搜索设备蓝牙名为:**SelfieCom**点击完成配对，显示已连接即完成。





远程遥控

1.开机:向下拨动开关 开机,指示灯闪烁进入搜索状态。
2.连接:打开手机蓝牙搜索"SelfieCom"点击连接，连接成功后指示灯熄灭。
3.拍照:遥控器与手机处于连接状态时单击拍照键，指示灯闪烁并拍照。
4.休眠:开机后连接好蓝牙，无操作5分钟，设备进入的低功耗休眠状态，点击按键唤醒，自动回连手机蓝牙。
5.关机:向上拨动开关关机,指示灯闪烁熄灭并关机。
6.回连:再次开机时，会默认回连已经连接过的手机蓝牙。

关于安卓系统手机个别出现按遥控器为加音量/调焦距/或无反应的问题的解决方案
1:打开相机进入拍照界面。2:向左滑动或者找到相机设置。3:点击音量键功能。4:将音量键功能设置为快门(不要选缩放或者对焦)。5:个别手机相机设置路径不同,请自行查找

落地支架模式



自拍杆模式



Information to User

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
--Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver
--Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
--Consult the dealer or an experienced radio/TV technician for help
NOTE: This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

⚠WARNING
- **HAZARDOUS HAZARD** - This product contains a button cell or coin battery. **DEATH** or serious injury can occur if swallowed.
- If swallowed, Button cell or coin battery can cause **Internal Chemical Burns** in as little as 2 hours.
- **KEEP** new and used batteries **OUT OF REACH of CHILDREN**
- **Seek immediate medical attention** if a battery is suspected to be swallowed or entered inside any part of the body.

Made in China

K50

SELFIE STICK



Product instructions

Product Introduction



Remote Control

Connect wireless:
Pull down the switch to turn on the device, and the LED light will flash. The blue light indicates that the device has been turned on. Then turn on the Wireless option on the phone, search for the device's Wireless name as "SelfieCom", and click on "Complete Pairing" to display "Connected".



Remote Control

1. Power on: Pull down the switch to turn on the device, and the indicator light will flash to enter the search mode.
2. Connection: Open your phone's wireless and search for "SelfieCom". Click on the connection button, and the indicator light will turn off after the connection is successful.
3. Taking photos: When the remote control is connected to the phone, click the photo button, the indicator light will flash and take a photo.
4. Sleep: After turning on the device and connecting to wireless, if there is no operation for 5 minutes, the device enters a low-power sleep state. Click the button to wake up and automatically reconnect to the phone's wireless.
5. Shutdown: Turn the switch upwards to shut down, the indicator light will flash and turn off, and then shut down.
6. Reconnect: When turned on again, it will default to reconnecting to the Bluetooth of the phone that has already been connected.

A Solution to the Problem of Individually Pressing the Remote Control to Increase Volume/Adjust Focus/or Not Responding on Android System Mobile Phones
1: Open the camera to enter the photography interface. 2: Swipe left or find the camera settings. 3: Click on the volume button function. 4: Set the volume key function to shutter (do not select zoom or focus). 5: Individual mobile camera settings have different paths, please search for them yourself

Floor support mode



Selfie stick mode



Information to User

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
--Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver
--Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
--Consult the dealer or an experienced radio/TV technician for help
NOTE: This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

⚠WARNING
- **HAZARDOUS HAZARD** - This product contains a button cell or coin battery. **DEATH** or serious injury can occur if swallowed.
- If swallowed, Button cell or coin battery can cause **Internal Chemical Burns** in as little as 2 hours.
- **KEEP** new and used batteries **OUT OF REACH of CHILDREN**
- **Seek immediate medical attention** if a battery is suspected to be swallowed or entered inside any part of the body.

Made in China