CozyBuds W29 说明书 80G书写纸 单色双面印刷 90*90mm 扇贝折首 6页5折

TALIX

ULTRA
OPEN EARBUDS X6

Clip-on
WIRELESS EARBUDS

Refreshing and beautifully fit. Say goodbye to slipperiness and enjoy an effortless experience

Parameter

Device Name	TALIX Earbuds X6
Wireless Version	V5.4
Transmission Distance	15M
Driver Unit	10mm
Frequency Response	20Hz~20KHz
Impedance	34Ω±10%
Sensitivity	105dB
Charging Case Battery Capacity	250mAh
Earbud Battery Capacity	35mAh
Charging Times of Charging Case	3 Times
Input	5V⎓500mA
Play Time	≥6H/2H
Standby Time	≥180H
Charging Time	≤2H
Net Weight	≈4g
Charging Case Size	70*47*30mm
Product Model	CozyBuds W29
FCC ID: 2ANJC-W5X6	
IC: 50635-W5X6	

FUNCTIONS

Function	Operation	Prompt tone
Connect to phone	Search device name in connect TALIX Earbuds X6	Connected
Voice assistant	Press and hold L/R earbud for 3s	DU
Play/Pause	Press L/R earbud once	DU
Answer a call	Press L/R earbud twice when a call comes in	DU
Reject a call	Press and hold L/R earbud for 3s when a call comes in	DU
End a call	Press L/R earbud twice during a call	DU
Previous track	Press L earbud 3 times	DU
Next track	Press R earbud 3 times	DU
Volume +	Press R earbud once	DU
Volume -	Press L earbud once	DU
Power on	Open the charging case and earbuds will turn on automatically	Power on
Power off	Put earbuds into charging case, close the case, and the earbuds will turn off automatically	Power off
Low battery alert	In any powered state, if battery voltage is below 3.3V, low battery alert sounds once every 5min	Battery low
Factory reset	When not connected to the phone, press L and R earbuds simultaneously 5 times	Power off
Battery level display	Phone displays the earbuds battery level (requires phone compatibility)	
Disconnect	When earbuds are paired in the charging case and the case is closed, they disconnect; when the case is opened, the earbuds turn on and reconnect automatically	Disconnected
Charging case indicator light		
Earbuds in case	Charging case: red light flashes once (red light flashes when charging case is in low battery)	/
Earbud for charging case	Charging case: red light stays on while charging	/
Charging case fully charged	Charging case: light turns off when fully charged	/

Cautions

Temperature/humidity range: Place the product in a dry and ventilated space, avoid contact with corrosive substances, and keep away from fire and heat sources. The product should be charged once every 3 months during storage. Working Temperature:0~40℃ Storage Temperature:-20~45℃
Working humidity: Less than 70%. Storage humidity: Less than 70%

Warning: 1. Do not use any abrasive detergent to clean this product.
2. Do not place this product in a place with high temperature such as a cooking stove.
3. Do not expose this product to direct sunlight for a long time.
4. Do not dispose of this product in the fire to avoid explosion.
5. Do not disassemble, squeeze, puncture, or make modifications, for it does not contain any maintenance components. 6. Do not use this product in the rain.
7. If the product is not for use for a long period of time, please store it in a dry environment, and charge it at least once a month to extend its life and avoid extreme temperatures and dust.

Notice
1. Do not use this product under high temperature or environment of high humidity, high cold, high dust, high pressure, and strong electromagnetic interference.
2. Do not use non-original charging accessories to charge.
3. Charging time does not exceed 2.5H.
4. Do not place the product in a place with heat for a long time.
5. Do not exceed 40 decibels when used for a long time to avoid hearing damage.
6. Do not disassemble or self-maintenance on warranty.
7. Do not use the product in the rain. It can be used in a professional recycling agency. Do not chop it at will, so as not to pollute the environment.

General Safety Information

① Do not attempt to disassemble the earbud to avoid damaging your earbud or causing battery spontaneous combustion, explosion, or other dangerous situations.
② Ears are the earbud while driving, follow your local regulations.
③ Do not place this wireless earbud in high temperatures (above 50°C/122°F), for example,exposure to theSun, to avoid damaging its wireless performance or reducing its battery life.
④ Using the earbud at high volume for a long time may damage your hearing.

Troubleshooting

Problems	Causes	Solutions
Cannot Power on	Dead battery	Charge the earbud
Cannot charge	The charge plug was not connected tightly or correctly	Redo charge charge
Cannot connect to APP	Bluetooth connection failed or cannot the earbud pairing	Use Bluetooth to charge and reset
Cannot find the earbud	The earbuds did not enter the pairing state	Let the earbud go into pairing mode
Cannot upload	Certain phone's wireless application program and wireless	Power off and pair with the earbud for one time

United Kingdom (UK) compliance

This warranty does not apply:
(A) to a product that is out of warranty;
(B) to damage caused by operating the product outside the permitted or intended uses described by KGIS;
(C) to damage caused by unauthorised repairs or modifications carried out without the authorisation of KGIS;
(D) if warranty claim and proof of purchase cannot be presented;
(E) to damage caused by earthquake, fire or other external causes;natural disasters, etc.
Note: The warranty does not include product transport costs and does not provide on-site maintenance services.

JBR reserves all rights to clarify this warranty interpretation. ⚠

Warranty Feedback Form(Tick Off)

A. Pin issued B. Sound quality deteriorates C. Button malfunction D. Unable to pair other devices
E. Can not be recharged F. Others

Buying time

Dealers of sale

Time of problems

User's contact info

FCC Statement

FCC ID: 2ANJC-W5X6
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
(A) Reorient or relocate the receiving antenna.
(B) Increase the separation between the equipment and receiver.
(C) Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
(D) Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body.
We are not responsible for any radio or television interference caused by using other than specified or recommended modifications to this equipment. Unauthorized changes or modifications could void the user's authority to operate the equipment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

ISED Statement
This device complies with Innovation, Science and Economic Development Canada licence-exempt RSS standard(s). **Operation is subject to the following two conditions:**
(1) this device may not cause interference; and
(2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence.
L'exploitation est autorisée aux deux conditions suivantes:
(1) l'appareil ne doit pas produire de brouillage; et
(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Exposure of humans to RF fields (RSS-102)
The device employs low gain integral antennas that do not emit RF field in excess of Health Canada limits for the general population; consult Safety Code 6, obtainable from Health Canada's Web site at **http://www.hc-sc.gc.ca/.**
The radiated energy from the antennas connected to the wireless adapters conforms to the IC limit of the RF exposure requirement regarding IC RSS-102 issue 5.

HDI Statement

Exposition des êtres humains aux champs radioélectriques (RF) (CNR-102)
Cet équipement utilise des antennes intégrales à faible gain qui n'émettent pas un champ électromagnétique radiofréquence dépassant les limites de Santé Canada pour la population générale; consulter le Code de Sécurité 6 sur le site Web de Santé Canada à l'adresse **http://www.hc-sc.gc.ca/.**
L'énergie émise par les antennes reliées aux adaptateurs sans fil respecte la limite d'exposition aux radiofréquences telle que définie par Industrie Canada dans le document CNR-102, version 5.

パラメーター

デバイス名	TALIX Earbuds X6
ワイヤレス バージョン	V5.4
伝送距離	15M
ドライバー ユニット	10mm
周波数応答	20Hz～20KHz
インピーダンス	34Ω±10%
感度(dB)	105dB
充電ケースのバッテリー容量	250mAh
イヤホン バッテリー容量	35mAh
充電ケースの充電時間	3 Times
入力	5V⎓500mA
再生時間	≥6H/2H
スタンドバイ時間	≥180H
充電時間	≤2H
正味重量	≈4g
充電ケース サイズ	70*47*30mm
製品モデル	CozyBuds W29

機能

機能	操作	プロンプト・トーン
電話に接続	接続するデバイス名を検索 TALIX Earbuds X6	接続済み
音声アシスタント	L/R イヤホンを 3 秒間長押しします	DU
再生/一時停止	L/R イヤホンを 1 回押します	DU
着信に応答	L/R イヤホンを 2 回押します (着信上の場合)	DU
通話を拒否	L/R イヤホンを 3 秒間長押しします (着信上の場合)	DU
通話を終了	L/R イヤホンを 2 回押します (通話中)	DU
前のトラック	L イヤホンを 3 回押します	DU
次のトラック	R イヤホンを 3 回押します	DU
音量＋	R イヤホンを 1 回押します	DU
音量－	L イヤホンを 1 回押します	DU
電源オン	充電ケースを開く、イヤホンが自動的にオンになります	電源オン
電源オフ	イヤホンを充電ケースに入れ、ケースを閉じるとイヤホンが自動的にオフになります	電源オフ
低バッテリー アラート	電源オン状態で、3V 未満の場合、低バッテリー警告音が 5 分に 1 回鳴ります	低バッテリー
工場出荷時の状態にリセット	電話と接続していないときは、L および R イヤホンを同時に 5 回押します	電源オフ
バッテリー レベルのディスプレイ	電話とイヤホンのバッテリー レベルが表示されます (電話の互換性が必要です)	/
USB	イヤホンを充電ケースに入れた状態でケースを閉じると、切断されます。ケースを開くと、イヤホンへの電源オンとペアリング、自動的に再接続されます	切断済み
充電ケースのインジケーター・ライト		
付属充電ケースに入った状態	充電ケース: 赤色の点滅2 回 (充電ケース内バッテリーが残り少ない場合は赤色に点滅)	/
充電ケース内のイヤホン	充電ケース: 充電中は赤色のライトが点灯	/
充電ケース満充電	充電ケース: フル充電後、赤色のライトが消灯	/

注意

保管/湿度範囲: 製品を乾燥した換気の良い場所に保管、腐食性物質に接触しないようにし、火元や熱源から遠ざけて保管してください。保管時には、製品を 3 か月に 1 回充電する必要があります。
動作温度: 0～40℃ 保管温度:-20～45℃ 動作湿度: 70% 未満 保管湿度: 70% 未満

警告: 1. 製品の清掃に研磨剤洗剤を使用しないでください。
2. 本製品を調理ストーブ、火源の近くに置かないでください。
3. 本製品を長時間ご直射日光にさらすことはないでください。
4. 本製品を爆発を防ぐために火の中に廃棄しないでください。
5. 本製品は分解できません。メンテナンス部品が含まれていないため、本製品を分解して修復を試みようとしないでください。
6. この製品を雨の中で使用しないでください。
7. 製品を長期間使用しない場合は、乾燥した環境に保管してください。また、乾燥を防ぐために、電池は最低でも月に 1 回は充電してください。

通知
1. 本製品は、高温/すさまじい湿度/強い電磁干渉下、腐蝕に乗じ場所、低ごつの寒い場所、高電圧/高気圧/より高の場合下で使用しないでください。
2. 非純正の充電器を充電アクセサリーに使用しないでください。
3. 充電時間は 2.5 時間を超えないようにしてください。
4. 本製品を熱源の近くに長時間置かないでください。
5. 聴覚に損傷を与えないように、長時間使用する場合は 40 デシベルを超えないようにしてください。
6. 分解/メンテナンスは保証期間内に実施しないでください。
7. 本製品は雨の中で使用しないでください。専門のリサイクル業者に預けることができます。環境を汚染しないように自由に切断しないでください。

トラブルシューティング

問題	原因	解決策
電源がつけられない	バッテリー切れ	イヤホンを充電する
充電できない	充電プラグが正しくまたはきちんと接続されていない	充電を再開する
電話とペアリングに失敗しました	第三者のイヤホンペアリングアプリを開いました	充電器を使用してペアリングする
電話とペアリングできません	イヤホンがペアリングモードに入っていません	イヤホンをペアリングモードに入れる
アプリにアップロードできません	特定の電話のペアリングアプリケーションとワイヤレス接続時エラー	一度、電源オフし、イヤホンをペアリングする

日本語(ジャパニーズ)のクイックガイド

ようこそ!
本製品をBluetooth 5.0 対応の電話またはデバイスに接続して音楽をお楽しみください。
ご購入前に、お使いの電話またはデバイスが Bluetooth 5.0 以上の規格を満たしていることを確認してください。本製品に組み込まれた充電容量は、通常の使用条件下で約 6 時間の連続再生を提供するように設計されています。ただし、実際の使用パターンや環境条件は異なる場合があります。最適な性能を確保するために、定期的に充電することをお勧めします。

周波数帯	周波数範囲	最大伝導電力
2.4GHz帯	2412 - 2472 MHz Bluetooth 5.0	2.45 - 3.50 dBm LE 1Mbps

ご注意事項と使用環境要件では、用アンシン使用の観点、特定、周波数帯動作設定で周波数帯の干渉を使用する行いは各国の電波法に違反する可能性があります。
本製品は、電波法に基づく技術基準に適合しており、日本国内(国内)(海外を含む)に無線機(電波を発する機器)を使用する無線機器の使用を推奨しております。

ご注意事項を遵守の上、ご使用の無線機器の種類(無線設備)に特定の電力無線規格に対してアンプ等 増幅器の調整のご使用をご使用ください。
ご使用の無線機器(無線設備)の種類(無線設備)に対して電波干渉の事例が発生した場合には、直ちに、使用周波数を変更するなどの適切な措置を講じるようお願いします。
ご使用の無線機器(無線設備)の種類(無線設備)に対して電波干渉事例が発生した場合には、直ちに、使用周波数を変更するなどの適切な措置を講じるようお願いします。

ご使用の無線機器(無線設備)の種類(無線設備)に対して電波干渉事例が発生した場合には、直ちに、使用周波数を変更するなどの適切な措置を講じるようお願いします。

ご注意事項
1. 本製品は、高温/すさまじい湿度/強い電磁干渉下、腐蝕に乗じ場所、低ごつの寒い場所、高電圧/高気圧/より高の場合下で使用しないでください。
2. 非純正の充電器を充電アクセサリーに使用しないでください。
3. 充電時間は 2.5 時間を超えないようにしてください。
4. 本製品を熱源の近くに長時間置かないでください。
5. 聴覚に損傷を与えないように、長時間使用する場合は 40 デシベルを超えないようにしてください。
6. 分解/メンテナンスは保証期間内に実施しないでください。
7. 本製品は雨の中で使用しないでください。専門のリサイクル業者に預けることができます。環境を汚染しないように自由に切断しないでください。

ペアリング方法
1. イヤホンを充電ケースに入れ、ケースを閉じるとイヤホンが自動的にオフになります。
2. 充電ケースを開くと、イヤホンが自動的にオンになります。
3. 電話のイヤホンを設定する場合は、電源の横に進ってください。
4. ワイヤレス充電の場合ケースが電源横に充電できるため、ワイヤレス イヤホンを直接ケース内でペアリングする場合は、ケースを閉じてください。
5. イヤホンを充電ケースに長時間保管すると、電池を長期間 2 年間保存します。

用語対照

日本	中国	解説
電源オン/オフ	开机/关机	イヤホンを充電する
充電/充電中	充电/正在充电	充電中/充電
電源オフ/電源入	第一次操作イヤホン、プロンプトなしでペアリング	充電時間長、工場出荷のシャットダウン
電源オフ/ペアリング	长按L/R耳机5秒进入配对模式	イヤホンをペアリングモードに入れる
充電ケースのインジケーター	指示灯指示充电盒状态	一般的、電源オフ、バッテリーレベルペアリングなど

日本語(ジャパニーズ)のクイックガイド

ようこそ!
本製品をBluetooth 5.0 対応の電話またはデバイスに接続して音楽をお楽しみください。
ご購入前に、お使いの電話またはデバイスが Bluetooth 5.0 以上の規格を満たしていることを確認してください。本製品に組み込まれた充電容量は、通常の使用条件下で約 6 時間の連続再生を提供するように設計されています。ただし、実際の使用パターンや環境条件は異なる場合があります。最適な性能を確保するために、定期的に充電することをお勧めします。

周波数帯	周波数範囲	最大伝導電力
2.4GHz帯	2412 - 2472 MHz Bluetooth 5.0	2.45 - 3.50 dBm LE 1Mbps

ご注意事項と使用環境要件では、用アンシン使用の観点、特定、周波数帯動作設定で周波数帯の干渉を使用する行いは各国の電波法に違反する可能性があります。
本製品は、電波法に基づく技術基準に適合しており、日本国内(国内)(海外を含む)に無線機(電波を発する機器)を使用する無線機器の使用を推奨しております。

ご注意事項を遵守の上、ご使用の無線機器の種類(無線設備)に特定の電力無線規格に対してアンプ等 増幅器の調整のご使用をご使用ください。
ご使用の無線機器(無線設備)の種類(無線設備)に対して電波干渉の事例が発生した場合には、直ちに、使用周波数を変更するなどの適切な措置を講じるようお願いします。
ご使用の無線機器(無線設備)の種類(無線設備)に対して電波干渉事例が発生した場合には、直ちに、使用周波数を変更するなどの適切な措置を講じるようお願いします。

ご注意事項
1. 本製品は、高温/すさまじい湿度/強い電磁干渉下、腐蝕に乗じ場所、低ごつの寒い場所、高電圧/高気圧/より高の場合下で使用しないでください。
2. 非純正の充電器を充電アクセサリーに使用しないでください。
3. 充電時間は 2.5 時間を超えないようにしてください。
4. 本製品を熱源の近くに長時間置かないでください。
5. 聴覚に損傷を与えないように、長時間使用する場合は 40 デシベルを超えないようにしてください。
6. 分解/メンテナンスは保証期間内に実施しないでください。
7. 本製品は雨の中で使用しないでください。専門のリサイクル業者に預けることができます。環境を汚染しないように自由に切断しないでください。

ペアリング方法
1. イヤホンを充電ケースに入れ、ケースを閉じるとイヤホンが自動的にオフになります。
2. 充電ケースを開くと、イヤホンが自動的にオンになります。
3. 電話のイヤホンを設定する場合は、電源の横に進ってください。
4. ワイヤレス充電の場合ケースが電源横に充電できるため、ワイヤレス イヤホンを直接ケース内でペアリングする場合は、ケースを閉じてください。
5. イヤホンを充電ケースに長時間保管すると、電池を長期間 2 年間保存します。

用語対照

日本	中国	解説
電源オン/オフ	开机/关机	イヤホンを充電する
充電/充電中	充电/正在充电	充電中/充電
電源オフ/電源入	第一次操作イヤホン、プロンプトなしでペアリング	充電時間長、工場出荷のシャットダウン
電源オフ/ペアリング	长按L/R耳机5秒进入配对模式	イヤホンをペアリングモードに入れる
充電ケースのインジケーター	指示灯指示充电盒状态	一般的、電源オフ、バッテリーレベルペアリングなど

現代機器の進歩、時間性、あるいはプロンプトスケジュール、環境の高な加重があると機器の故障の発生の恐れ。定期性インプット、あるいはペアーリングペアリングの設定は適時設定可能性のとして、内蔵プログラム、ペアーリング を使用することを推奨致します。
他の電子機器に対して使用と設置されの機器が干渉を発生させる可能性があるため、使用する前に、本製品の電源をスイッチ切にしてください。
本製品は、電源スイッチ切にしてから、ご使用前に必ず充電されてからのご使用をお願いします。
本製品は、高温でかつ湿度の高い場合は、ご使用を控えてください。

本製品は、規格品から1年間、ワンウン保証、材料および技術の通常使用および取り扱いを条件とする保証が適用されます。お日なる保証期間に関連する問題に関連しては、無料の修理および交換保証が適用されます。

1. 製品保証は下記は適用されません。
(A) 期限切れの製品
(B) 販売店によって指定された以外の保証期日内の修理以外で製品を操作した場合に発生した損傷。
(C) 販売店以外で指定された方法、修理、または定期点検。
(D) 保証カードおよび購入証明書を提示できない場合。
(E) 地震、火災、または外部の外的、自然災害などによって発生した損傷。
(F) 保証に関連する輸送費は含まれません。オンサイト保守サービスは提供されません。

JBR は、本保証の解釈を明確にする権利を有します。 ⚠

保証フィードバック フォーム(チェックしてください)

A. 保存日付 B. 音質が悪化 C. ボタンの不具合 D. 他のデバイスとペアリングできない
E. 再充電できない F. その他

購入時期

販売商店

問題の発生時期

ユーザーの連絡先情報