HP iPAQ Voice Messenger
Product Guide

© Copyright 2008 Hewlett-Packard Development Company, L.P.

HP iPAQ products are powered by Microsoft® Windows Mobile® 6.1 with Messaging and Security Feature Pack.

Microsoft Windows, the Windows logo, Outlook, Windows Mobile Device Center, and ActiveSync are trademarks of Microsoft Corporation in the U.S. and other countries.

Java and all Java-based trademarks and logos are trademarks or registered trademarks of Sun Microsystems, Inc. in the U.S. and other countries.

SD Logo is a trademark of its proprietor.

Bluetooth® is a trademark owned by its proprietor and used by Hewlett-Packard Development Company, L.P. under license.

Google and Google Maps™ are trademarks of Google Inc.

All other product names mentioned herein may be trademarks of their respective companies.

Hewlett-Packard Company shall not be liable for technical or editorial errors or omissions contained herein. The information is provided 'as is' without warranty of any kind and is subject to change without notice. The warranties for Hewlett-Packard products are set forth in the express limited warranty statements accompanying such products. Nothing herein should be construed as an additional warranty.

This document contains proprietary information that is protected by copyright. No part of this document may be photocopied, reproduced, or translated to another language without the prior written consent of Hewlett-Packard Development Company, L.P.

First Edition September 2008

Document Part Number: 496988-001.

Table of contents

1 Welcome to your HP iPAQ and product registration

2 Box contents

3 Components

Front panel components 3
Top panel components 4
Left and Right panel components 5
Back panel components 5

4 Set up your HP iPAQ

Step 1: Remove the battery cover and insert the SIM card 7
Step 2: Insert the battery and replace the battery cover 8
Step 3: Charge the battery 9
Step 4: Turn on your HP iPAQ 9

5 Get started with your HP iPAQ

Home screen 11
Getting Started 12
Status icons 12
Keyboard 13
Answer/Send key 13
End key 13
Home key 13
Back key 13
Softkeys 13
Keyboard layout 13
Enter text 14
Enter key 15
Backspace key 15
Shift key 16
Options key 16
Symbol key 16
Center Select button 16
Know your HP iPAQ 16
Find information about your HP iPAQ 17
Access programs 17

View the operating system (OS) information 17
Check the connection and signal strength 18
Customize your HP iPAQ 18
Create a device name 18
Enter owner information 18
Change the regional settings 18
Adjust the volume settings 19
Adjust the ring tone and notification sounds 19
Manage profiles 19
Use profiles 19
Edit profiles 20
Change the power management settings 20
Adjust the brightness settings 20
Increase the font size 21
Install and remove programs 21
Set clocks and alarms 22
Use Key Guard 22
Lock and unlock your HP iPAQ 23
Use the SIM PIN to protect information on your HP iPAQ 24
Battery saving tips 24
HP Power Save Mode 25

6 Use your HP iPAQ

Call features 26
Make calls 26
Make calls from the Home screen 26
Make calls from Contacts 26
Redial a number 26
Answer calls 26
Mute a call 27
Put a call on hold 27
Create an appointment during a call 27
Use call waiting 27
Make emergency calls 28
Make calls using speed dial 28
Make data calls 28
Make a conference call 29
Make a call from a hyperlinked phone number 29
Make international calls 29
Use voice mail 29
Use the handsfree function 30
Call history 30
Manage calls using call history 30

Make calls using call history 30
View the call details 30
Voice commands 31
Change the service settings 31
Auto Answer 31
Band Control 31
Call Options 32
Forward calls 32
Call waiting 33
Caller ID 33
Block calls 33
Configure channels 34
Fixed Dialing 34
Change the network settings 35
View the available phone networks 35
Set the preferred networks 35
Manually select a phone network 36
Select a frequency band 36
Voice notes 36
Create a voice note 36
Listen to voice notes 36
Rename voice notes 37
Reply to e-mails using voice notes 37
Delete voice notes 37
Reset your HP iPAQ 37
Perform a soft reset 37
Perform a hard reset (factory reset) 38

7 Storage cards

Insert a storage card 39
Remove a storage card 40
View contents of a storage card 41

8 Contacts

Create a contact 42
Edit the contact information 42
Copy a contact 42
Create and assign a category for a contact 43
Find a contact 43
Send an e-mail message to a contact 43
Send a text message to a contact 43
Add or remove a picture 44
Delete a contact 44

Use the contact list 44

9 Messaging

Understand messages 46
Text messaging 46
MMS and its uses 47
Set up e-mail accounts 48
Set up e-mail using Exchange Server 48
Internet e-mail 48
Create a new POP3 or IMAP4 account 48
Change the e-mail download options 50
Delete an account 50
Synchronize e-mail 51
Use messaging 51
Folder types 51
Compose and send e-mails 52
Reply to or forward a message 52
Add an attachment to a message 53
Receive attachments 53
Receive meeting requests 53
Create or change a signature 54
Download messages 54
Download messages from a server 55
Install an online address book 55

10 Calendar

Create a new appointment 57
Assign a sensitivity level to an appointment 57
Change the display of the work week 57
Set a default reminder for all new appointments 58
Update an appointment 58
Cancel an appointment 58

11 Tasks

Create a new task 59
Create and assign a category to a task 59
Set the start and due dates for a task 59
Show the start and due dates in the task list 59
Mark a task as completed 60

12 Camera

Use the camera 61
Capture photos 61

View photos 61
Camera settings 61
Basic settings 61
Photo settings 62
Use the video recorder 65
Record videos 65
Video settings 65
Transfer images 66
Use GPRS 66
Use Bluetooth 66

13 Connections
Use Wireless Manager 67
HSPA/GPRS/EDGE 67
HSPA 67
GPRS/EDGE 68
Differences between GSM and GPRS/EDGE/WCDMA/3G technology 68
Configure GPRS network settings 68
Edit an Internet connection 68
Edit WAP information settings 69
Troubleshoot automatic detection 70
Bluetooth 70
Bluetooth terms 70
Open Bluetooth settings 71
Connect to a computer using Bluetooth 71
Create, end, and accept a Bluetooth partnership 72
Edit a Bluetooth partnership 73
Use your HP iPAQ as a wireless modem with Bluetooth 73
Bluetooth device profiles 74
Set up an incoming or outgoing Bluetooth communications (COM) port 74
End a Bluetooth connection 74
Wi-Fi 75
Wi-Fi terms 75
Open Wi-Fi settings 76
Automatically connect to a Wi-Fi network 76
Manually connect to a Wi-Fi network 77
Delete a Wi-Fi network 77
End a Wi-Fi connection 77
Configuring 802.1x authentication settings 78
Advanced settings 78
Connect to intranet URLs 78
Change an intranet URL 78
Set up a WAP gateway 79

Configure advanced proxy settings 79
Advanced connection settings 79
Set up a VPN server connection 80
End a connection 80

14 Synchronization
Synchronization software 81
Set up the Synchronization application 81
Synchronize data and copy files 82
Port data to Microsoft Windows Mobile 6.1 83
Troubleshoot synchronization issues 83
Customized links in WMDC 85

15 Applications
ArcSoft Streaming Player 86
Global Positioning System (GPS) 86
Use GPS 86
Use GPS Connection Utility 87
Google Maps™ for mobile 87
Google Search 88
Launch Google Search 88
HP Help and Support 88
HP Asset Viewer 88
Getting Started 89
Customer Support 89
HP Enterprise Mobility Suite 89
HP iPAQ DataConnect 89
HP iPAQ Key Guard 90
Internet Explorer® 90
Internet Sharing 90
To connect to a computer using a USB data connection 90
To connect to a computer using Bluetooth data connection 91
Java Virtual Machine 91
Jetcet PDF 92
Jetcet Print 92
MSN Messenger 93
Office Mobile applications 93
Word Mobile 93
Excel® Mobile 93
PowerPoint® Mobile 94
OneNote® Mobile 94
Pictures & Videos 95
View the pictures stored on your HP iPAQ or on a storage card 95

View a slideshow 96
E-mail pictures 96
Associate a contact with a picture 96
Assign a picture to the Home screen background 97
HP Snapfish Upload 97
HP Enhance Document 97
Switch to the camera 98
Video support 98
Remote Desktop Mobile 98
SIM Manager 98
Manage certificates 99
Task Manager 99
Voice Commander 100
Windows Live™ 101
Windows Media® Player 103
Clear the Now Playing List 103
Update the Library 103
Use Voice Commander to play media files 104
Windows Update 104

16 Product specifications

System specifications 105
Physical specifications 105
Operating environment 106

17 Guidelines for care and maintenance

Use your HP iPAQ 107
Clean your HP iPAQ 107
Carry or store your HP iPAQ 107
Use accessories 107

18 Frequently asked questions

Battery 108
Connection 110
Synchronization 112
Miscellaneous 112

19 Optional accessories

20 Safety information

General precautions 114
Safety precautions for power cords and accessories 115

Safety precautions for battery packs 115
Safety precautions for docking devices 116
Safety precautions for products with wireless devices 116
Safety precautions for products with modems, telecommunications or local area network accessories 116

21 Regulatory notices

Federal Communications Commission Notice 117
Modifications 117
Cables 117
Declaration of Conformity for Products Marked with the FCC Logo (United States Only) 118
Canadian Notice 118
Avis Canadien 118
European Union Notice 118
Products with 2.4-GHz Wireless LAN Devices 120
France 120
Italy 120
Battery Warning 120
Battery Recycling 120
Battery Disposal 120
Chemical substances 120
Disposal of Waste Equipment by Users in Private Household 121
Equipment Warning 125
Acoustics Warning 125
Airline Travel Notice 126
Medical Electronic Equipment 126
SAR Notice 126
Wireless Notices 127
U.S. Regulatory Wireless Notice 127
Canadian Regulatory Wireless Notice 127
Brazilian Notice 127
Singaporean Wireless Notice 127
Thailand Wireless Notice 128
Wireless LAN 802.11b Devices 128
Wireless LAN 802.11g Devices 128
Bluetooth Devices 128

22 Quick reference

Acronyms 129
Icons used 131

Index 132

1 Welcome to your HP iPAQ and product registration

Welcome and congratulations on the purchase of your HP iPAQ Voice Messenger!

This Product Guide provides you with instructions necessary to set up, use and enjoy your new HP iPAQ. Please read the user instructions contained in this Product Guide before using your HP iPAQ. This Product Guide will give you a comprehensive understanding of all the features and functionalities available in your HP iPAQ Voice Messenger and enables you to use them to its fullest potential.

NOTE: In addition to the instructions contained in this HP iPAQ Product Guide, you can find further product information at www.hp.com/support.

We also invite you to register your new HP iPAQ with Hewlett-Packard to perform the following tasks:

- Access support and services, and get the most out of your HP products.
- Sign up for free support alerts, software updates, and personalized newsletters.

Visit http://www.register.hp.com to register your HP iPAQ or to update your postal or e-mail address after registration. You are required to enter your user ID and registration password to edit your online profile. After registering your HP iPAQ, you will receive an e-mail message on special offers and promotions.

NOTE: Registration is not supported in all countries/regions.

2 Box contents

This illustration shows the items that are included in the box with your HP iPAQ.

(1)	HP iPAQ Voice Messenger
(2)	Getting Started CD with additional software
(3)	1260 mAh Li-polymer removable/rechargeable battery
(4)	Welcome Guide
(5)	Getting Started Guide
(6)	AC adapter **NOTE:** The AC adapter shipped with your HP iPAQ might vary depending on the country/region.
(7)	Micro-USB synchronization cable
(8)	2.5 mm wired stereo headset

3 Components

Identify the different components of your HP iPAQ, understand its functions, and use your HP iPAQ to its full potential.

Front panel components



Component	Description	Function
(1)	Receiver	Use to listen to phone calls, sounds, and notifications.
(2)	Display	Use to view the on-screen contents.
(3)	Right Softkey	Press to access the displayed functions and menus.
(4)	End/Power Key	Performs the following functions: • Press and hold to turn your HP iPAQ on and off. • Press to end a phone call. • Press to return to the **Home** screen from any program. • Press to activate the device from sleep mode.
(5)	Back Key	Press to return to the previous screen or exit a program. Press to activate the device from sleep mode.
(6)	QWERTY Keyboard	Use keys on the keyboard to enter text or dial numbers. Press to activate the device from sleep mode. **NOTE:** The keyboard layout on your HP iPAQ might vary depending on the country/region.

Component	Description	Function
(7)	5-way Optical Navigation with Center Select Button	Navigate up, down, left, and right on the screen. Slide your thumb or finger in the direction you want to scroll. Press the **Center Select** button to select the item highlighted on the screen.
(8)	Microphone	Use the microphone for making phone conversations, recording notes, and providing voice commands to your HP iPAQ.
(9)	Home Key	Press to return to the **Home** screen from any program. **NOTE:** Press and hold to view the **Quick List**.
(10)	Answer/Send Key	Performs the following functions: • Press to answer a call. • Press to make a call from Call or Contacts list. • Press twice to redial the last dialed number. • Press to activate the device from sleep mode.
(11)	Left Softkey	Press to display the **Start** menu from the **Home** screen to access programs and perform the function displayed on the screen.
(12)	LEDs	Indicates battery, network, or device status. • Quick 3 Blink Red - Device or charging error • Blinking Orange - Phone on and out of coverage area, or phone on with no SIM card present • Solid Green - Battery fully charged and connected to the power source • Solid Red - Charging when the battery is low • Blinking Red - Low battery warning

Top panel components



Component	Description	Function
(1)	Back Cover Latch	Press to release the back cover.
(2)	Ringer/Sound Switch	Use to switch off incoming call rings and system notification alert sounds.

Left and Right panel components



Component	Description	Function
(1)	Key Guard Button	Press to lock the keyboard. Press to activate the device from sleep mode.
(2)	Volume Up/Down Key	Press to increase or decrease the volume. Press once to temporarily mute the ringtone and notification sounds.
(3)	Voice Commander Button	Press and hold to launch **Voice Commander**.
(4)	Stereo Headphone Jack (2.5mm)	Use to connect the stereo headphones to your HP iPAQ.
(5)	Micro-USB Connector	Use to connect the Micro-USB synchronization cable and the charger.
(6)	Camera Button	Use to launch the camera to capture photos and videos.

Back panel components



Component	Description	Function
(1)	3.1 Mega Pixel Camera	Auto-focus 5x digital zoom camera, use to capture photos and videos.
(2)	Speaker	Use the speaker to listen to music or as a speakerphone.
(3)	Camera Flash LED	Use the camera flash LED to illuminate your subject while you capture photos.
(4)	Back Cover	Remove to insert or remove the battery, the SIM card, and the microSD card.

4 Set up your HP iPAQ

Follow these steps to set up and use your HP iPAQ. Carefully remove your HP iPAQ and all the components from the box before beginning to set up your HP iPAQ.

NOTE: Do not place your HP iPAQ on a hard surface with the screen facing down. Placing the screen on hard surface can cause scratches on the screen surface.

Step 1: Remove the battery cover and insert the SIM card

1. Press the back cover release latch (1), and then pull the back cover (2) from your HP iPAQ as shown in the figure.



2. Slide the SIM card into the SIM card slot.



NOTE: If the battery is already inserted, remove it before inserting the SIM card. Also, make sure that the metal contacts are facing down and the notched corner is in the correct position. If the SIM card is not properly inserted in the HP iPAQ, (No SIM card installed icon) will be displayed on the title bar at the top-right corner of the screen after you turn on your HP iPAQ.

The SIM card is provided by a mobile phone service provider.

If your HP iPAQ is SIM-locked, please contact your service provider.

Step 2: Insert the battery and replace the battery cover

1. Align the battery connectors on the battery with the housing pins in the battery compartment and insert the battery.



2. Replace the battery cover and press at the top and bottom of the cover until it locks into place.

Step 3: Charge the battery

△ **CAUTION:** To avoid damaging your HP iPAQ or the AC adapter, make sure all the metal connectors are correctly aligned before connecting to the power source.

The battery provides power for your HP iPAQ to operate. Use the AC adapter to charge the battery inside your HP iPAQ.

It takes approximately 2 to 4 hours to fully charge the battery for the first time. Charging might take more time when your HP iPAQ is connected to a powered computer or with non-HP accessories.

To charge the battery:

1. Connect the AC adapter (input: 100-240VAC, 47-63Hz, output: 5VDC, 1A) to an electrical outlet.
2. Connect the other end of the cable to the Micro-USB connector port on your HP iPAQ. The cable connector only fits one way. If the connector does not insert easily, turn it over.

TIP: You can also charge the battery by connecting your HP iPAQ to a USB port on your computer through the Micro-USB synchronization cable. The HP iPAQ must be turned on for it to be charged using the USB connection. The LED indicator turns solid red while the battery is charging.

Step 4: Turn on your HP iPAQ

Press and hold the **Power** key for a few seconds to turn on your HP iPAQ. Follow the instructions on the screen to complete the setup. Use the keyboard to enter information. For more information, see Keyboard on page 13.

NOTE: The first time you turn on your HP iPAQ, it will take a few minutes to become fully functional. The keyboard will not be active during this period.