iBT32 IB (English)
Size: 153mm x 120mm
Printing color: Black
Dec 15, 2014

Warranty iHome.

Limited 1 Year Warranty

iHome Products, a division of SDI Technologies Inc. (hereafter referred to as SDI), warrants this product to be free from defects in workmanship and materials, under normal use and conditions, for a period of one (1) year from the date of original purchase. Should this product fail to function in a satisfactory manner, it is best to first return it to the store where it was originally purchased. Should this fail to resolve the matter and service still be required by reason of any defect or malfunction during the warranty period, SDI will repair or, at its discretion, replace this product without charge. This decision is subject to verification of the defect or malfunction upon delivery of this product to the Factory Service Center authorized by Customer Service.
If service is required, please call Customer Service at 1-800-288-2792 to obtain a Return Authorization Number and shipping instructions.

Disclaimer of Warranty
NOTE: This warranty is valid only if the product is used for the purpose for which it was designed. It does not cover (i) products which have been damaged by negligence or willful actions, misuse or accident, or which have been modified or repaired by unauthorized persons; (ii) cracked or broken cabinets, or units damaged by excessive heat; (iii) damage to digital media players, CD's or tape cassettes (if applicable); (iv) the cost of shipping this product to the Factory Service Center and its return to the owner.
This warranty is valid only in the United States of America and does not extend to owners of the product other than to the original purchaser. In no event will SDI or any of its affiliates, contractors, resellers, their officers, directors, shareholders, members or agents be liable to you or any third party for any consequential or incidental damages, any lost profits, actual, exemplary or punitive damages. (Some states do not allow limitations on implied warranties or exclusion of consequential damages, so these restrictions may not apply to you.) This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. Your acknowledgment and agreement to fully and completely abide by the above mentioned disclaimer of warranty is contractually binding to you upon your transfer of currency (money order, cashier's check, or credit card) for purchase of your SDI product.

Printed in China

iHome.

Model: iBT32

Portable SoundFlask Rechargeable Bluetooth Stereo Speaker

CHARGE
BEFORE
USE

instruction manual

Questions? Contact Customer Service at 1-800-288-2792

BC

iBT32

Introduction

Thank you for purchasing the iHome iBT32 SoundFlask Portable Bluetooth Speaker. This product is designed to provide high quality wireless sound for your iPad, iPhone, iPod, computer, PDA or other Bluetooth audio device.

This instruction booklet explains the basic operation and care of the unit. Please read carefully and keep for future reference.

Maintenance

- Place the unit on a level surface away from sources of direct sunlight or excessive heat.

- Protect your furniture when placing your unit on a natural wood and lacquered finish. A cloth or other protective material should be placed between it and the furniture.

- Clean your unit with a soft cloth moistened only with mild soap and water. Stronger cleaning agents, such as thinner or similar materials can damage the surface of the unit.

iBT32

Table of Contents

iBT32

Included

- iBT32 system
- USB adaptor
- Micro USB to USB cable
- Aux audio cable

iBT32

USB Adaptor and
micro USB to USB cable

Aux audio cable

3

iBT32

Meet Your iBT32

Top

Play/Pause/Pairing Button

REV/End Call Button

Power Button

FWD/Answer Call Button

Microphone

Volume Knob

Status Indicator Lights (front of unit)

Bottom

Micro USB Charging Port (charges unit)

USB Charging Port (to charge devices)

Reset port

RESET

POWER IN

USB OUT 1A

AUX-IN

Aux-in Jack

Pull back splash proof seal on unit to access bottom ports

4

Using the iBT32

Charging the Unit

CHARGE UNIT BEFORE USE

1. Connect the micro USB plug to the micro USB charging port on the bottom of the unit.

Charge via included USB AC adaptor, computer USB port, or other powered USB port

USB Adaptor

iHome iBT32 USB port

OR

Computer connected to working outlet

Computer USB port

Battery Charge Status (unit is ON)	
No light	Dead, needs charging
1 light blinking	16 - 30% charged, needs charging
1 light	31 - 45% charged
2 lights	46 - 60% charged
3 lights	61 - 85% charged
4 lights	86 -100% charged

NOTE: The white Status Indicator Lights on the top front of the unit are activated when the unit is ON or when connected to a charging source via the USB cable.

2. Connect the standard USB plug end of the cable to the included USB adaptor and plug into a working outlet, or attach USB plug to the power USB port on a computer or other USB charging device. **For first time use, charge unit for about 8 hours.**

3. **The Status Indicator Lights on the top front of the unit flash while the unit is charging** and turn solid once the unit is fully charged. See table above for charge status information.

5

Pairing Your Device

Using the iBT32

Pairing is the set-up process to introduce your Bluetooth-capable device to the iBT32. Once your device is paired, the iBT32 can recognize it and you can play your audio through it.

1. Make sure your Bluetooth device is fully charged. Turn on your Bluetooth device and make it "discoverable" by turning on Bluetooth mode (check in Options or Settings).

2. *Press and hold* the ⏻ **Power Button** to turn on the iBT32. *The first time the unit is powered on*, it will enter auto-pairing mode and attempt to connect to a Bluetooth device (if so, skip to step 4). Otherwise, follow step 3 to begin pairing.

3. *Press and hold* the ▶❚❚ **Play/Pause/Pairing Button** for 2 seconds. The iBT32 will beep and the status indicator lights will flash quickly.

4. "iHome SoundFlask" should appear in your device's Bluetooth menu. If "Not Paired", "Not Connected" or similar message appears, select "iHome SoundFlask" to connect it. If prompted for a passcode, enter "1234" on your device's keypad.

For iPhone

For other

5. If pairing is successful, a long beep will sound and the status indicator lights will appear solid white, indicating the iBT32 is ready to play music. There should also be an indication on your device. If no device is successfully paired within 3 minutes the iBT32 will default to previous mode. Once the iBT32 is paired to a device, it will attempt to autolink when the device is within range (about 30 feet).

6

Using the iBT32

Pairing with a Different Device

When you power ON the unit, it will automatically link with the previously paired Bluetooth device as long as that device is still within range (approx. 30 feet). To pair with a different device follow steps 1 - 4 under "Pairing Your Device" on previous page.

Playing Audio Via Bluetooth

1. *Press and hold* the ⏻ **Power Button** to turn on the unit. The status indicators will flash slowly while seeking a linked device then glow solid white when a linked device is in range and detected. You can then listen to audio streamed wirelessly from your paired Bluetooth device.

2. Press the ▶Ⅱ **Play/Pause/Pairing Button** to play audio from your device. Press again to pause play and once more to resume play. When Bluetooth audio is active, the status indicator will glow solid white.

3. Press the ◀◀ **Button** to go to the beginning of the current track or to a previous track. Press the ▶▶ **Button** to go to the next track. *Press and hold* either to search within the current track. You can also use menu and track controls on your Bluetooth device to navigate tracks.

4. Turn the **Volume Knob** to adjust the iBT32 volume. You can also adjust volume on your device.

5. When done listening, *press and hold* the ⏻ **Power Button** to turn the unit OFF.

Using the iBT32

Speakerphone Operation

NOTE: The unit must be powered on and linked to a Bluetooth phone to receive a call.

1. When a call is received, playing music is muted to hear the ring tone. Press the ▶▶ **FWD/Answer Call Button** to answer the call, or press the ◀◀ **REV/End Call Button** to ignore it. For call waiting function, use phone controls on your device.

2. When a call is completed, press the ◀◀ **REV/End Call Button** to end the call and resume previous function.

Using the iBT32

Playing Audio via Aux In

1. Connect one end of the included 3.5mm stereo audio cable to the Aux-in jack on the bottom of the unit under the splash seal and connect the other end to the headphone or line-out jack on your audio device.

2. *Press and hold* the ⏻ **Power Button** on the unit to turn it on.

3. Power on the audio device and use the controls on the device to play or pause audio, and navigate tracks.

4. Turn the **Volume Knob** to adjust the system volume. You can also adjust volume on your device.

5. When done listening, *press and hold* the ⏻ **Power Button** to turn the unit OFF. Remember to turn off your device, too.

NOTE: Make sure no Bluetooth device is playing or you will not hear the aux signal.

Mobile Phone   PC/Tablet   Game Devices   iPod   Laptop   MP3/MP4

Using the iBT32

Charging Devices via USB Port

Note: When operating on internal battery, the unit must be powered ON to charge devices via the USB Port. The iBT32 will charge devices when connected to USB power via the micro USB power in port OR when operating on the internal battery (provided the battery has enough charge). To charge devices via USB while operating on the internal battery, we recommend that the unit be *fully charged first.* The iBT32 will *not* charge external devices via USB when internal rechargeable battery is too low (single indicator is blinking or no indicator). To save battery power, USB charging is limited to 1 hour when no audio is playing.

1. Lift water resistant seal located on the bottom of the unit to expose the USB Port.
2. Connect the standard size end of a USB cable (not included) to the USB Port and connect the other end to the charging port on your device.
3. *Press and hold* the ⏻ **Power Button** on the unit to turn it on.
4. Monitor the charging on your device. If your device does not charge, you must charge your device using the charger that came with it.

Internal Rechargeable Lithium-ion Battery

This device uses an internal rechargeable lithium-ion battery that should last the lifetime of the device. If you suspect your battery may be dead, try charging it several times. If the battery does not recharge, please contact us for repair information.

WARNING/DISPOSAL OF UNIT
Please do NOT attempt to change the battery yourself. If the battery has died and you do not want us to replace your battery, you should follow the disposal instructions below:
• Never dispose of used batteries/electronics with ordinary solid wastes, since they contain toxic substances.
• Always dispose of used batteries/electronics in accordance with the prevailing community regulations that apply to the disposal of batteries/electronics. If there are no local regulations concerning battery/electronics disposal, please dispose of the device in a waste bin for electronic devices.
• Many electronics retailers now recycle batteries and other electronic components at no charge. Check to see which ones in your area do so.

CAUTION
The battery used in this device may present a risk of fire, explosion or chemical burn if mistreated
• Never use or charge the battery if it appears to be leaking, discolored, deformed, or in any way abnormal.
• Never disassemble the unit or attempt to remove battery as that could cause leakage of alkaline solution or other electrolytic substance.
• Always confirm that the temperature is 5°C – 35° C (41° - 95° Fahrenheit) before you charge the battery. Leakage or deterioration of the battery may occur if this warning is not heeded.
• Never expose the battery to any liquid.
• Never expose the battery to excessive heat such as direct sunlight or fire. Never use the battery pack in an unventilated vehicle where excessive internal temperatures may be encountered.
• Always keep the battery out of the reach of infants and small children.

11

Consumer Product Safety Guide

IMPORTANT SAFETY INSTRUCTIONS

When used in the directed manner, this unit has been designed and manufactured to ensure your personal safety. However, improper use can result in potential electrical shock or fire hazards. Please read all safety and operating instructions carefully before installation and use, and keep these instructions handy for future reference. Take special note of all warnings listed in these instructions and on the unit.

1. **Water and Moisture** – The unit should not be used near water. For example: near a bathtub, washbowl, kitchen sink, laundry tub, swimming pool or in a wet basement.

2. **Ventilation** – The unit should be situated so that its location or position does not interfere with its proper ventilation. For example, it should not be situated on a bed, sofa, rug or similar surface that may block ventilation openings. Also, it should not be placed in a built-in installation, such as a bookcase or cabinet, which may impede the flow of air through the ventilation openings.

3. **Heat** – The unit should be situated away from heat sources such as radiators, heat registers, stoves or other appliances (including amplifiers) that produce heat.

4. **Power Sources** – The unit should be connected to a power supply only of the type described in the operating instructions or as marked on the appliance. Only use the AC adapter that came with the unit.

5. **Power-Cable Protection** – Power supply cables should be routed so that they are not likely to be walked on or pinched by items placed upon or against them. It is always best to have a clear area from where the cable exits the unit to where it is plugged into an AC socket.

6. **Cleaning** – The unit should be cleaned only using a warm damp cloth. Do not use solvents, etc.

7. **Objects and Liquid Entry** – Care should be taken so that objects do not fall and liquids are not spilled into any openings or vents located on the product.

8. **Attachments** – Do not use attachments not recommended by the product manufacturer.

9. **Lightning and Power Surge Protection** – Unplug the unit from the wall socket and disconnect the antenna or cable system during a lightning storm or when it is left unattended and unused for long periods of time. This will prevent damage to the product due to lightning and power-line surges.

10. **Overloading** – Do not overload wall sockets, extension cords, or integral convenience receptacles as this can result in a risk of fire or electric shock.

11. **Damage Requiring Service** – The unit should be serviced by qualified service personnel when:
    A. the power supply cable or plug has been damaged.
    B. objects have fallen into or liquid has been spilled into the enclosure.
    C. the unit has been exposed to rain.
    D. the unit has been dropped or the enclosure damaged.
    E. the unit exhibits a marked change in performance or does not operate normally.

12. **Periods of Nonuse** – If the unit is to be left unused for an extended period of time, such as a month or longer, the backup batteries should be removed from the unit to prevent damage or corrosion.

13. **Servicing** – The user should not attempt to service the unit beyond those methods described in the user's operating instructions. Service methods not covered in the operating instructions should be referred to qualified service personnel.

FCC Information

iBT32

FCC ID:EMOIBT32

IC:986B-IBT32

FCC Radiation Exposure Statement

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment.

This device complies with Part 15 of the FCC Rules, operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

- Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAN ICES-3 (B)/NMB-3(B)

IC Statement

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.
Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

The device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS-102 RF exposure, users can obtain Canadian information on RF exposure and compliance.
Le dispositif rencontre l'exemption des limites courantes d'évaluation dans la section 2.5 de RSS 102 et la conformité à l'exposition de RSS-102 rf, utilisateurs peut obtenir l'information canadienne sur l'exposition et la conformité de rf.

Declaration ID:D022536

Troubleshooting

Unit doesn't respond (no power)

- Make sure unit is completely charged.
- Check that all connections are correct and properly plugged in.
- Make sure your device is properly paired with the iBT32.
- Make sure the unit is ON.

Unit doesn't respond (locked up/ "frozen")

If the unit does not respond, try disconnecting it from power source. Insert a paperclip or similar into the Reset port located on the bottom of the unit for about 10 seconds.

Trouble pairing device/computer with iBT32

Bluetooth implementation varies depending on your device's hardware and operating system. Please see our website for updates on pairing.

- When you power ON the speaker, it will automatically link with the last previously paired Bluetooth device if the device is still within range (approx. 30 feet). To pair with a different device you must turn off Bluetooth capability on the already paired device, or take it out of range.
- If your device does not auto-link when within range, re-pair the device. To do so, first delete the iBT32 from your Bluetooth devices menu.
- Make sure your device is working properly. Check your device's manual for details on Bluetooth pairing and linking.

  For further information and to see the latest instructions, visit **www.ihome.com/support**