C19515US_KDUS_AW_UM_01_019_190318

KD INTERACTIVE

Units: mm **Actual Scale**

Printing colors : K

AW

History:

V01: For production based on brief : C19515US_KDUS_brief UM_FR_01_190311

297 mm

210 mm

EN

Data Transfer Share Photos, Videos, Music

It's possible to connect the KURIO Watch Glow to a computer (MAC / PC) and share photos (jpg, gif, png, bmp), videos (avi, mp4, 3gp), music (mp3, amr, wav). Use the Micro USB cable supplied to connect your KURIO Watch Glow.
Please follow these steps:

- Pull up the USB rubber cover on the left side of the watch.
- Insert the Micro USB plug into the KURIO Watch Glow.
- Insert the USB plug (standard size) into your computer's USB port.
- A removable drive will appear on your computer.
  Use this drive to transfer data to and from your KURIO Watch Glow.
- There are 4 folders available in your KURIO Watch Glow drive - Download, Gallery, Music, System.
  Make sure to move the files to and from the relevant folders so they will appear properly on your KURIO Watch Glow.

While files are uploading/downloading, do not disconnect your KURIO Watch Glow. Once finished, remove the watch by following the steps to safely remove hardware from your computer. You can then physically unplug the KURIO Watch Glow from the computer.
Minimum PC requirements: From any version after Windows XP.
Minimum MAC requirements: From any version after MAC OS 10.10.

Tech Support & Warranty Information

If you have any questions about setting up or using your KURIO Watch Glow, please visit us at www.kurioworld.com to learn more. All of our products are backed by a 1 Year Limited Warranty. In the unlikely event that you experience a problem, please visit **www.kurioworld.com/support/** to contact our KURIO Support Team.

Please note, this device is warranted only to the original purchaser for a period of twelve months from the original date of purchase, under normal use and service, against defective workmanship and materials. If the product is damaged due to accident, improper or unreasonable use or maintenance (such as a broken screen, fall, water damage, etc.), these damages are not covered by the warranty.

Warning

Avoid using the KURIO Watch Glow while charging: this may alter the battery charging process and the battery life of the device.
The device should not be exposed to dripping or splashing liquid and never place objects filled with liquid on the device - such as a glass of water.
Do not expose the device to flames.
Never use KURIO Watch Glow while operating a motor vehicle or bicycle.
If you feel discomfort or any pain using KURIO Watch Glow, please stop using it.
If a small part is coming out of the KURIO Watch Glow, don't try to remove it. Keep it away from small children.
Never force a connector into a port of KURIO Watch Glow. Make sure that the micro USB connector matches the USB port.
To clean up the screen, simply use a soft damp cloth. Do not use alcohol, solvent, aerosol spray, liquid or abrasive cleaners to clean your KURIO Watch Glow.
The product and micro USB cable should be periodically examined to check that they are in good condition. In case of defect, the micro USB cable should not be repaired, but replaced.

Restricted Use of Electronic Devices

The use of electronic/electric devices may interfere with safe operation of some aircraft and can be restricted with some airline companies. Please check with your airline company before traveling.

We CATALANA de INVESTIGACION y DESARROLLO de ELECTRONICA S.L.U= declare that the radio equipment type 05017 is in compliance with Directive 2014/53/EU, 2014/30/EU EMC Directive. The full text of the EU declaration of conformity is available at the following internet address: http://kdplanet.com/download/05017_CE.pdf

C19515US_KDUS_AW_UM_01_019_190318
Made in China. Printed in China.

CAN ICES-3 (B)/NMB-3(B)

Imported by:
KD UK
Cardinal Point,
Park Road, Rickmansworth,
WD3 1RE,UK

Kidz Delight, Ltd.
1431 Opus Place Suite 110
Downers Grove
Illinois
IL 60515
United States of America

Waste Electrical & Electronic Equipments must not be disposed of with household waste, these ones must be collected and treated separately. Please check with your local authority to know the collecting areas.

Micro SD Card

You can also share data using a Micro SD Card (sold separately). To insert a Micro SD card, pull up the rubber cover of the Micro SD card on the right side of your KURIO Watch Glow. As soon as you insert a Micro SD card into your KURIO Watch Glow, 4 folders will be created - Download, Gallery, Music, System. Make sure to move the files to and from the appropriate folders so that they can appear properly on your watch. We recommend that you transfer your photos and videos regularly.

Exposure to Radio Frequency Energy

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.
- The device must not be co-located or operating in conjunction with any other antenna or transmitter.

This device complies with RSS247 of Industry Canada.
This device complies with Industry Canada license-exempt RSS standard(s).
Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.
Radiation Exposure Statement: The product complies with the Canada portable RF exposure limit set forth for an uncontrolled environment and is safe for intended operation as described in this manual.
The further RF exposure reduction can be achieved if the product can be kept as far as possible from the user body or set the device to lower output power if such function is available.

Copyrights

KURIO® & KD INTERACTIVE are registered trademarks of CIDE INTERACTIVE S.L.U. © 2019 Kidz Delight, Ltd. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by CIDE Interactive is under license. Other trademarks and trade names are those of their respective owners. MicroSDHC Logo is a trademark of SD-3C, LLC.

Kurio WATCH GLOW
The Ultimate Smartwatch Built for kids

KD INTERACTIVE

USER MANUAL

Safety precautions

- Please do not use the KURIO Watch Glow if you have or had symptoms/signs of skin irritation.
- Do not attempt to disassemble, repair or modify the product or replace the batteries. This will invalidate the warranty. There is danger of explosion if the battery is replaced incorrectly.
- Use only the micro USB cable supplied with KURIO Watch Glow for charging the battery and transferring data. Do not damage or deform the power supply micro USB cable and connector. If it is damaged or deformed, it may cause electric shock or malfunction when used. When removing it from the device, be sure to remove by holding the plug attachment and not by pulling the cord.
- In case of data transfer from the KURIO Watch Glow to the PC or MAC, to avoid data corruption or lost data, follow the instruction in this manual. The user is responsible for any damage or loss of data, the misuse, malfunction or modification.
- If for any reason, the screen (display) is cracked or broken, stop using the product immediately.
- Do not drop the product or subject it to severe impact.
- Do not use and do not expose the device in extreme temperatures (hot or cold), dusty conditions or damp conditions. Do not expose to direct sunlight. Do not expose the device to water, liquids, rain, dust or moisture. If your KURIO Watch Glow is exposed to liquid, power off the device immediately and clean/dry it.
- Avoid using the device near strong magnetic fields. If your KURIO Watch Glow has been exposed to magnetic fields, please restart the device, following the instructions in this manual if necessary.
- Please keep the box and this manual for further reference. This manual may not reflect your actual device's operation. All information is subject to change without prior notification. Please follow your actual device's operational procedures.

WARNING: All packing materials such as internal bags, plastic collars, plastic films and carton inserts should be discarded before handing the device over to a child, for your child's safety.

Apps & Games

- My Little Dragon
- Mood Sensor
- Light & Touch
- Light & Memory
- Sport Challenge
- Tic Tac Toe
- Ninja Roll
- Snake
- Pirates Battle
- Activity Tracker
- Music player
- Light & Party
- Take photos & videos
- Photo Filter
- Drawing
- Messaging
- Phone function
- Phrase Translator
- Time features
- Calculator
- Calendar
- Contact list
- Reminder

Included

- KURIO Watch Glow with rechargeable Lithium battery*
- Micro USB cable
- User Manual

* Battery is not replaceable

WARNING

Please remove the screen protective film before turning on your KURIO Watch Glow.

If you unfortunately find that the screen freezes during initial setup, and that the device cannot be turned off by pressing the power button, please press the Reset button.

To do so - please note that the Reset button is located on the left-hand side of the KURIO Watch Glow, under the USB cover. Once you have lifted the USB cover, you will see a small hole. Insert a paper clip to into the hole, and press once to Reset. This will automatically restart the KURIO Watch Glow.

Getting Started

We recommend fully charging your device before use. A full charge takes about 3 hours. To charge your KURIO Watch Glow, connect it to a USB port with the Micro USB cable included with the product. How long the battery lasts depends on the device usage. More frequent usage drains the battery more quickly. Additionally, some activities require more battery consumption, such as games, videos, Bluetooth® communication, light intensive activities, etc.

BATTERY TIME FOR REFERENCE	
Standby	10 days
Normal Use	1 day
Heavy Use	2 hours

Change the theme



To choose your preferred theme, press and hold anywhere on the screen for 2 seconds to enter the Customization Mode. Swipe Left or Right to select different themes. Then press the screen when you've found a theme you'd like to choose.

Change the Watch face

By going to GALLERY you can also personalize your theme and put your favorite picture as a background. To do so, select the picture and touch .

You can choose between digital and analog watch faces. To choose one face, press and hold anywhere on the screen for 2 seconds to enter the Customization Mode. Swipe Left or Right to select different watch faces. Press the screen when you've found a watch face you'd like to select.

Navigation

Swipe Left and Right to navigate the main menu. Press an icon to select it. Swipe down to display the Option bar. In the Option bar, you can activate or deactivate the flashlight, open the Camera app, use Bluetooth®, enable or disable the LED mode and adjust the volume. Swipe up or press anywhere on the main screen to hide the Option bar. The Option bar is accessible from all screens.

TIP: On many apps & games, swipe right (from left edge) to go back to previous screen.

LED mode

Because Light is an integral part of Kurio Watch Glow, it is integrated into many activities. From the Option bar, press to disable it in order to save battery power.

LED MODE	
ON	OFF
Timer: Light flashes RED during the last 10 seconds. Stopwatch: Light flashes RED once every 60 seconds. Alarm: Wake up with music and light. Low battery warning: Light flashes RED when your watch is about to turn off.	The light related features mentioned on the left section will be disabled.
Tic Tac Toe / Ninja Roll / Snake / Pirate Battle / Sport Challenge The light flashes GREEN whenever you win and RED whenever you lose.	
Activity tracker: Light flashes GREEN when receiving a notification.	
Music player: Light flashes to the beat of your music!	
Light & Touch / Light & Memory / Mood Sensor / Light & Party / My Little Dragon The light cannot be disabled in these games as it is an essential part of their functionality.	

Settings

Swipe to the last screen of the main interface to access the Settings

FOLDER	ITEMS	DESCRIPTION
System	Language	Change the language of the device.
	Bluetooth®	Manage the Bluetooth® features.
	Saving	Decide where to save the photos and videos taken: Internal Memory or Micro SD card (if inserted).
	Factory reset	Reset your KURIO Watch Glow to factory settings. Note: You will lose all your data.
	About	See the firmware version, credits and legal notices.
Display	Time & Date	Set the date and time of your KURIO Watch Glow.
	Theme	Change the theme.
	Watch Face	Change the watch face.
	Notifications indicator	Enable / Disable the notifications for the activity tracker (achievements).
	Screen	Set your KURIO Watch Glow brightness and screen timeout.
Sounds	Volume	Adjust the volume of your KURIO Watch Glow.
	Mute	Enable / disable the sound.
	Incoming call	Select the phone ringtone (when the KURIO Watch Glow is paired to a smartphone by Bluetooth®). MP3 sounds loaded on the internal memory of the KURIO Glow Watch (not on the Micro SD card) can also be used as ringtone.
	Alarm	Select the Alarm ringtone.

Photo Filter

To take fun pictures with frames, click on the icon . Select a filter by using the 2 arrows. To adjust the size use the plus or minus sign. To move it, keep it pressed for a second, then drag and drop it.

M

Wh not unfulfilled dragon need will result in a red flash and a dragon icon appear on the screen. Shall you disable the light notifications, only the dragon icon will appear.

by pressing the .

Play 2-Player Games & Send Messages to another KURIO Watch

Pirates Battle and Tic Tac Toe allow you to play with your friend, while you and your friend both use your own KURIO Watch. The messaging app also allows you to share messages with another KURIO Watch. Bluetooth® connection is required. You must pair two watches in order to connect them for game play and message sharing.

Step 1: Go to the settings
Step 2: Select "Bluetooth".
Step 3: Select "My device".
Step 4: Select "Scan" to find a Kurio Watch around. Kurio Watches are named "KW-..-...".
Step 5: Select the device and press "Pair". If the device was already paired before, just press "Option" and "Connect".

The Messaging App works with Android Tablets & Smartphones. (from any version after Android 4.0). Download the KURIO Watch Messenger on your Android device. The app is available on the Google Play Store. The pairing process is the same as for the pairing with another KURIO Watch Glow described above.

Secret Light Messages

In addi texts, emojis, selfies, doodles and voice recordings, you also have the poss ch-to-watch light m nected via Bluetooth® w low.

Step 1: Open your messaging app and click on
Step 2: Each mess the list and one from
Step 3: Your friend color. Let t responding

ES

Transferencia de datos Comparte fotos, vídeos, música

Existe la posibilidad de conectar su reloj KURIO Glow a su ordenador (MAC/PC) y compartir fotos (jpg, gif, png, bmp), vídeos (avi, mp4, 3gp), música (mp3, amr, wav). Use el cable Micro USB incluido para conectar su reloj KURIO Glow.
Por favor, siga los siguientes pasos:

- Quite la tapa de goma que cubre el Puerto micro USB en el lado izquierdo del reloj.
- Inserte la clavija del cable Micro USB en su reloj KURIO Glow.
- Inserte la clavija USB (tamaño normal) en un puerto USB de su ordenador.
- Un disco extraíble aparecerá en su ordenador.
  Use este disco para transferir archivos desde y a su reloj KURIO Glow.
- Hay 4 carpetas disponibles en este disco - Download, Gallery, Music, System. Asegúrese de mover los archivos a y desde las carpetas adecuadas de manera que aparezcan correctamente en su reloj.

Mientras los archivos se estén subiendo /descargando no desconecte el reloj KURIO Glow. Una vez acabado, desconecte el reloj siguiendo los pasos de extracción de hardware de manera segura. Después puede desconectar físicamente el reloj KURIO Glow de su ordenador.
Requisitos mínimos para PC: versión Windows XP en adelante.
Requisitos mínimos MAC: versión MAC OS 10.10 en adelante.

Información sobre el Soporte Técnico y la garantía

Si tiene alguna pregunta sobre la configuración o el uso de su reloj KURIO Glow, visítenos en www.kurioworld.com para obtener más información. Todos nuestros productos están respaldados por una garantía limitada de 1 año. Visita **www.kurioworld.com/support** para consultar nuestras preguntas frecuentes y la información sobre resolución de problemas, o bien contacte con nuestro servicio de atención al cliente.

Por favor, tenga en cuenta que la garantía cubre solamente al comprador durante un periodo de 12 meses para el dispositivo principal y de 6 meses para la batería y cable, a contar desde el día de la compra, contra defectos de fabricación y materiales en condiciones normales de utilización y mantenimiento.

Los daños producidos por accidente o un uso o mantenimiento inadecuado del producto (como la rotura de la pantalla, caída, daños por agua, etc) no están cubiertos por la garantía.

ADVERTENCIAS

Evite usar el reloj KURIO Glow mientras se esté cargando: esto podría alterar el proceso de carga de la batería y por consiguiente, la duración de la misma. El reloj KURIO Glow no es sumergible. Nunca coloque objetos con líquidos, como vasos llenos de agua, encima del mismo. No exponga el dispositivo a las llamas. No utilice nunca el reloj KURIO Glow mientras esté conduciendo un vehículo a motor o una bicicleta. Si siente alguna molestia o dolor mientras usa el reloj KURIO Glow por favor, deje de utilizarlo de inmediato. Si alguna pieza pequeña sobresale de su reloj, no intente arrancarla. Mantenga el reloj alejado de los niños pequeños. No fuerce nunca en el reloj un conector dentro de un puerto. Asegúrese de que el conector micro USB encaja en el Puerto USB. Para limpiar la pantalla, simplemente use un paño suave y húmedo. No use alcohol, disolvente, espray en aerosol, líquido o limpiadores abrasivos para limpiar su reloj KURIO Glow. Tanto el producto como el cable micro USB deben ser examinados periódicamente para comprobar que se encuentran en buenas condiciones. En caso de observarse algún defecto, el cable micro USB debe ser reemplazado, no reparado.

Tarjeta Micro SD

También puede compartir archivos usando una tarjeta micro SD. Para insertar una tarjeta micro SD, abra la tapa situada en el lado derecho del reloj KURIO Glow e inserte la tarjeta. En cuanto inserte una tarjeta micro SD en su reloj se crearán 4 carpetas - Download, Gallery, Music, System. Asegúrese de que mueve los archivos a y desde las carpetas adecuadas para que aparezcan de modo correcto en su reloj. Le recomendamos que transfiera sus fotos y vídeos regularmente.

Copyrights

KURIO® & KD INTERACTIVE son marcas registradas pertenecientes CIDE INTERACTIVE S.L.U. © 2019. Tanto la marca denominativa como los logos de Kidz Delight, Ltd. The Bluetooth® son marcas registradas pertenecientes a Bluetooth SIG, Inc. y cualquier uso que CIDE Interactive haga de las mismas está sometido a un acuerdo de licencias. Las demás marcas registradas y nombres comerciales pertenecen a sus respectivos propietarios. El logo de MicroSDHC es una marca registrada de SD-3C, LLC ©. Todos los derechos reservados.

Uso restringido de Aparatos Electrónicos

El uso de aparatos electrónicos puede interferir con el funcionamiento seguro de ciertas aeronaves y, por ello, puede estar restringido en algunas aerolíneas. Por favor, compruebe este extremo con su aerolínea.

Por la presente, CATALANA de INVESTIGACION y DESARROLLO de ELECTRONICA S.L.U declara que los equipos radioeléctricos tipo 05017 cumplen con lo establecido en la Directiva 2014/53/EU, 2014/30/EU Directiva EMC. El texto completo de la declaración CE de conformidad está disponible en la siguiente dirección electrónica:
http://kdplanet.com/download/05017_CE.pdf

C19515US_KDUS_AW_UM_01_019_190318
Hecho en China - Impreso en China

CAN ICES-3 (B)/NMB-3(B)

Importado por:
KD UK
Cardinal Point,
Park Road, Rickmansworth,
WD3 1RE,UK

Kidz Delight, Ltd.
1431 Opus Place Suite 110
Downers Grove
Illinois
IL 60515
United States of America

Los residuos eléctricos y electrónicos no deben ser tirados junto con los residuos domésticos. Compruebe con su autoridad local el lugar donde puede deshacerse de los mismos.

Kurio WATCH GLOW
The Ultimate Smartwatch Built for kids

KD INTERACTIVE

GUÍA DE CONFIGURACIÓN

Actividades

- My Little Dragon
- Mood Sensor
- Light & Touch
- Light & Memory
- Sport Challenge
- Tic Tac Toe
- Ninja Roll
- Snake
- Pirates Battle
- Monitor de actividad física
- Reproductor de música
- Light & Party
- Toma de fotos y vídeos
- Filtro fotos
- Dibujo
- Mensajería
- Teléfono
- Traductor de voz
- Cronómetro y alarma
- Calculadora
- Calendario
- Lista de contactos
- Recordatorio

Precauciones de seguridad

- Por favor, no utilice el reloj KURIO Glow si tiene o ha tenido signos de irritación en la piel.
- No trate de desmontar el reloj, repararlo o modificarlo, ni tampoco intente reemplazar por sí mismo las baterías. Estas acciones invalidan la garantía del producto. Existe además, riesgo de explosión si la batería se reemplaza incorrectamente.
- Utilice únicamente el cable micro USB que se proporciona con el reloj KURIO Glow para cargar la batería y transferir los datos. No dañe o deforme el suministrador de energía del cable micro USB o del conector. En caso de estar dañado o deformado, puede causar descarga eléctrica o un mal funcionamiento del dispositivo. Cuando los quite del dispositivo asegúrese de no tirar del cable si no de la clavija.
- Para evitar la corrupción o pérdida de datos a la hora de transferir datos de su Reloj KURIO Glow a su PC o MAC siga las instrucciones de este manual. En caso de no hacerlo, el usuario será el responsable ante cualquier daño o pérdida de información, uso incorrecto, malfuncionamiento o modificación.
- Si por cualquier razón la pantalla se agrieta o rompe, deje de usar inmediatamente el producto.
- No deje caer el producto o lo someta a impactos severos.
- No use o exponga el producto a temperaturas extremas (calor o frío) o a entornos muy polvorientos o húmedos. No lo exponga a la luz directa ni al agua, líquidos, lluvia, polvo o humedad. Si su reloj KURIO Glow ha sido expuesto a líquidos, apáguelo inmediatamente y límpielo/ séquelo.
- Evite usar este dispositivo cerca de fuertes campos magnéticos. Si su Reloj KURIO Glow ha sido expuesto a campos magnéticos, por favor, reinicie el dispositivo, siguiendo las instrucciones si fuera necesario.
- Por favor, guarde la caja y el manual para futuras referencias. Puede ser que este manual no refleje con exactitud el funcionamiento de este dispositivo. Toda la información está sujeta a cambio sin previo aviso. Por favor, siga los procedimientos de funcionamiento actuales.

ADVERTENCIA: Todos los materiales de embalaje, como las bolsas internas y otros embalajes de plástico y cartón deben ser quitados antes de que el niño se coloque el reloj en la muñeca por motivos de seguridad.

Incluye

- Reloj KURIO Glow con batería de litio recargable*
- Cable Micro USB
- Manual de usuario

* La batería no es reemplazable

¡Atencion!

Por favor, retire el protector de pantalla antes de encender su reloj KURIO Glow.

Si la pantalla se quedase congelada durante la configuración inicial del reloj y el dispositivo no se pudiera apagar pulsando el botón de encendido /apagado , por favor presione el botón "Restaurar".

Para hacerlo, tome nota de que el mismo se encuentra en el lado izquierdo de su reloj KURIO Glow, debajo del tapón protector de goma del puerto USB. Una vez que haya abierto la tapa de goma del puerto USB, verá un pequeño agujero. Inserte un Clip en el mismo y presione una vez para restaurar. Esto hará que el reloj KURIO Glow se reinicie.

¡Empecemos!

Recomendamos recargar la batería en su totalidad antes de usar su reloj KURIO Glow. La carga completa de la batería tarda alrededor de 3 horas. Para cargar su reloj KURIO Glow conéctelo al Puerto USB con el cable micro USB que se incluye en este producto. La duración de la batería dependerá del uso del dispositivo. Un uso más frecuente agota la batería más rápidamente. Asimismo, ciertas actividades requieren un mayor consumo de batería, como juegos, vídeos, Bluetooth®, comunicación, etc.

TIEMPO DE REFERENCIA DE DURACIÓN DE LA BATERÍA	
Modo reposo	10 días
Uso normal	1 día
Uso frecuente	2 horas

Cambie el tema

Para elegir su tema preferido, presione durante 2 segundos en cualquier lugar de la pantalla para entrar en el modo personalización. Deslice el dedo hacia la izquierda o derecha para ver los diferentes temas. Cuando haya decidido cuál elegir, presione sobre el mismo.

Cambie la esfera del reloj

Puede elegir entre esferas analógicas o digitales. Para elegir una esfera, presione durante unos segundos en la pantalla para acceder al modo configuración. Deslice el dedo hacia la derecha o izquierda para ver las diferentes esferas. Presione en la pantalla cuando desee elegir alguna.

Yendo a GALERÍA puede personalizar el fondo de pantalla colocando su imagen favorita como fondo. Para ello, seleccione la imagen y haga clic en .

Navegación

Deslice el dedo hacia la izquierda y hacia la derecha para navegar por el menú principal. Pulse un icono para seleccionarlo. Deslice hacia abajo para mostrar la barra de opciones.
En la barra de opciones, puede activar o desactivar la linterna, abrir la aplicación de la cámara, activar Bluetooth®, habilitar o desactiva el modo LED y ajustar el volumen. Deslice hacia arriba o presione en cualquier lugar de la pantalla principal para ocultar la barra de opciones.
La barra de opciones es accesible desde todas las pantallas.

ADVERTENCIA: en muchas apps y juegos, para volver a la pantalla anterior deslice el dedo hacia la derecha (desde el extremo izquierdo)

Modo LED

Debido a que la luz es una parte integral del reloj KURIO Glow, se utiliza en muchas de las actividades. Desde la barra de opciones, presione para desactivarla si quiere ahorrar batería.

MODO LED	
ENCENDER	APAGAR
Temporizador: la luz parpadea en ROJO durante los últimos 10 segundos. Cronómetro: la luz parpadea en ROJO una vez cada 60 segundos. Alarma: Despertarse con música y luz. Advertencia de poca batería: la luz parpadea en ROJO cuando el reloj está a punto de apagarse.	La luz no se puede desactivar en los juegos, ya que es una parte esencial de sus funcionalidades.
Tic tac toe / Ninja Roll / Snake / Pirate Battle / Sport challenge La luz parpadea en VERDE cada vez que ganas y en ROJO cuando pierdes.	
Controlador de actividad física: la luz parpadea en VERDE al recibir una notificación.	
Reproductor de música: ¡La luz parpadea al ritmo de la música!	
Light & Touch / Light & Memory / Mood Sensor / Light & Party / My Little Dragon Las características relacionadas con la luz, mencionadas en la sección izquierda, se deshabilitarán.	

Configuración

Deslice el dedo hacia la derecha hasta la última pantalla del interfaz principal para acceder a la configurac

CARPETA	ELEMENTOS	DESCRIPCIÓN
Sistema	Idioma	Cambia el idioma del dispositivo.
	Bluetooth®	Administre las funciones de Bluetooth®
	Guardar	Decida dónde guardar las fotos y vídeos: memoria interna o tarjeta micro SD (si procede).
	Reinicio	Restaure los valores de fábrica. NOTA: perderá todos sus archivos.
	Créditos	Vea la versión del producto, créditos e información legal.
Pantalla	Tiempo & Fecha	Configure la fecha y hora de su reloj KURIO Glow.
	Temas	Cambie el tema.
	Diseña	Cambie la esfera del reloj.
	Notificaciones	Active / Desactive las notificaciones del monitor de actividad física (logros).
	La pantalla	Configure el brillo e el tiempo de espera de la pantalla de su reloj KURIO Glow.
Sonidos	Volumen	Ajuste el volumen de tu reloj KURIO Glow.
	Silencio	Active / Desactive el volumen.
	Llamadas entrantes	Seleccione el tono de llamada (cuando su reloj KURIO Glow esté asociado con su Smartphone a través del Bluetooth®). Los sonidos de MP3 cargados en la memoria interna de su reloj KURIO Glow (no en la tarjeta micro SD) pueden usarse como tono de llamada.
	Alarma	Seleccione el tono de la alarma.

Filtro de foto

Para tomar fotos divertida res, objetos o marcos, haga clic Seleccione un filtro utilizando las 2 flechas. Para ajustar el tamaño use el signo más o menos. Para mover un objeto, manténgalo presionado durante un segundo y luego arrástrelo hasta donde quiera de la pantalla y suéltelo.

M

Al not con alguna necesidad del dragón insatisfecha, aparecerá un destello rojo y un icono del dragón aparecerá en la pantalla. Si desactiva la función de notificaciones con luz, solo aparecerá el icono del dragón.

configuración de la luz presionando el icono de la puerta .

Modo 2 – Juegos multijugador & mande mensajes a otros relojes KURIO

En los juegos de Pirates Battle y Tic Tac Toe es posible jugar contra un amigo, mientras el niño y su amigo usan el reloj. La app de mensajería también permite mandar mensajes a otros reloj KURIO . Se requiere conexión Bluetooth®. Debe asociar los dos relojes para que estén conectados para jugar y enviar mensajes.



Paso 1: En la opción seleccione "Sistema".
Paso 2: Seleccione "Bluetooth".
Paso 3: Seleccione "Mis dispositivos".
Paso 4: Seleccione "Buscar" para encontrar relojes KURIO cercanos a usted. Todos empiezan por las letras "KW-..-...".
Paso 5: Seleccione el dispositivo que quiere y presione "enlazar". Si no es la primera vez que conecta con este dispositivo, simplemente presione "Opción" y "Conectar".

La app de mensajería funciona con tabletas Android & Smartphones (versión Android 4.0 en adelante).
Descárguese la app KURIO Messenger App en su dispositivo Android. La app está disponible en Google Play Store.

Mensajes secretos con luz

Adem mensajes secret de texto, emojis, selfies, dibujos y grabaciones de voz, también exis IO Glow siempre que est Bluetooth®.

Paso 1: Abrir la app de Mensajes y haga clic en
Paso 2: Cada mens uno de la li res. Elija a enviar.
Paso 3: En el reloj mensaje significado! el color del adivine el