9.36W" x 7.37H" x 7.37D"

THUNDER TUMBLER®
RADIO CONTROL 360° RALLY CAR
OPERATING INSTRUCTIONS
KEEP THIS MANUAL FOR REFERENCE AS IT CONTAINS IMPORTANT INFORMATION.
BASIC CONTROL FUNCTIONS
BATTERY INSTALL
Operation requires 4 "AA" (1.5V alkaline batteries (not included).
1. Locate the battery compartment on the bottom of the car.
2. Carefully remove tabs from package.
3. Insert batteries as shown in the battery compartment. Be sure batteries are installed correctly.
4. Close battery compartment cover.
5. Turn the car over and locate the "ON" switch on the bottom of the car.
6. Turn the car over and place on a level surface and the car will be ready to play.
GENERAL CONTROLS
Forward
Press left control button to move forward.
Reverse
Press left control button to move reverse.
Turning Action
Press and hold the control button to turn the car in the direction shown.
Action Button
Press and hold the action button to turn the car in the direction shown.
SPINNING ON REAR WHEEL (ACTION BUTTON)
Action Button
Press and hold the action button to turn the car in the direction shown.
Action Button
Press and hold the action button to turn the car in the direction shown.
SAFETY PRECAUTIONS
• Do not use the car near water, in the rain or in high humidity.
• Do not use the car near other electronic devices.
• Do not use the car near people with pacemakers.
• Do not use the car near people with medical devices.
• Do not use the car near people with hearing aids.
• Do not use the car near people with epilepsy.
• Do not use the car near people with other medical conditions.
• Do not use the car near people with other medical conditions.
• Do not use the car near people with other medical conditions

9.36W" x 7.37H" x 7.37D"


THUNDER TUMBLER®
RADIO CONTROL 360° RALLY CAR
KEEP THIS PACKAGE FOR REFERENCE AS IT CONTAINS IMPORTANT INFORMATION.
OPERATING INSTRUCTIONS
Operation requires 4 "AA" 1.5V alkaline batteries (not included) for car and one 9V battery (not included) for remote control.
1. Carefully remove all parts from packaging.
2. Locate the battery compartment on the back of each item (see diagram on right).
3. Swivel latches on bottom of car to release battery pack and insert batteries.
4. Switch both car and remote buttons to "ON" position.
5. Place car on smooth surface like car on hard surfaces such as wood or tile.
REMOTE CONTROL ASSEMBLY
USES ONE 9V BATTERY (NOT INCLUDED)
CHARGE SWITCH
ON/OFF SWITCH
BATTERY DIAGRAM
CHARGE SWITCH
ON/OFF SWITCH
RECHARGEABLE BATTERY PACK (NOT INCLUDED)
USE ALKALINE BATTERIES FOR BEST PERFORMANCE
GENERAL CONTROLS
Reverse
Press both control sticks backward.
Forward
Press both control sticks forward.
Spinning Action
Press and hold the control sticks in opposite directions to make the car spin.
ACTION BUTTON
Action Button
Press and hold the action button to have the car stand up on its back wheels and move forward.
SPINNING ON REAR WHEEL (ACTION BUTTON)
1) Spin the car by pressing and holding the control sticks in opposite directions.
2) Press and hold the action button while the car is spinning.
SAFETY PRECAUTIONS
• Adult supervision is recommended when operating this car.
• Do not operate and store batteries at cold temperatures.
• Do not submerge car or controller in water.
• Never operate your car in the vicinity of people, and do not use poison or animals as obstacles.
• Do not place car on hot surfaces, objects or hard surfaces, as this will cause damage to the car and injure people.
• Keep fingers, hair and loose clothing away from the tires, gears and motor while the car is switched to "ON".
• Do not place your car in extreme heat sources of heat or under direct sunlight for long periods of time.
• Do not leave car or transmitter outside overnight. Dampness is harmful to the electronic components.
• Remove all batteries when not in use to avoid accidental operation.
• Adult supervision is recommended when operating this car.
BATTERY WARNING:
• Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
• Insert batteries with the correct polarity (+ and -) as indicated in the battery compartment.
• Remove batteries when not in use. Dispose of dead batteries according to local regulations. Do not dispose of batteries in fire. Batteries may explode or leak.
• Do not short circuit the battery terminals. Do not charge non-rechargeable batteries.
• Do not mix new and used batteries. Do not mix different types of batteries together.
KEEP THIS PACKAGE FOR REFERENCE AS IT CONTAINS IMPORTANT INFORMATION.
WARNING: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
Caution: Use only batteries specified.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
• Consult the dealer or an experienced radio TV technician for help.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.
FC
3980448 [1017]
94202-31583
Made in China
©2014 Mega Brands Inc. Mega Brands Inc. Mega Brands Inc.