FCC/IC ID Label Location

Bottom of Host PC