RAZER MONITOR LIGHT BAR
MODEL: RZ43-0504

USER MANUAL

WHAT'S INSIDE

▪ Razer Monitor Light Bar

A. Angle-adjustable dual lighting

    a. Back lighting Powered by Razer Chroma™ RGB

    b. Ultra-wide white lighting

B. White light brightness button

C. White light temperature button

D. Setting adjustment slider

E. RGB button

F. Power button

G. USB Type C connector

H. Adjustable monitor clip

I. Light bar thread mount

▪ Important Product Information Guide

WHAT'S NEEDED

PRODUCT REQUIREMENTS

- USB Type C port
- 2.4 GHz WiFi network (WPA / WPA2 encryption)
- WiFi-enabled PC / Laptop (Windows® 10 64-bit or higher)*

RAZER SMART HOME APP REQUIREMENTS

- iOS 16.4 / Android 9 (or higher) device with Bluetooth connectivity*
- Internet connection for app installation

RAZER SYNAPSE REQUIREMENTS

- Windows® 10 64-bit (or higher)
- Internet connection for software installation

Bluetooth connectivity required for initial setup only.

LET'S GET YOU COVERED

Your product's serial number can be found here.

Register your product and score exclusive benefits
razerid.razer.com/warranty

SETTING IT UP

1.

USB Type C

> ℹ️ *For optimal performance, make sure to connect the light bar to the USB Type C port of your PC directly.*

2.

OR

> ℹ️ *The recommended screen-frame thickness is 0.5 to 4.5 cm / 0.2 to 1.8 in. The light bar is compatible with various monitor sizes and curvature types.*

3.

CUSTOMIZING THE LIGHTING

A. VIA MOBILE DEVICE USING THE RAZER GAMER ROOM APP (REQUIRED)

1.

RZR.TO/GAMER-ROOM-APP

Razer Gamer Room

2.

Power on

Press

3.

Razer Gamer Room

CREATE A HOME

ADD NEW DEVICE

ADD ROOM

ℹ️ *Launch the app, follow the onscreen instructions and scan the QR code on the light bar. Please make sure that your mobile device is on your preferred 2.4 GHz network.*

You can now customize the Monitor Light Bar using the Razer Gamer Room app.

B. VIA PC / LAPTOP USING THE RAZER SYNAPSE APP

Before proceeding, make sure the light bar is already set up on your network (via the Razer Gamer Room app) and your PC is on the same network.

1.

razer.com/synapse

Update Razer Synapse to its latest version or download its installer from razer.com/synapse. Registering for a Razer ID account is recommended but optional. You may continue as a guest; however, you won't be able to store any of your settings on the cloud.

2.

Power on

Press

3.

Razer Synapse

ADD WIFI DEVICE

GAMER ROOM DEVICES

DEVICES ON THE NETWORK
[Product Name]-XX-XX

Update Razer Synapse when prompted, and wait for Razer Synapse to set up the light bar.

You can now customize the Monitor Light Bar using Razer Synapse.

UNDERSTANDING PAIRING MODE

Reactivating pairing mode

Pairing mode is required when setting up the light bar from the Razer Gamer Room app. It activates when you power on the light bar and deactivates after 5 minutes if the light bar remains unpaired. To reactivate pairing mode, power off and on the light bar.

Resetting to factory settings

Once connected, a reset is required to pair the light bar to a new device. To reset, press and hold the RGB and Power buttons for four (4) seconds. The back lighting will briefly cycle through colors before displaying a wave effect, indicating the reset and activation of pairing mode.

USING THE LIGHT BAR

POWER ON/OFF

Press

PERSONALIZING THE LIGHTING

Enabling / disabling lightings

To disable or enable the white light:

Disable white light   Enable white light


Press and hold   Press

To disable or enable Chroma lighting:

Disable Chroma lighting   Enable Chroma lighting

Press and hold   Press

When both lights are disabled, the light bar is considered 'powered off'. Simply press the power button to power it on, and the light bar will use the last disabled lighting.

Adjusting the white light temperature

Enable temperature
adjustment

Adjust slider

Press

Warmer ← → Cooler

Customizing the Chroma effect

Enable Chroma
lighting

Cycle between
Chroma effects

Press

Press**

**WHITE > RED > ORANGE > YELLOW > RAZER GREEN > BLUE > INDIGO > PURPLE > SPECTRUM
CYCLING > WAVE (LEFT) > WAVE (RIGHT) > WAVE (DIVERGING) > WAVE (CONVERGING)**

**Repeat until the desired lighting effect is active.

Adjusting the brightness of any mode

To adjust the brightness of Chroma lighting:

Enable Chroma
lighting

Adjust slider

Darken ⟵————————⟶ Brighten

Press

To adjust the brightness of the white light:

Enable
white light

Adjust slider

Darken ⟵————————⟶ Brighten

Press

RESETTING TO FACTORY SETTINGS

Once connected, a reset is required to connect the light bar to a new device.

1. Press and hold the RGB and Power button for 4 seconds.

4s

Press and hold

2. Wait for the light bar to briefly shift between colors before displaying a wave (diverging) effect. This indicates that the light bar has been reset and is now in pairing mode.

Find out more about your light bar at support.razer.com

SAFETY AND MAINTENANCE

SAFETY GUIDELINES

To achieve maximum safety while using your Monitor Light Bar, we suggest that you adopt the following guidelines:

- Should you have trouble operating the device properly and troubleshooting does not work, unplug the device and contact the Razer hotline or go to support.razer.com for assistance.

- Don't take apart the device, and don't attempt to operate it under abnormal current loads. Doing so will void your warranty.

- Only use the light bar indoors.

- Organize the light bar's cable to ensure that objects don't tug, pinch, or damage it.

- If the screen bar will not be used for an extended period, please power it off or unplug it.

- Keep the light bar away from liquid, humidity, or moisture. Operate the device only within the specific temperature range of 0°C (32°F) to 40°C (104°F). Should the temperature exceed this range, unplug and/or switch off the light bar to stabilize the temperature to an optimal level.

For indoor use only.

The light source of this luminaire is not replaceable; when the light source reaches its end of life the whole luminaire shall be replaced.

The external flexible cable or cord of this luminaire cannot be replaced; if the cord is damaged, the luminaire shall be destroyed.

This product contains a light source of energy efficiency class F.

MAINTENANCE AND USE

The Monitor Light Bar requires minimum maintenance to keep it in optimum condition. Once a month, we recommend you unplug the light bar from the computer and clean it using a soft cloth or cotton swab to prevent dirt buildup. Don't use soap or harsh cleaning agents.

FCC NOTICE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions,

may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio TV technician for help.

For more information, refer to the online help system on razer.com

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:
1) This device may not cause harmful interference, and
2) This device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

FCC RADIATION EXPOSURE STATEMENT

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

NOTICE FOR CANADA

This Class B digital apparatus complies with Canadian ICES-005.

Cet appareil numérique de la classe B est conforme à la norme NMB-005 du Canada

CANADIAN CLASS B STATEMENT:

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus as set out in the radio interference regulations of Industry Canada.

Le présent appareil numérique n'émet pas de bruits radioélectriques dépassant les limitesapplicables aux appareils numériques de Classe B prescrites dans le règlement sur le brouillage radioélectrique édicté par Industrie Canada.

CANADA STATEMENT

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s).

Operation is subject to the following two conditions:

(1) This device may not cause interference.
(2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence.
L'exploitation est autorisée aux deux conditions suivantes :
(1) L'appareil ne doit pas produire de brouillage;
(2) L'appareil doit accepter tout brouillage
radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This equipment complies with ISED radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body.

Cet équipement est conforme aux limites d'exposition aux rayonnements ISED établies pour un environnement non contrôlé. Cet emetteur ne doit pas etre Co-place ou ne fonctionnant en meme temps qu'aucune autre antenne ou emetteur. Cet equipement devrait etre installe et actionne avec une distance minimum de 20cm entre le radiateur et votre corps.

CE

STATEMENT OF COMPLIANCE WITH EU DIRECTIVE

Razer (Europe) GmbH, declares that this Razer Monitor Light Bar (Model No.: RZ43-0504) is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU & 2015/863/EU.

The full Declaration of Conformity can be requested via the following:
Company: Razer (Europe) GmbH
Address: Alter Teichweg 25, 22081 Hamburg, Germany
E-mail: compliance@razer.com

The full text of the EU declaration of conformity is available at the following internet address:
https://www.razer.com

Wi-Fi 802.11b/g/n (for Europe)
Frequency Band: 2400- 2480Mhz
RF Output power: <20dBm (e.i.r.p for Europe)
Type of modulation: DSSS, OFDM

Bluetooth LE (for Europe)
Frequency Band: 2400- 2480Mhz
RF Output power: <10dBm (e.i.r.p)
Type of modulation: GFSK

LEGALESE

COPYRIGHT AND INTELLECTUAL PROPERTY INFORMATION

©2024 Razer Inc. All rights reserved. Razer, the triple-headed snake logo, Razer logo, "For Gamers. By Gamers.", and "Powered by Razer Chroma" logo are trademarks or registered trademarks of Razer Inc. and/or affiliated companies in the United States or other countries. All other trademarks are the property of their respective owners.

Android, Google, Google Logo, Google Play, and the Google Play logo are trademarks of Google LLC.

Apple, the Apple logo, and iPhone are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc. iOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc., and any use of such marks by Razer is under license.

Windows and the Windows logo are trademarks of the Microsoft group of companies.

Razer Inc. ("Razer") may have copyright, trademarks, trade secrets, patents, patent applications, or other intellectual property rights (whether registered or unregistered) concerning the product in this guide. Furnishing of this guide does not give you a license to any such copyright, trademark, patent or other intellectual property right. The Monitor Light Bar (the "Product") may differ from pictures whether on packaging or otherwise. Razer assumes no responsibility for such differences or for any errors that may appear. Information contained herein is subject to change without notice.

LIMITED PRODUCT WARRANTY

For the latest and current terms of the Limited Product Warranty, please visit razer.com/warranty.

LIMITATION OF LIABILITY

Razer shall in no event be liable for any lost profits, loss of information or data, special, incidental, indirect, punitive or consequential or incidental damages, arising in any way out of distribution of, sale of, resale of, use of, or inability to use the Product. In no event shall Razer's liability exceed the retail purchase price of the Product.

GENERAL

These terms shall be governed by and construed under the laws of the jurisdiction in which the Product was purchased. If any term herein is held to be invalid or unenforceable, then such term (in

so far as it is invalid or unenforceable) shall be given no effect and deemed to be excluded without invalidating any of the remaining terms. Razer reserves the right to amend any term at any time without notice.