70mm

100mm

DELUX 多彩

M600 Series

STRIVE FOR **EXCELLENCE**

精益求精

User Manual 使用说明书



模式切换

通过底部拨动开关，选择2.4G模式(ON)/有线模式(OFF)，进行使用

DPI 按钮

DPI按钮为DPI等级切换功能，通过短按DPI按钮，在不同DPI等级之间进行切换，不同DPI等级会有不同颜色指示灯进行提示

- ·1级-400DPI-红色
- ·2级-800DPI-绿色
- ·3级-1200DPI-蓝色
- ·4级-1600DPI-黄色
- ·5级-3200DPI-黄色
- ·6级-5000DPI-白色

PR按钮/配对

PR按钮为回报率切换开关与配对按键，通过短按[PR] 按钮，在不同回报率等级之间进行切换不同回报率等级会有不同颜色指示灯进行提示

- ·1级-125Hz-红色
- ·2级-250Hz-绿色
- ·3级-500Hz-蓝色
- ·4级-1000Hz-紫色

2.4G连接配对功能，通过长按[PR] 按钮，激活鼠标2.4G连接配对

Connection Mode Switch

Before start to use the mouse, please find the connection mode switch to selectconnection mode between 2.4G(ON)/Wired(OFF)

DPI Button

DPI button is for switching the DPI level.
DPI switching: quick press the DPI button to change the DPI level, each DPI level will be indicated by a different color LED light

- ·Level 1-400DPI-Red
- ·Level 2-800DPI-Green
- ·Level 3-1200DPI-Blue
- ·Level 4-1600DPI-Purple
- ·Level 5-3200DPI-Yellow
- ·Level 6-5000DPI-White

PR Button/Pairing

PR Button is for switching the polling rate and activate the 2.4G pairing: quick press the PR button to change the polling rate, each polling rate will be indicated by a different color LED light

- ·Level 1-125HZ-Red
- ·Level 2-250HZ-Green
- ·Level 3-500Hz-Blue
- ·Level 4-1000Hz-Purple

2.4G Pairing: long press the PR button to activate the 2.4G pairing.

如需详细使用说明请扫描以下二维码
获取M600 电子档说明书

For detailed usage instructions, please scan the
QR code below to access the M600 electronic user manual

电子版说明书
Electronic Manual

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits
are designed to provide reasonable protection against harmful interference in a
residential installation. This equipment generates, uses and can radiate radio
frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and (2) this device must accept any interference

多彩游戏外设天津...
微号：DELUXGAME
扫一扫二维码，加入群聊
QQ

多彩科技公众号
DELUX WeChat Official Accounts

多彩科技官网
DELUX Official Website

DELUX
Official Community

产品中有害物质的名称和含量

根据中国《电子电气产品有害物质限制使用标识要求》

有害物质
Hazardous Substances

部件名称 Parts Name	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)	邻苯二甲酸二丁酯 (DBP)	邻苯二甲酸丁基苄酯 (BBP)	邻苯二甲酸二(2-乙基）己酯 (DEHP)	邻苯二甲酸二异丁酯 (DIBP)
电缆线/电源 Cable/Adapter	X	O	O	O	O	O	O	O	O	O
电路板组件 PWA	X	O	O	O	O	O	O	O	O	O
塑料/其他部件 Plastic/Others parts	O	O	O	O	O	O	O	O	O	O
玻璃部件 Glass parts	X	O	O	O	O	O	O	O	O	O
金属部件 Metal parts	X	O	O	O	O	O	O	O	O	O
电池 Battery	X	O	O	O	O	O	O	O	O	O

本表格依据SJ/T 11364的规定编制。
O=表示该有害物质在该部件所有均质材料中的含量均在GB/T 26572规定的限量要求下。
X=表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572规定的限量要求。
表中标有“X”的所有部件均符合欧盟RoHS Recast 法规 -2011/65/EU指令。

此表提示“多彩科技有限公司”的电子电气产品部件中何处存在这些有害物质。请注意，并非内装产品都包含上述所有部件。
注：环保使用期限的参考标准，取决于产品正常工作的温度和湿度等条件。

此为A级产品，在生活环境中，产品可能会造成无线电干扰。在这种情况下，可能需要用户对干扰采取切实可行的措施。

制造商：

芜湖多彩移动互联设备有限公司
地址:中国安徽省芜湖市湾沚镇新芜区西次3路多彩工业园

MANUFACTURER
WUHU DELUX MOBILE INTERNET DEVICE CO.,Ltd
Delux Industrial Park, No.3 Xici Road, Xinwu District,
Wanzhi Town,Wuhu City,Anhui Province, P.R. China

合格证
深圳市多彩实业有限公司
质检员:
QC01 PASS

保 修 服 务 卡

感谢您对多彩产品的信任与支持，我们将竭诚为您提供满意的服务，请准确清晰的填写相关条目，以确保您的合法权益。

多 彩 产 品 保 修 卡

产品型号		维 修 记 录
制造编号		
购买日期		
用户电话		
销售商电话		

备注：请清楚填写各条目，勿擅自涂改，并妥善保管好本保修服务卡，以维护您的合法权益。如果保修服务中有任何疑问，请咨询本地经销商或与我们联系，请拨打免费电话:4006990600

产品售后服务指南

购买多彩产品，在质保期内产品出现质量问题用户可以选择：
①前往多彩的服务中心进行维修，维修流程为：在我们工作人员的指导下填写用户信息注册单，等待我们的工程师为您检测及维修或更换产品。
②如果本地或者附近没有多彩的产品服务中心，您可以凭借购买记录，联系购买的渠道（平台）进行维修或者更换处理，相对应用产生的费用，双与购买平台协商后再行承担。
③对于已经停产了在质保期内的产品，多彩将按照国家规定提供免费维修的服务保障。

保修期的确认

多彩保证您的多彩硬件产品自购买之日一年内不会出现材料和性能方面的缺陷。并提供为期一年(从购买之日起)的保修服务。保修期自最终用户购买之日起算起,以最终用户的购机发票(注明型号、主机序列号(S/N)，并由代理商盖章)或发票复印件及有效保修卡为凭证，若用户无法提供以上证明，则按照用户购买本公司产品的出厂日期计算保修日期。出厂日期根据主机序列号(S/N)判断。保修标签被人为破坏，本公司不给予免费保修，如需维修需收取相应的材料费用。

保修条件

1、所有配件必须为本公司产品标准配件并在保修期内。
2、以下情况不予保修：
①人为地自行拆卸、修理、安装;
②使用非本公司部件;
③使用了未经公司认可的扩展部件或外围设备导致本公司标准部件损坏或产生故障;
④不慎使异物进入设备、溢输、移动、辐射等造成的物理损坏及故障;
⑤不可抗力所有地震、火灾等自然灾害或意外事故(被盗,丢失)等不可抗力引起的设备不能正常工作。

设计说明：
1、尺寸：100x70mm(公差+/-1mm)
2、材质：157g双铜覆哑膜
3、颜色：CMYK双面印刷
5、装订方式：风琴折页

DELUX 多彩	深圳市多彩实业有限公司 SHENZHEN DELUX INDUSTRY CO., LTD.		
	名 称	M600 Ultra标准说明书 保修卡	
	料 号	R3.4.0M60006001A	
分 发	☐研发部 ☐产品部 ☑资材部 ☑品保部 ☑生产部 ☑工程部 ☑海外营销部 ☐国内营销部 ☑文控中心	批 准	审 核
	设 计	毛武峰/2023-1-4	