REMOTE CONTROLLED CAR
INSTRUCTIONS

INSTALLING BATTERIES AND BATTERY SAFETY

Requires 2 x AA batteries (not included) for the Remote Controlled Car.



Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.





NOTE: Battery life varies depending on usage

To insert the batteries, twist the dome cover anti-clockwise to open. Remove the car from the pedestal and slide the battery compartment cover open. Unscrew the pedestal from the battery compartmentcover using a screwdriver. Place 2 x AA batteries in the poduct, ensuring they are fitted the right way round observing + and- signs on the battery and product, taking care not to danage the batteries or contacts. Replace the battery compartrent cover ensuring it is secure.

If battery leakage occurs and comes in contact with the skin or eyes wash immediately with lots of water.
Rechargeable batteries should not be used.
Follow equipment instructions carefully and always use recommended type of batteries.
Do not allow children to fit batteries without adult supervision.

Replace all batteries at the same time. Do not mix new and old batteries or batteries of different types.
Store batteries away from metal objects. Never short circuit batteries.
Remove batteries if equipment is not going to be used for extended periods of time.
Store batteries in a cool place away from direct sunlight.
Remove exhausted battery promptly and dispose of in household waste.
Do not put batteries in fire.
Never disassemble batteries.
Do not attempt to revive batteries by heating, charging or other means.

Also place the antenna into the hole at the top of the remote control and turn clockwise. DO NOT OVER TIGHTEN.
Gently pull the tip of the antenna to extend.



CHARGING THE CAR

Open the cover at the bottom of the remote control.
Align metal nodes on the remote control with the nodes on the car and gently push to connect. The charging indicator light will come on when the car is charging.
It is fully charged when the light is turned off.
Carefully take the car off the remote control.



HOW TO OPERATE

The remote control is fully functional.
To make the car go, push the forward or reverse button.
The car will turn left and right when the left or right button is pressed.
The car will only turn left and right when it is moving in forward or reverse direction.
The operating light will come on when the car is in use.
Once the car is discharged, recharge the car as above.
The car will not charge when the batteries in the remote control need replacing.
This is indicated by the red light becoming faint. The batteries are then replaced as above.



OTHER INFORMATION

Occasionally the car will sway left or right while moving in forward or reverse direction. To correct this, adjust the directional guide on the bottom of the car as shown in the illustration below.

For best results use on desktops, wooden floors and other smooth surfaces.

Directional guide

WARRANTY

In addition to your statutory rights Boots The Chemist Limited agrees that if any defect in materials or workmanship appears in the product within TWO YEARS after the original date of purchase, we will offer a refund. This applies only if the product has been used solely for domestic purposes and has not been damaged through misuse, accident or neglect and has not been modified or repaired by anyone other than Boots or its authorised agents.
If a defect appears, please check that the article is being used properly in accordance with the instructions. If so return it with this warranty and the Boots Certificate of Purchase or some other proof of date of purchase to the nearest branch of Boots that stocks this article or similar articles as soon as possible.
Boots The Chemists Limited reserves the right to modify this product without notice.

Store these instructions in a safe place for future reference.
The Boots Company PLC
Nottingham England
www.boots.com

Made in China
IMPORTANT: For additional safety, check toys regularly for signs of damage during use.
Adult supervision is recommended at all times.
Please keep a note of our Company name and address and all safety warnings / information.
WARNING: Not suitable for children under 36 months.
Contains small parts which could represent a choking hazard to young children.