User Manual

NOTICE

USING YOUR NAVIGATOR at the first time

1. Charge completely

2. Install into your vehicle

3. Initialize software as described in the manual

4. Make sure that the car is outside the garage and it is not covered by anything (treed, bridges, etc)

5. Normally it takes a bit longer to receive the GPS signal the first time you turn on the unit. Your device has to locate 3 satellites to function. This time to find the satellites is significantly shorter after the first time you use the device. If you move your unit over 300km without it being used, it may need a little more time to locate the satellites again.

Introduction

This manual is a complete instruction for the device. Please read this manual carefully before using.

Contents:

Safety and Regulatory Information

Important Safety Notices and Warnings

Global Positioning System

The Global Positioning System (GPS) is a satellite-based system that provides location and timing information around the Globe.

GPS is operated and controlled under the sole responsibility of the Government of the United States of America, who are responsible for its availability and accuracy. Any changes in GPS availability and accuracy, or in environmental conditions, may impact the operation of your device .We cannot accept any liability for the availability and accuracy of GPS.

Precautions and Notices

For your own safety, do not operate the controls of the product while driving.

Use this product prudently. The product is intended to be used only as a navigation aid. It is not for precise measurement of direction, distance, location or topography.

The calculated route is for references only. It is the user's responsibility to follow the traffic signs and local regulations along the roads When you get off the car, do not leave your device on the dashboard or the car glass that is subject to direct sunlight. The overheating of the battery can cause malfunction and /or danger.

GPS is operated by the United States government, which is solely responsible for the performance of GPS. Any change to the GPS system can affect the accuracy of all GPS equipments.

GPS satellite signals can not pass through solid materials (except glass).When you are inside a tunnel or building, GPS positioning is not available.

A minimum of 4 GPS satellite signals is needed to determine current GPS position. Signal reception can be affected by situations such as bad weather or dense overhead obstacles (e.g. trees and tall buildings)

The wireless devices might interfere the reception of satellite signals and cause the reception of the signal to be unstable. For better signal reception, it is recommended that you use a car antenna (option)

Aircraft and Hospitals

Use of devices with an antenna is prohibited on most aircraft, in many hospitals and in many other locations. The device must not be used in these environments.

1. Getting Started

1.1 Unpacking

Unpack your device box and identify the contents. You should have:

(1) Unit. Its main features are a touch-sensitive LCD screen, 1 SD card slot, 1 volume control switch. Details see the photo below.

(2) Holder   to hold the device.

(3) Bracket, its main features is to fix the device on a car .

(4) Car Charger. With 12V cigarette lighter adapter. This is the normal way of providing power to your device when it's in your vehicle.

(5) AC adapter (Option), included for you to charge and work with your device even when It's not in your vehicle. When you use the adapter, please make sure it is cooled by placing it in a ventilated area.

(6) USB data cable for connecting your device to a Windows PC

(7) User Manual.

*Note: please check optional accessories with local retailer/importer/distributor.

1.2 Over View

(1) Charger Indicator Light

(2) Power Switch

(3) External GPS Antenna Connector

(4)Speaker

(5)SD Card Slot: for accessing data as maps. Note:

Before using GPS navigation software and maps, you need to insert the storage Card included with your device. Do not remove the card during GPS operation.

(6)Earphone Jack

(7)Reset Key

(8)USB Connector

Do not expose the device to high temperatures. We recommend that you do not leave the device in direct sunlight for long periods or in an unattended car on sunny days.

High temperatures can cause permanent damage.

Do not attempt to service the device yourself! Do not open, puncture or disassemble it.

Doing so may be dangerous and will invalidate your warranty.

1.3 Using Your Device in a Vehicle

A stand and a car charger are supplied with your device.

1.3.1 Using the Car Bracket

Caution:

-- Select an appropriate location for the stand. Never place the stand where the driver's field of vision is blocked.

-- If the car's windshield is tinted with a reflective coating, an external antenna (optional) may be needed to route the roads.

The external antenna is stick to the top of the car through a window. When closing the car window, be careful not to pinch the antenna cable (Cars with an anti-jam window design may automatically leave adequate space as needed.).

1.3.2 Connecting the Car Charger

The car charger supplies power to your device when you are using the device in a car.

Caution: To protect your device against sudden surges in current, connect the car charger only after the car engine has been started. Connect one end of the car charger to the power connector of your device. Connect the other end to the cigarette lighter in the car to power and charge your device.

1.4 Starting up

Insert the supplied SD card (optional) into the slot at the bottom of device.

Tap "OK "then enter into the "Main Function Operation Screen " as below.

Then select the functions you need and then go directly to the way you need.

1.5 Power saving

Press the power button on the top side of your device to turn on and off your device for saving power. When you press the power button to turn off the unit, your device actually enters a suspend state and the system stops operation. Once you turn on the system again, it resumes.

2.Main Menu Selection

Main Menu is the start of all functions. It includes four function icons such as navigation, Media with Mp3,Photo,Ebook and MP4,Bluetoothand system setting .You can choose your desired functions as you like.

2.1 Navigation

Please refer the navigation software user manual for the details.

2.2 Media

　　Tap the icon "Media" on the main menu and enter into following interface.

　　2.2.1 MP3

　　　　1)Tap the icon "Mp3" on the media menu and enter into following interface.

2) Tap your desired file and enter into the following interface.

It supports various player format.If no Mp3 files can be found, it will enter into playing directly.

A: Return to main menu　　E:Return to previous Menu　　I:Speed bar
B:Circle　　　　　　　　　F:Next　　　　　　　　　　J: Pause/play
C:Auto play　　　　　　　 G:Previous
D:Volume control　　　　　H:Stop

3 Tap " ✖ " return to main menu.

2.2.2 Photo

1) Tap " Photo" on the media menu and enter into the following interface.

2) Tap the file on the screen and enter into the following interface.

A: previous

B: next

C: return to previous menu

D: current picture name

E: Zoom out

F: Zoom in

G: rotate

H: full screen

3) Tap " ⚒ " and return to main menu.

Tips:

Tap FULL SCREEN button, it will display in full screen size

Tap PREVIOUS or NEXT button to view the pictures. If picture is too big or the device does not support the format, it will be dark screen or can not read.

2.2.3 Ebook

1) Tap " Ebook" on the media menu and enter into the following interface.

2) Tap the file on the picture and enter into the following interface.

A: Return to main menu
B: Previous
C: Next
D: Return to previous menu
E: Pages chose
F: Current page/total pages
G: Current file name

3)　Tap " ✖ " and return to main menu.

2.2.4 MP4

1) Tap the icon "Mp4" on the main menu and enter the following interface.

2) Tap the file and enter into the following interface.

It supports various player format, please refer to DOWNLOAD AND UPDATE.

A: Return to main menu

B: Pause/play

C: Stop

E: Volume control

F: Full screen

G: Return to previous menu

H: Speed bar

3) Tap " " and return to main menu.

Tips:

Tap NEXT button to recircle the movie.

Tap full screen button or double press the screen, it will play in full screen.

When playing in full screen, double press the screen again, it will return to original playing size.

2.3 Bluetooth

Tap the icon "Bluetooth" on the main menu and enter into the following interface.

And tap " ✕ " and return to main menu.

2.3.1　Phone keypad

1) Tap the icon [icon] on the bluetooth menu and enter into the following interface.

A   Return to the bluetooth menu

B   Backspace

C   Pair and connect with the mobile you want

D   Call Record

2) Tap " ⌗ " and return to the bluetooth menu.

2.3.2   Call Record

1) Tap the icon [ ] on the bluetooth menu and enter into the following interface.

A   Return to the bluetooth menu

B   Previous

C   Next

D   Connect with the mobile you want

E   Delete all the call record

F   Delete the record number you chose

G   Hang up the number you dial

H   Incoming call record

I   Outgoing call record

2)   Tap " ⌗ " and return to the bluetooth menu.

2.3.3   Pair

Tap the icon [icon] or the icon [icon] on the bluetooth menu and enter into the following interface.

2.3.4　　Attribute

1) Tap the icon [icon] on the bluetooth menu and enter into the following interface.


A　PIN　Setting

B　Music Setting

2) Tap PIN Setting button and enter into the following interface.

3) Tap Music Setting button and enter into the following interface.

Then tap the icon you desired and choose the music file as the ring of incoming call.

2.3.5   Pair Devices

1) Tap the icon [icon] on the bluetooth menu and enter into the following interface.

A   Previous

B   Next

C   Delete all the Devices information

D   Disconnect the Devices you chose

E   Connect the Devices you chose

2) Tap " [icon] " and return to the bluetooth menu.

2.4 Setting

Tap the icon "Setting" on the main menu and enter into the following interface.

A: return to main menu

B: volume

C: power

D: backlight

E: date and time

F: language

G: system information

1) Backlight

Tap the icon "Backlight" and enter into the following display.

A. Under Backlight icon, tap "-" to weaken the backlight, and tap "+" to stronger the backlight.

B. Under battery icon, tap < or > button to select the duration of auto power off the backlight.

C. Under AC power icon, tap <or >to select the duration of auto power off the backlight when using AC adaptor.

2) System Info

A. Tap the icon "USB" to set the USB working mode.

B. Tap the icon "Calibration" and enter the adjustment of touch screen.

According to the information on the screen, press the right cross centre. Then take the operation under instruction until the following screen display.


3) Language

A. Tap the icon "Language" and enter into the following display.

B. Tap "<"or ">" icon to select the language or color display.

4) Power

Tap the icon "Power" and enter into following display.


5) Volume

A. Tap the icon "Volume" and enter into volume setting display.

B. Tap"-" or "+" to adjust volume of speaker.

6) Date and Time

A. Tap the icon "Date Time" and enter into the following display.

B. Tap "Date" icon and use "<" or ">" icon to adjust the date.

C. Tap "Time" icon and use "<" or ">" icon to adjust the time.

This document is for guidance only and does not form part of any contract, and may be subject to change without notice.

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

Note: The manufacturer is not responsible for ANY interference, for example RADIO or TV interference, caused by unauthorized modifications to this equipment.

Such modifications could void the user's authority to operate the equipment.