FIGURE 1
UHF RFID HANDY TERMINAL (M/N: C35)
BATTERY REMOVED

FIGURE 2
UHF RFID HANDY TERMINAL (M/N: C35)
BATTERY



FIGURE 3
UHF RFID HANDY TERMINAL (M/N: C35)
TOP COVER REMOVED

FIGURE 4
UHF RFID HANDY TERMINAL (M/N: C35)
COVER REMOVED

FIGURE 5
UHF RFID HANDY TERMINAL (M/N: C35)
LCD PANEL REMOVED

FIGURE 6
UHF RFID HANDY TERMINAL (M/N: C35)
LCD PANEL FRONT

FIGURE 7
UHF RFID HANDY TERMINAL (M/N: C35)
LCD PANEL BACK

FIGURE 8
UHF RFID HANDY TERMINAL (M/N: C35)
LCD PANEL BOARD



FIGURE 9
UHF RFID HANDY TERMINAL (M/N: C35)
BUTTON BOARD (COMPONENT SIDE)



FIGURE 10
UHF RFID HANDY TERMINAL (M/N: C35)
BUTTON BOARD (SOLDERED SIDE)



FIGURE 11
UHF RFID HANDY TERMINAL (M/N: C35)
MAIN BOARD REMOVED

FIGURE 12
UHF RFID HANDY TERMINAL (M/N: C35)
MAIN BOARD (COMPONENT SIDE)



FIGURE 13
UHF RFID HANDY TERMINAL (M/N: C35)
MAIN BOARD BACK GENERAL



FIGURE 14
UHF RFID HANDY TERMINAL (M/N: C35)
MAIN BOARD (SOLDERED SIDE)



FIGURE 15
UHF RFID HANDY TERMINAL (M/N: C35)
CHIP ON MAIN BOARD#1

FIGURE 16
UHF RFID HANDY TERMINAL (M/N: C35)
CHIP & CRYSTAL ON MAIN BOARD#2



FIGURE 17
UHF RFID HANDY TERMINAL (M/N: C35)
CHIP & CRYSTAL ON MAIN BOARD#3



FIGURE 18
UHF RFID HANDY TERMINAL (M/N: C35)
CRYSTAL ON MAIN BOARD#4



FIGURE 19
UHF RFID HANDY TERMINAL (M/N: C35)
CRYSTAL ON MAIN BOARD#5



FIGURE 20
UHF RFID HANDY TERMINAL (M/N: C35)
CHIP ON MAIN BOARD#6

FIGURE 21
UHF RFID HANDY TERMINAL (M/N: C35)
RF MODULE GENERAL FRONT

FIGURE 22
UHF RFID HANDY TERMINAL (M/N: C35)
RF MODULE SHIELDED SHELL REMOVED



FIGURE 23
UHF RFID HANDY TERMINAL (M/N: C35)
RF MODULE (COMPONENT SIDE)



FIGURE 24
UHF RFID HANDY TERMINAL (M/N: C35)
RF MODULE (SOLDERED SIDE)



FIGURE 25
UHF RFID HANDY TERMINAL (M/N: C35)
CHIP & CRYSTAL ON RF MODULE#1

FIGURE 26
UHF RFID HANDY TERMINAL (M/N: C35)
CHIP & CRYSTAL ON RF MODULE#2



FIGURE 27
UHF RFID HANDY TERMINAL (M/N: C35)
CRYSTAL ON RF MODULE#3



FIGURE 28
UHF RFID HANDY TERMINAL (M/N: C35)
BACK SHIELDED SHELL REMOVED



FIGURE 29
UHF RFID HANDY TERMINAL (M/N: C35)
ANTENNA FRONT



FIGURE 30
UHF RFID HANDY TERMINAL (M/N: C35)
ANTENNA BACK



FIGURE 31
UHF RFID HANDY TERMINAL (M/N: C35)
SPEAKER FRONT



FIGURE 32
UHF RFID HANDY TERMINAL (M/N: C35)
SPEAKER BACK



FIGURE 33
UHF RFID HANDY TERMINAL (M/N: C35)
TRIGGER BOARD (COMPONENT SIDE)



FIGURE 34
UHF RFID HANDY TERMINAL (M/N: C35)
TRIGGER BOARD (SOLDERED SIDE)