THUNDERTUMBLER™
RADIO CONTROL 360° RALLY CAR
STUNTS, WHEELIES & FLASHING LIGHTS!
PERFORM 360° SINGLE-TIRE WHEELIES!
MULTI-DIRECTIONAL OPERATION
■ Perform Stunts and Wheelies and has Flashing Lights
■ Full-Function Radio Control with Special Action Button
■ Rear Wheels Illuminate With Colorful LED Lights
■ Available In Two Frequencies for Racing Against Each Other
BOX CONTAINS THE FOLLOWING FREQUENCY
27 MHz
49 MHz
AVAILABLE IN TWO FREQUENCIES FOR COMPETITIVE RACING!
BATTERY OPERATED PLAY VEHICLE
AGES 6 AND UP
WARNING!
CHOKING HAZARD - Small parts. Not suitable for children under 3 years.
AGES 6+
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
☐ Reorient or relocate the receiving antenna.
☐ Increase the separation between the equipment and receiver.
☐ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
☐ Consult the dealer or an experienced radio/TV technician for help.
■ Spinning Stunt Vehicle with Colorful Flashing LED Lights
■ Full-Function Wireless Radio Control
■ Available In 2 Frequencies For Racing Against Each Other
Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
OPERATING INSTRUCTIONS
KEEP THIS PACKAGE FOR REFERENCE AS IT CONTAINS IMPORTANT INFORMATION.
REMOTE CONTROL ASSEMBLY
BATTERY DIAGRAM
Operation requires 4 "AA" 1.5V alkaline batteries (not included) for the remote control and 3 "AA" batteries for the spinning control.
1. Carefully remove items from package.
2. Locate the battery compartment on the back of the remote control and open the door.
3. Select batteries on bottom of car to release battery pack and open battery door.
4. Switch both car and remote buttons to "ON" position.
5. Now you are ready! Place the car on a hard surface and use the remote to drive.
FOR BEST PERFORMANCE
GENERAL CONTROLS
Reverse: Press both control sticks forward.
Forward: Press both control sticks backward.
Spinning Action: Press and hold the control sticks in opposite directions.
Action Buttons: Press and hold the action button to have fun at the same time as the spinning function.
SPINNING ON REAR WHEEL (ACTION BUTTON)
1) Spin the car by pressing and holding the control sticks in opposite directions.
2) Press and hold the action button while the car is spinning.
SAFETY PRECAUTIONS
• Do not use batteries of different types or mix old and new batteries.
• Avoid water, sand and snow when operating car.
• Never operate your car in the street or highway.
• Never operate your car in the vicinity of people, animals or valuable objects.
• Do not operate your car in the vicinity of any kind of electrical equipment or equipment that is sensitive to electromagnetic radiation.
• Do not operate your car in the vicinity of people who are in a wheelchair or equipment of a medical nature