Dare to Be

ozakiverse.com

Quick Start Guide

O!music™ Powow+

WELCOME

O!, you and your O!music powow were made better for each other.

O!music powow lets you enjoy the music, games and movies everywhere.

Just Plug the O!music powow on the Smart backcover and play the perfect sounds.

CONNECT TO O!music powow

BLUETOOTH®
(wireless audio)

OR

3.5mm STEREO
(wired audio)

CHARGE

USB

CONTENTS

OVERVIEW ------------------------------------04
Step 1 - POWER UP ---------------------------09
Step 2 - CONNECT ---------------------------10
Step 3 - LISTEN -------------------------------15
Step 4 - CONTROL ---------------------------17
PLACEMENT ----------------------------------19
TROUBLESHOOTING -------------------------20
SPECIFICATIONS -----------------------------21
SAFETY INSTRUCTION -----------------------22
WARRANTY INFORMATION ------------------23

OVERVIEW

Package Contents



O!music powow Bluetooth® speaker



Smart backcover

Micro-USB charging cable

3.5mm stereo cable



Carrying bag

Quick S
tart Guide

Quick Start Guide

O!music powow Bluetooth® speaker button function & LED signal



LED SIGNAL
Power Status LED that can change to blue or red
LED: BLUE




Standby : Flash blue for one second (O!music powow goes to standby automatically after 5minutes if not use)


Fully Charge: Glow solid blue after the battery is fully charge

LED: RED





Bluetooth® Status LED






Playback : Flash blue for 1.5 seconds after every 1.5 seconds



Smart backcover

Front



Back



Step 1 - POWER UP

1 CHARGE

Plug O!music powow Bluetooth® speaker into the wall charger or computer via Micro-USB cable
(wall charger not included)



NOTE: Please fully charge your O!music powow Bluetooth® speaker before first time use.It takes around 4 hours to charge O!music powow Bluetooth® speaker fully.
When Battery is low The status led flashes red for 1 second,
When battery is below 20%, you will hear the sound alert (three short DIs) every 30 seconds until automatic power off.
When Battery is FullThe status led glows solid blue after the battery is fully charge

2 POWER ON



Turn ON the Power(3S for startup)

Step 2 - CONNECT

Option A: Connect to O!music powow Bluetooth® speaker wireless via Bluetooth®



1 Prepare your O!music powow Bluetooth® speaker for pairing



Press the pairing BUTTON for 2 seconds, you will hear 2 short beeps



The Bluetooth® Status LED keeps flashing rapidly

2 Turn on the Bluetooth® on your iOS device



Press Settings



Press General -> Press Bluetooth



Turn ON the Bluetooth®



When "O!music by OZAKI" appears, click it.

Connected!
Congratulations, you have successfully connected your O!music powow Bluetooth® speaker with your iOS device.
Your can start ENJOYING your music, game and movie everywhere.



Connected


Bluetooth® Status LED glows solid blue

Option B: Connect to O!music powow Bluetooth® speaker wire via 3.5mm stereo cable

Don't want connect the Bluetooth®! Don't worry!
You can also connect to O!music powow Bluetooth® speaker wire via 3.5mm stereo cable.



Connect to O!music powow Bluetooth® speaker wire via 3.5mm stereo cable

Step 3 - PLAY & LISTEN

Connected wirelessly via Bluetooth®

1 Turn the volume fully up on your iOS device
2 Use the " + " and " - " Buttons to adjust the volume on your O!music powow



Play Music and Listen the BEST SOUND from O!music powow via Bluetooth®



Watch MOVIE and Listen the BEST SOUND from O!music powow via Bluetooth®

Play Racing Game and Listen the BEST SOUND from O!music powow via Bluetooth®

Connect via 3.5mm stereo cable

1 Turn the volume of your iOS device down
2 Use the " + " and " - " Buttons to adjust the volume on your O!music powow

Play Music and Listen the BEST SOUND from O!music powow via 3.5mm stereo cable

Step 4 - CONTROL

Power on/off switch



Pairing Button



Volume Control: " +", " -" Button



When the volume is Max., your will hear a short beep

When the volume is Min., your will hear a short beep.

Charge: Micro-USB for charge



wall charger via Micro-USB cable



computer via Micro-USB cable

PLACEMENT

You can attached the Smart Backcover from different viewing angles.
Separate the Smart Stand on various places.

1 Hand hold



2 different viewing angles



3 Stand



4 Separate



5 avoid vibrate



TROUBLESHOOTING

Q: The Speaker stops responding and Power Status LED flashes red for 1 second
A: Battery is low and must be recharged.

Q: Power switch is ON but the Power Status LED is off.
A: Battery is empty. Connect Micro-USB cable to a wall charger and fully recharge the speaker.

Q: Unable to pair with Bluetooth
A: 1 Make sure your iPad, iPhone or iPod touch is turning on the Bluetooth
2 Follow Connect to O!music powow wireless via Bluetooth® instruction in this guide (page ?)

Q: Signal loss or dropouts via Bluetooth
A: 1 Move O!music powow closer to your iPad, iPhone or iPod touch. Its will reconnect via Bluetooth automatic.
2 If Not, Press the Pairing Button 1 second then reconnect.

Q: The Power Status LED is ON but there is no sound.
A: If connected via Bluetooth, try turn OFF the speaker and turn ON again.
If connected via 3.5mm cable, check the 3.5mm stereo cable is firmly connected to your iPad, iPhone or iPod touch.

Q: The Speaker doesn't recharge.
A: Check the Micro-USB cable is firmly connected and that the wall charger or USB port of PC is not faulty.

SPECIFICATIONS

Size and Weight

O!music powow Bluetooth® speaker
- Height: 215 mm
- Width: 65 mm
- Depth: 35 mm
- Weight: 310 g

Smart iPad 2 backcover
- Height: 245 mm
- Width: 190 mm
- Depth: 12 mm
- Weight: 100 g

Connections:
Wireless (Bluetooth)
Wire (3.5mm stereo input)
Charge (Micro-USB cable for charging only)

Bluetooth:
Bluetooth 2.1 + EDR technology
Support Advanced Audio Distribution Profile (A2DP) 1.2
Wireless Range: At least 33 feet(10M)

Audio
AMP Output Power: 2W x 2
Driver Output Power: 3W x 2
Driver Unit: 2" x 2
Full-range Frequency Response: 80Hz ~ 20 KHz
Input Impedance: ≥4.7K ohm
Input Sensitivity : 1000mV Dimension: W112xH112xD112mm

Power and Battery:
Power Source request: DC 5V, 1000mA wall charger via Micro-USB cable(wall charger not included)
Fully Charge: About 4Hours

Power and Battery:
Power Source request: DC 5V, 1000mA wall charger via Micro-USB cable(wall charger not included)
Built-in rechargeable 2300mAh lithium-polymer battery
Battery Life: About 8Hours of continuous play
(varies by volume level and audio content)
Fully Charge: About 4Hours

FCC Compliance Statement:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
NOTE: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful

interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.
FCC RF warning statement: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

RTTE Statement:
Hereby, OZAKI WORLDWIDE LTD., declares that this O!music powow, Model:OM950 /OM955 is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.