AUSDOM®

V3.0

使用说明书
User Manual



Hola87

无线机械键盘
Wireless Mechanical Keyboard

1. Product Overview



2. Wired Connection Mode

1) Plug the USB-C Cable to the keyboard's USB-C port and the computer's USB-A port, It can support the wired connection function and also can charge the keyboard.



2) Turn the power switch to "**ON**", Press "**Fn+5%**" once to switch wired connection mode.

3. 2.4G Mode Connection



Model: HOLA87 USB
Power Supply: DC 5V by PC
FCC ID: Z63-HOLA87USB

1) Remove the USB receiver and insert it into your computer's USB port.

2) Press "**Fn+4$**" once to switch to 2.4G mode, then it can plug and play.

4. Bt Wireless Mode Connection



1) Turn the power switch to "**ON**".



2) Press and hold "**Fn+1** or **2** or **3**" for 3 seconds, then the keyboard turns to "pairing" mode and the key's backlit indicator flashes rapidly.

3) Turn on the device's "**Bluetooth**" function, search and select "**Hola87**" for pairing.

Note: The system can ot support the BT wireless connection below windows7.

5. Mode And System Switching

Windows:

Mac:

1)System switching:
Press "**FN+W**" once to switch to Windows system;
Press "**FN+A**" once to switch to Mac OS system.



2) Mode switching: Press "**FN+1/2/3/4/5**" to switch to different modes channels.

6. Keyboard Indiactor

Category/Lamps	Status/Operation	light display
RGB Flowing Light	Press "FN+Right ALT" once to switch the flow light effect	Switching streamer light effect changes
Keys RGB Backlit	Press "FN+W" once to switch Windows system	Blinking blue light 3 times and then returning to restore the original state
	Press "FN+A" once to switch Mac system	Blinking yellow light for 3 times and then returning to the original state
	Press "FN+INS" once to switch Keys RGB Backlit effect.	Change the effect of different lights under the switch axis
RGB Side Light	Press"FN+Menu key" once to switch light effect	Switch side lights to change the effect of different lights
Keys RGB Backlit	Wired Charging Status	Charge from left to right light effect prompts, full or stop charging will restore RGB light effect.
	Low battery	Flashing red
CAPS Lock indicator	Turn on Caps	CAPS key stay white status

7. Keys Function

Keycap Characters	System Function	Keycap Characters	System Function
F1	• **Mac OS:** Screen brightness - (Default) • **Windows:** FN+F1:Screen brightness - (Default)	F2	• **Mac OS:** Screen brightness +(Default) • **Windows:** FN+F2:Screen brightness + (Default)
F3	• **Mac os:** Multi-Windows display (Default) • **Windows:** FN+F3: Open calculator	F4	• **Mac os:** Open Launchpad (Default) • **Windows:** FN+F4:Open My Computer
F5	• **Windows:** FN+F5:Open Multimedia Player	F6	• **Windows:** FN+F6: Previous Track
F7	• **Mac os:** Previous Track (Default) • **Windows:** FN +F7: Next Track (Default)	F8	• **Mac os:** Play/Pause (Default) • **Windows:** FN+F8:Play/ Pause (Default)
F9	• **Mac os:** Next Track (Default) • **Windows:** FN+F9: Stop playback control	F10	• **Mac os:** Mute (Default) • **Windows:** FN+F10: Mute
F11	• **Mac os:** Volume - (Default) • **Windows:** FN+ F11: Volume-	F12	• **Mac os:** Volume + (Default) • **Windows:** FN+ F12: Volume +
1!	• **FN+1:** • Press once,Switch to BT1 • Press and hold for 3s, turn to BT1 repairing status	2@	• **FN+2:** • Press Tonce, Switch to BT2 • Press and hold for 3s, turn to BT2 repairing status
3#	• **FN+3:** • Press once, Switch to BT3 • Press and hold for 3s, turn to BT3 repairing status	4$	• **FN+4:** • Press once, Switch to 2.4G mode • Press and hold for 2-3s, turn to 2.4G repairing status

5%	• **FN+5:** • Press once Switch to wired mode	6^	• **FN+Esc:** • Press and hold for 3 seconds to reset to settings
7&	• **FN+INS:** • Press once to switch the keys RGB backlit effect	8*	• **FN+Menu Key:** • Press once to switch the left and right side lights
9(	• **FN+Del:** • Press once to switch the color of keys RGB backlit	0)	• **FN+ 0 :** • Press once to increase the brightness of the keys RGB backlit
↓	• **FN+ ↓ :** • Press once to decrease the brightness of the keys RGB backlit	←	• **FN+ ←:** • Press once, cut down the backlit running speed
→	• **FN+ → :** • Press once, Pick up the backlit running speed	A	• **FN+ALT:** • Press once to Switch Right/Left side light effect
W	• **FN+W:** • Press once to switch to Windows system	A	• **FN+A:** • Press once to switch to Mac OS system
⟵	• **FN+Backspace:** • Press once to turn on/off the keys RGB backlit		

8. Packing list

1* AUSDOM Hola87
1* USB-C Cable
1* User Manual
1* Switch and Keycaps Puller
1* Keyboard dust cover
1* Quick Guide
2* Mechanical axis

9. Charging

Charge from left to right light effect prompts, full or stop charging will restore RGB light effect, low state red flashing prompts.

Low battery indicator: the light flashes red until powering off.



10. Specifications

Wireless Pairing Name	Hola87
Wireless Version	BT 5.0
US Layout	87(80%TKL)
Keyboard Switch	Mechanical axis
Battery Capacity	5000mAh-10000mAh
Battery Type	Lithium Ion Battery
Charge input	DC5V/500mA
System Compatibility	Win7/8/10/11 / Mac10.10 above

Note: Functional and technical specifications are subject to change without notice, and we apologize for any inconvenience this may cause you.

11. Warranty

This keyboard supports 1 year quality warranty, for more information please visit **www.ausdom.com**.

12. Safety Instructions

⚠ Warning: Fire, electric shock, damage to keyboard device could occur if the following instructions are not obeyed
Danger (high risk) ⚠ Warning (Moderate risk) ✗ Note (Poor risk).

✗ 1. Away from edge tool
✗ 2. Away from microwave radiation source
✗ 3. Do not place heavy objects on this product
✗ 4. No shocking and bending
⚠ 5. Away from oil, chemical, or organic solvents

⚠

CAUTION:
RISK OF EXPLOSION IF BATTERY IS REPLACED
BY AN INCORRECT TYPE
DISPOSE OF USED BATTERIES ACCORDING
TO THE INSTRUCTIONS

RECYCLING
This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European directive 2012/19/EU in order to be recycled or dismantled to minimize its impact on the environment.
User has the choice to give his product to a competent recycling organization or to the retailer when he buys a new electrical or electronic equipment.

DC voltage

FCC ID: Z63-HOLA87
FCC ID: Z63-HOLA87USB

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference.
(2) This device must accept any interference received, including interference that may cause undesired operation.
Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver isconnected.
-Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

WARRANTY CARD

ATTENTIONS:

-Please read the return procedures and warranty policy carefully on www.ausdom.com
before sending items back to point-of-purchase.
-Please fill the card and send it to your reseller together with the product if your product's warranty is valid.

S.N:	
Date of Purchase:	
Product Model:	
RMA Number:	
Return Reason:	
Customer Name:	
TEL:	
E-mail:	
Address:	