IB-200-X0003P-00　　说明书X3 Pro英法西德意葡日等26国语言/出口V1.0
页面数及装订方式：XX面XX页，风琴折再从中间对折
尺寸：85x170mm、成型尺寸：85x85mm
工艺：四色印刷
材质：80g书纸

保 密
Confidential

封面 —
对折线
封底 —

EDIFIER

X3 Pro

Model: EDF200182
True Wireless Earbuds with Active Noise Cancellation

— Manual —

BC

For more information, please visit our website:

www.edifier.com

Edifier International Limited
PO Box 6284
General Post Office
Hong Kong

www.edifier.com
©2024 Edifier International Limited. All rights reserved.
Printed in China

NOTICE:
For the need of technical improvement and system upgrade, specifications and instructions shown in this manual may be subject to change from time to time without prior notice.

Products of EDIFIER will be customized for different applications. Pictures and illustrations shown on this manual may be slightly different from actual product.
If any difference is found, the actual product prevails.

IB-200-X0003P-00 V1.0

@EdifierGlobal　@EdifierGlobal　@EdifierGlobal

WHAT'S IN THE BOX　1

x1　x1

x1　x1　x2

APP　2

Scan and download
EDIFIER ConneX App

Download on the App Store　GET IT ON Google Play

POWER ON/OFF　3

1s

Take out or place in both earbuds to power on/off.

FIRST PAIRING　4

1. Once powered on, the earbuds will auto-enter Bluetooth pairing.
2. Select "EDIFIER X3 Pro" from your device list to connect.

MULTIPOINT CONNECTION　5

1. While the earbuds are paired, disconnecting them from deivce A will auto-enter Bluetooth pairing mode.
2. Go to device B settings and select "EDIFIER X3 Pro" from the product list to connect.
3. Select "EDIFIER X3 Pro" from the list on device A to reconnect.
Note: For subsequent use, the earbuds will automatically reconnect to the two devices used last time.

PAIRING FOR NEW DEVICE　6

1. Once powered on, the earbuds automatically reconnect to the last device used.
2. If the connection fails, the earbuds enter Bluetooth pairing mode in 10 seconds.
3. If manually disconnected, the earbuds enter pairing mode immediately.
4. Select "EDIFIER X3 Pro" from new device's list to connect.

RESET　7

1. Take the earbuds out of the case.
2. Quickly tap both touch areas 5 times to finish factory reset in 8 seconds.

CONTROLS　8

Note:
1. Default sound control: Noise cancellation on
2. "x2" double tap;　"x3" triple tap

CHARGING　9

Input: 5V=200mA (Earbuds)　　5V=1A (Charging Case)
Note: Make sure the USB port is completely dry before charging.