说明书NeoBuds Pro 3 英法西德意葡日等27国语言/出口V1.0
页面数及装订方式:36面18页,风琴折再从中间对折
成型尺寸:90x90mm
工艺:四色印刷
材质:80g书纸

保 密
Confidential

封面 —

对折线

封底 —

EDIFIER

NeoBuds Pro 3
Model: EDF00196
True Wireless Noise Cancelling Earbuds

— Manual —

BC

For more information, please visit our website:

www.edifier.com

EDIFIER International Limited
PO Box 2094
Kowloon Post Office
Hong Kong

www.edifiercare.com
© 2024 EDIFIER International Limited. All rights reserved.
Printed in China

NOTICE:
For the need of technical improvement any system upgrade, information contained herein may be subject to change from time to time without prior notice.
Please visit our website for the latest version of this manual.
Pictures and illustrations shown on this manual may be slightly different from actual product, if any difference is found, the actual product prevails.

@EDIFIER @EDIFIER_Official @EDIFIER_Official

XX-XXX-XXXXXXXX-01 V1.0

1 WHAT'S IN THE BOX

(XS/S/M/L/XL/XXL)

2 APP

Scan and download EDIFIER ConneX App

EDIFIER ConneX

Download on the App Store | Google Play

3 POWER ON/OFF

Indicator light

Open or close the case to power on/off.

4 FIRST PAIRING

Indicator light

EDIFIER NeoBuds Pro 3

1. Once power on, the earbuds will automatically enterBluetooth pairing mode. LEDs will be lit one by one from left to right in a circulating pattern.
2. Select "EDIFIER NeoBuds Pro 3" in your device setting to connect.

5 PAIRING FOR NEW DEVICE

Indicator light

EDIFIER NeoBuds Pro 3

1. Place the earbuds in the case and keep it open.
2. Press the button on the caseFor 3s, LEDs will be lit one by one from left to right in a circulating pattern.
3. Select "EDIFIER NeoBuds Pro 3" in your device setting to connect.

Note: For subsequent use, the earbuds will automatically connect to the device used last time

6 RESET

1. Place the earbuds in the case and keep it open.
2. Press the button on the case 3 times, the LED will blink until the reset is complete.

Note: This operation will clear pairing records, reconnect left&right earbuds and restore factory setting.

6 MULTIPOINT CONNECTION

A

B

A

1. Pair device A with the earbuds manually and keep the earbuds in the case;
2. Re-enter Bluetooth pairing and select "EDIFIER NeoBuds Pro 3" in device B setting to connect.
3. Select "EDIFIER NeoBuds Pro 3" again in device A setting to complete the multipoint connection.

7 CONTROLS

Call

Music

Mode

Note:
1. "x1" Press; "x2" double press; "x3" triple press; "-" press and hold.
2. Default sound control: High Noise Cancellation / Ambient Sound / Noise Cancellation Off.
3. Download EDIFIER ConneX App for more customizable control settings.

8 CHARGING

Use the included USB-C cable to connect to a power source for charging
Input: 5V⎓200mA(Earbuds) 5V⎓1A(Charging Case)
Note: Make sure the eabuds and USB-C port is completely dry before charging.

9