

OY22E

SMART WATCH
User Manual

1 Enter pairing mode
The watch automatically turns on while charging.
Press and hold the button on the side to power on.

2 Get the Fastrack Reflex World app
Scan the QR code or search "HaloFit" in the App Store/Google Playstore to download.

3 Set up and pair
Make sure your phone's bluetooth is on.
Please download and install the "HaloFit" APP to bind your device and use more services.
Please scan the QR code on the right or the QR code on the watch screen.
Download and install the "HaloFit" APP.
Open the "HaloFit" APP and follow the instructions on the screen.
When adding a device, a pop-up box about whether to accept the binding will pop up on the watch side, click "i" to complete the binding with the APP.

4 Button actions
Short press
Wake the watch screen
Return to the previous screen in an app
Enter the app list
Pause or resume workout
Press and hold
Power on, off or restart
Press for 10 seconds to force restart

5 On home screen
Press and hold to change the watch face
Swipe down to enter shortcut menu
Swipe up to view messages
Swipe left to see Switch card
Swipe right to music control

6 Charger
Please connect charging cable to the watch as follows
Use a regular USB charger with output voltage of 5.0V and output current of 300mA or above to connect your charging cable to a power outlet or charging device
The charger

7 Changing the wristband
Slide the spring pin and hold it while pulling away from the watch to remove the current wristband. To attach a new band, slide the spring pin across and slot the new band. When both sides of the band are positioned correctly, release the spring pin.

8 FAQ		
Issue description	Possible cause	Solution
Incorrect step count	Abnormal wagging or vibration of device	Wear the watch properly to avoid abnormal vibration
	Walked less than 15 steps	Walk more than 15 steps continuously
	Sliding or walking in slippers	Walk with normal posture/ wear something other than slippers
No display	Low battery	Connect to charger to charge the watch
Watch failed to sync data to the App	The connected phone's Bluetooth is off	Turn on the connected phone's Bluetooth
	App is shut down or has crashed	Restart the "Fastrack Reflex World" App
	Out of Bluetooth signal range	Make sure your watch is in close proximity to the connected phone

9 Specifications	10 Features	11 Regulatory information	12 Warning	13 Certification	14 Batteries warning																				
<table border="1"> <tr> <td>Product Name</td><td>OY22E</td></tr> <tr> <td>Product Model</td><td>OY22E</td></tr> <tr> <td>Bluetooth Name</td><td>OY22E_XXXX</td></tr> <tr> <td>Storage Environment</td><td>Temperature: -20°C to 60°C RelativeHumidity: ≤90%RH</td></tr> <tr> <td>Working Temperature</td><td>0°C to 45°C</td></tr> <tr> <td>Frequency Range</td><td>2402MHz-2480MHz</td></tr> <tr> <td>Bluetooth Transmitting Power</td><td>< 8 dBm</td></tr> <tr> <td>Battery Capacity</td><td>300mAh</td></tr> <tr> <td>Waterproof Rating</td><td>IP68 (1.5 meters)</td></tr> <tr> <td>Charging Duration</td><td>About 2 hours</td></tr> </table>	Product Name	OY22E	Product Model	OY22E	Bluetooth Name	OY22E_XXXX	Storage Environment	Temperature: -20°C to 60°C RelativeHumidity: ≤90%RH	Working Temperature	0°C to 45°C	Frequency Range	2402MHz-2480MHz	Bluetooth Transmitting Power	< 8 dBm	Battery Capacity	300mAh	Waterproof Rating	IP68 (1.5 meters)	Charging Duration	About 2 hours	<ul style="list-style-type: none"> Bluetooth BLE5.3 Full-screen touch 1.83" TFT 240*284 pixel Bluetooth call Daily Tracking: Active/ Steps / Calories SpO2 Blood Oxygen monitoring Breathing training Sleep monitoring report Call notification Find your phone Music control Camera control Automatic recognition of motion Pressure test Female physical health 	<ul style="list-style-type: none"> If the screen or shell is damaged, do not use the product. Do not put the product in the dishwasher, washing machine or dryer. Do not expose the product to fire, the battery may explode. While charging, please make sure the charging cable is correctly connected to the watch and charger, and that the charger is properly connected to the power outlet. If the temperature of the product rises sharply during charging, please stop charging and contact our support team for assistance. Some users may experience skin irritation due to wearing the product for too long. If you experience redness, swelling, itching, or other negative physical side effects, please consult your doctor. Do not open the shell of the watch. Do not replace the built-in battery by yourself. Do not use corrosive cleaner to clean the product. Do not charge when the product is wet. If the product is not completely dry, do not charge. Do not expose the product to extended periods of direct sunlight. Do not use the product in a sauna or steam room. Do not expose the product to extremely high or low temperatures. 	<ul style="list-style-type: none"> If the screen or shell is damaged, do not use the product. Do not put the product in the dishwasher, washing machine or dryer. Do not expose the product to fire, the battery may explode. While charging, please make sure the charging cable is correctly connected to the watch and charger, and that the charger is properly connected to the power outlet. If the temperature of the product rises sharply during charging, please stop charging and contact our support team for assistance. Some users may experience skin irritation due to wearing the product for too long. If you experience redness, swelling, itching, or other negative physical side effects, please consult your doctor. Do not open the shell of the watch. Do not replace the built-in battery by yourself. Do not use corrosive cleaner to clean the product. Do not charge when the product is wet. If the product is not completely dry, do not charge. Do not expose the product to extended periods of direct sunlight. Do not use the product in a sauna or steam room. Do not expose the product to extremely high or low temperatures. 	<p>FCC statement</p> <p>1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:</p> <ol style="list-style-type: none"> (1) This device won't cause any harmful interference. (2) This device must accept any interference received, including interference that may cause undesired operation. <p>Medical Disclaimer</p> <p>Warning: This Smart Watch OY22E_XXXX is not a medical device. The Smart Watch OY22E_XXXX and its related Apps can't be used to diagnose, treat, or prevent any disease or medical condition. Before performing any exercise, sleep, or nutritional changes, be sure to seek the advice of qualified medical professionals, otherwise serious injury or death may occur.</p> <p>This symbol means that according to local laws and regulations your product and/or its battery shall be disposed of separately from household waste. When this product reaches its end of life, user has the choice to give his product to a competent recycling organization. Proper recycling of your product will protect human health and the environment.</p>	<p>Batteries warning</p> <p>The built-in lithium battery of the product is for indoor use only, it is impacted, exploded or flammable, it may cause a fire or explosion, it may result in explosion or flammable liquid or gas leakage, avoid the battery in a high-temperature environment or being exposed to liquid or gas leakage, avoid the battery in a high-temperature environment or being exposed to strong sunlight avoid explosion. Do not use the battery continuously in case of serious battery explosion. The battery shall be handled according to local regulations and shall not be disposed of household garbage. Don't try to repair, remove or short the battery. Explosions may happen if the battery is replaced by incorrect model. Don't compress or puncture the battery with hard objects. The battery leakage, overheating or break or a fire may occur if the battery is destroyed.</p> <p>Search the FCC number</p> <p>1. Enter into the smart watch 2. Enter into the regulatory information 3. Enter into the user manual 4. Enter into the FCC ID number</p>
Product Name	OY22E																								
Product Model	OY22E																								
Bluetooth Name	OY22E_XXXX																								
Storage Environment	Temperature: -20°C to 60°C RelativeHumidity: ≤90%RH																								
Working Temperature	0°C to 45°C																								
Frequency Range	2402MHz-2480MHz																								
Bluetooth Transmitting Power	< 8 dBm																								
Battery Capacity	300mAh																								
Waterproof Rating	IP68 (1.5 meters)																								
Charging Duration	About 2 hours																								