

中文

## 1.产品结构

## 2. 蓝牙配对

- ### 3.使用方法

- #### 4.操作按钮的位置和操做方法

按键面板在左右各自的前侧,通过按动按键面板可以进行基本的操作。  
注意不是触摸操作,需要轻轻按动按键面板

## 5.操作列表

|                    |                                                                            |
|--------------------|----------------------------------------------------------------------------|
| 配件                 | 左右耳机和/或置于下方耳机时，耳机将自动静音且LED灯熄灭。重新打开，左右耳机灯亮起时，此时可安全使用 ISO 耳机且无需佩戴降噪耳机类型：W902 |
| 电源ON/OFF           | 由合上电源开关或长按3秒钟电源键<br>混合自动关机或长按3秒钟电源键<br>(Power On/Power Off)                |
| 播放/暂停/停止<br>或返回/返回 | 单击任意一边耳机上的播放按钮                                                             |
| 上一首歌曲              | 双击任意一边耳机“>”按钮                                                              |
| 下一首歌曲              | 双击任意一边耳机“<”按钮                                                              |
| 音量增加               | 单击任意一边耳机“+”按钮                                                              |
| 音量减少               | 单击任意一边耳机“-”按钮                                                              |
| 语音助手支持             | 长按任意一边耳机侧按钮2秒后松开                                                           |
| 来电接听               | 长按任意一边耳机正顶部按钮                                                              |

**注意事项:**

请遵守以下注意事项，以避免造成听力损伤或财产损失。长时间使用高音量音乐或设备时，可能会導致听力减弱等负面影响。为了更好地了解您的听力状况，请注意是否曾有过听力损失。根据相关听力学家的说法，嘈杂环境可能会导致听力损失。请随时注意保持适当的音量，提高音量时请逐渐进行，突然加高音量可能会对您的听力造成伤害。

如在使用耳机时出现头晕或耳痛等情况，请减少使用时间或停止使用。如果系统连接中心或购买时的销售店进行咨询。

1. 不要将耳机本体置于过热的环境中以免产生火灾，出现变形或其他故障。

2. 不要使用飞机上的耳机使用本机。无线电话等影响可能会引发故障或造成其他故障。

3. 请不要在驾驶车辆时使用本机。无线电话等影响可能会引起心脏起搏器或其他医疗设备电子设备出现故障。

4. 请不要在指挥的车辆内或其他的场所使用飞机的室内使用本机。请不要在登机口、火警警报器等自动识别系统上使用。无线电话等影响可能会引发故障或造成其他故障。

**警告：**

[illegible]

英文

## 1. Product structure

## 2. Bluetooth pairing

- ### 3. Usage

- #### 4. Position and operation method of operation buttons

The button panels are located on the front sides of the left and right sides, and basic operations can be performed by pressing the button panels.

Note that it is not a touch operation and requires gentle pressing of the button panel.

## 5. Operation List

|                                           |                                                                                                                                                                                                                                                                                                                                                               |
|-------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| pair                                      | The left and right main speakers on the same pairing mode. After pairing the left and right light on the main speaker will blink alternately, and the light on the secondary will go off. After pairing the left and right main speakers, the power OFF can be heard after 10 seconds of no sound. (The power OFF can be heard after 10 seconds of no sound.) |
| Power QUOTE                               | Automatic shutdown on no sound for 10 seconds when using the wireless. Automatic shutdown upon entering the wireless or manual long press of the 5 second button (Power OFF button)                                                                                                                                                                           |
| Music Play/Stop Call answering/hanging up | Click on any headphone button panel                                                                                                                                                                                                                                                                                                                           |
| Previous song                             | Double click on any headphone "+" button                                                                                                                                                                                                                                                                                                                      |
| Next piece of music                       | Double click on any headphone "-" button                                                                                                                                                                                                                                                                                                                      |
| Volume increase                           | Click on any headphone "+" button                                                                                                                                                                                                                                                                                                                             |
| Volume reduction                          | Click on any headphone "-" button                                                                                                                                                                                                                                                                                                                             |
| Summoning/voice Assistant                 | Long press the button panel on the front of the headphones for 2 seconds to release and trigger Siri                                                                                                                                                                                                                                                          |
| Call rejection                            | Long press any headphone front button panel                                                                                                                                                                                                                                                                                                                   |

Notes:

Please follow the following precautions to avoid injury and property damage. Long term use of this product can stimulate the ears and may lead to cognitive effects such as reduced hearing.

- To better protect both ears and hearing, please pay attention to preventing situations where the volume is too high. According to the World Health Organization, prolonged exposure to sound levels connected to the use of headphones can lead to hearing loss. Please keep an appropriate volume all the time. Please gradually increase the volume as sudden increases may damage the ears.
- You experience skin allergies or other symptoms while using this device, please stop using it as soon as possible and consult a doctor.
- Please do not use the device for extended periods of time. Prolonged use of the device may irritate the skin.
- Please do not place the earphone body in the back pocket to avoid compression, deformation, or other malfunctions when traveling.
- Please do not use this device with its functions, as radio waves and other factors may cause accidental operation and accidents.
- Please do not use this device near medical devices, as radio waves and other influences may cause malfunctions in pacemakers and other medical devices.
- Please do not use this device in crowded vehicles or other miscellaneous places, or in the interior of medical facilities.
- Please do not operate under automatic doors, fire alarm devices, or other devices that may be affected by radio waves.
- The use of radio waves and other factors may cause accidental operations and accidents.

**Warning:**

Please pay attention to the following precautions to avoid death or serious injury caused by fire, electric shock, heat, fire, etc. Do not directly touch the charging battery with your hands to prevent liquid leakage. If the leaked liquid accidentally enters the body or causes the possibility of blindness, please do not rub your eyes.

Do not directly touch the battery with your hands, clean the battery with a wet cloth. If the leaked liquid accidentally enters the body or clothing, to avoid possible burns, please wash the body with water immediately.

Wash with water or other USG fluids. If there is inflammation or other damage to the skin, please seek medical treatment promptly. Please use the attached USG fluid C-accessory for charging. Damage, battery leakage, overheating, and other situations may occur due to the use of other USG fluids, resulting in serious injury.

Do not disassemble this machine on your own to avoid malfunctions or electric shock. If you need to replace the rechargeable battery, inspect or repair, please contact the seller in a timely manner.

Put service center or specialized store at the time of purchase. Please do not expose this device to high temperatures or heating equipment, such as near flames, direct sunlight, or other high-temperature environments.

Use, store, and place in high-temperature areas such as the interior of a car.

## FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

### RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.