



7. How to use A-ONE TAB

(4) HD Hair Diagnosis



◆ <Damage> Diagnosis ◆


1) Click 'Damage' .

2) Put camera on hair and take a photo by clicking 'shot' .

** ** Click <Shot> to re-take a photo.

3) Click 'compare' and select similar sample.

4) Click 'OK' and 'Result' to go to result page.





7. How to use A-ONE TAB




(4) HD Hair Diagnosis

◆ <Thickness> Diagnosis ◆

- 1) Click 'Thickness' .
- 2) Put camera on hair and take a photo by clicking 'shot' .
- ** ** Click <Shot> to re-take a photo.
- 3) Drag a hair and check thickness.
- 4) Click 'Result' to go to result page.

 : To widen the hair thickness


 : To narrow the hair thickness



7. How to use A-ONE TAB


(4) HD Hair Diagnosis

◆ Integrated Diagnosis ◆




Diagnose Scalp type/Density/Sebum/Damage /Thickness.

1) Click 'Comprehensive Diagnosis' .



2) Click 'Start' .



* Tip



*** If user did all tests on the first page by clicking each test item, no need to diagnose each test item again after pressing Start button.

*** if you want to re-take a photo, click the test item or 'shot' button at camera screen.

7. How to use A-ONE TAB

(4) HD Hair Diagnosis

◆ Integrated Diagnosis ◆



1) Put camera on scalp and take a photo by clicking 'shot' .

** Click <Shot> to re-take a photo.

2) Click 'compare' and select similar sample.

3) Click 'OK' and 'Next' .

7. How to use A-ONE TAB

(4) HD Hair Diagnosis

◆ Integrated Diagnosis ◆




1) Put camera on scalp and take a photo by clicking 'shot' .

** Click <Shot> to re-take a photo.



NEVER aim the beam in or near anyone's eyes.



the test value will be shown automatically at the bottom of left.



2) Click 'Next' .

*If you want to use sebum tape, please refer to the page 39.

7. How to use A-ONE TAB

(4) HD Hair Diagnosis

◆ Integrated Diagnosis ◆



1) Put camera on scalp and take a photo by clicking 'shot' .

** ** Click <Shot> to re-take a photo.

2) Click 'compare' and select similar sample.

3) Click 'OK' and 'Next' .

7. How to use A-ONE TAB

(4) HD Hair Diagnosis




◆ Integrated Diagnosis ◆

- Hair Density uses the image of scalp type.

1) If you want to re-take a photo,
Put camera on scalp and take a photo
by clicking 'shot' .

2) Click the most empty part and click each hair
to mark.

3) Click 'Next' .






7. How to use A-ONE TAB

(4) HD Hair Diagnosis

◆ Integrated Diagnosis ◆


- 1) Select the most similar type of when you see the scalp at top position.
- 2) Click 'Next' .
- 3) Put camera on hair and take a photo by clicking 'shot' .
** ** Click <Shot> to re-take a photo.
- 4) Click 'compare' and select similar sample.
- 5) Click 'OK' and 'Next' .



7. How to use A-ONE TAB

(4) HD Hair Diagnosis

◆ Integrated Diagnosis ◆



- Hair Thickness uses the image of Hair Damage.

1) If you want to re-take a photo,
Put camera on scalp and take a photo
by clicking 'shot' .

2) Drag a hair and check thickness.

3) Click 'Result' .

<Do you want to save the test result?>

4) Select 'Yes' or 'No'

Move to result page.

7. How to use A-ONE TAB

(4) HD Hair Diagnosis

Result page

Result 1









- Result graph
- intensive skincare zone,

Result 2 :

- Result of each test

Result 3,4,5,6,7,8,9

- Specific description of each result



7. How to use A-ONE TAB

(4) HD Hair Diagnosis




Press <Cart> button to move to purchase page

It Recommends the products according to the test result

Individual diagnosis – recommends the products for selected test item

Comprehensive diagnosis – recommends the products for all test item

**** If user logged on as a guest, <Cart> button is not displayed on result page**




To purchase a product, select a skin or hair / scalp type

Select on a product image and press arrow button

To change the quantity, double-click on the selected product


Enter the quantity and press OK button




7. How to use A-ONE TAB

(4) HD Hair Diagnosis


◆ Cart ◆



To remove a product from the cart, select the product and press <Delete> button



To purchase the selected products, press the checkbox and select <Purchase> button




Check the product, quantity and price and press <Purchase> button

7. How to use A-ONE TAB

(4) HD Hair Diagnosis

◆ Cart ◆



Purchase list				
Product	Price	qty	Date	Type
Dendruff shampoo	125.00	1	2013-05-24	Hair
Dendruff shampoo	375.00	3	2013-05-24	Hair
test	11730.00	51	2013-05-23	Skin

Ok

When selecting <Purchase List>, user can check the purchase history


User can check the purchased product name, price, quantity, date

Products are classified Skin and Hair

7. How to use A-ONE TAB

(4) HD Hair Diagnosis

◆ Record ◆



Test data is recorded per date and time

Select the date and time to see the previous data



Drag a image which you want to edit or see to the window for thumbnail image




Click red-circled icon on the thumbnail image to see the image on full screen


7. How to use A-ONE TAB

(4) HD Hair Diagnosis

◆ Record ◆




- User can magnify / minimize the image by dragging on the image
- Double-click on a image to see the full screen image of the image.



Click red-circled icon and select Edit button

When clicking Edit button, it returns to diagnosis process

User can retake the image or edit the test result by measuring or selecting other sample



When selecting Result button, it moves to the recorded test result on the selected date and time

7. How to use A-ONE TAB


(5) Configuration



◆ Configuration ◆

<Config> - Change the configuration

Click <Config> button to change the configuration



◆ Set Date / Time ◆

Newly set date and time


RTC is equipped in it, so date and time is saved once user changes the date and time



Change the date and time with ^ , v button


7. How to use A-ONE TAB

(5) Configuration



◆ Sensitivity ◆

Adjust the sensitivity of moisture / Elasticity




Adjust the sensitivity by moving button on the bar

** in case clicking default button, sensitivity return to default value(0)


7. How to use A-ONE TAB

(5) Configuration

◆ Logo ◆





Client can change the logo image



To change the logo, click Open button and load the image file in the storage

7. How to use A-ONE TAB

(5) Configuration



◆ WIFI ◆

Connect to another device(PC) at close range with Wifi

Transfer the capture screen and file to the connected device(PC)

There are two way to connect to the device at close range


<Connection through Wireless Line Sharer>

or

<Connection by Ad-Hoc>

7. How to use A-ONE TAB

(5) Configuration




◆ How to set the WIFI ◆

1. <Connection by Ad-Hoc>


Click on the Signal level symbol on the taskbar.

Click <Open Network and sharing center> at the bottom



Click < Set up a new connection or network>

Click <Set up wireless ad hoc (Computer-to-computer) network>



Click <Next> button

7. How to use A-ONE TAB

(5) Configuration

◆ How to use WIFI ◆

1. <Connection by Ad-Hoc>

Click <Next> button

Enter <Network name>

User can set <Security key> if necessary
**** For Security key, at least 8 characters should be entered.**



Enter the default security key
 "123456789a" .

- Select Security type as <WEP>

- Check <Save this network> to save the Ad-Hoc network



- Click <Next> button to move to next step

Click <Close> button
 Network setting is completed



7. How to use A-ONE TAB

(5) Configuration



◆ How to use WIFI ◆

1. Connection by <Ad-Hoc>

Switch ON Wi-Fi

When pop-up window comes up, click Refresh button

Double-click the Ad-Hoc Network ID set on PC

If user specified the security key for Ad-hoc network, keyboard will appear
Enter the security key and click <OK> button

When Connecting to the PC, condition will be changed as below:

Connecting to Wi-Fi -> search IP Address -> Connected -> Start image!!!



When the condition is changed to "Start image!!!" , you can see the screen of the A-One Tab on the PC.

7. How to use A-ONE TAB

(5) Configuration

◆ How to use WIFI ◆

1. Connection by < Ad-Hoc >




Execute Device Discovery

Check if IP address is matched with
Click <Server Start> button

If WI-FI is connected well, you can see
the screen of the A-One Tab on the PC

7. How to use A-ONE TAB

(5) Configuration





◆ How to use WIFI ◆

2. Connection through Wireless Line Sharer

Click on the Signal level symbol on the taskbar and connect to wireless network


Switch ON WI-FI

Execute the Device Discovery and click server start button



7. How to use A-ONE TAB

(5) Configuration




◆ How to use WIFI ◆

2. Connection through Wireless Line Sharer

Find the wireless network on the A-One Tab and double-click on it

*** Enter the security key In case security key for wireless newtwork is specified




3. How to disconnect WI-FI

Click <EXIT> button in Device Discovery

or


Switch off Wi-Fi



7. How to use A-ONE TAB

(5) Configuration

◆ Skin Age ◆



Check <Skin age> to see skin age on the result page
If it is unchecked, skin age will not be displayed


7. How to use A-ONE TAB

(5) Configuration


◆ Product Update ◆



Register or edit products to recommend products to client after diagnosis
Click <Product> button to register or edit the product line



If you click SD button on the right top, product update page for HD will be displayed





Click <Add> or <Edit> to register new product or edit the information of registered products



7. How to use A-ONE TAB

(5) Configuration

◆ Product Update ◆



Click  to load the saved picture of product



Enter product name/ price/ description and click OK button



BOMTECH Electronics Co., Ltd.

2-3F, Yeon-san Bldg., 1547-15,
Seocho 3-dong, Seocho -ku,
Seoul, 137-073, Korea

Global Business Dept.

TEL: 822-523-8295

FAX: 822-523-8297

E-mail: bomtech@bomtech.net

Homepage: www.bomtech.net

Copyright©2001 BOMTECH ELECTRONICS Co., Ltd. All right reserved.