my tab 10.1

model b

USER GUIDE



models: B-110XP912B and B-110XP912W

my tab Mobile Internet Devices were created to maximize the benefits offered by today's software and applications. We encourage you to become familiar with this guide so that you can get the most out of your use. Please retain access to this USER GUIDE for future reference.

my tab Mobile Internet Devices are developed in America by Video Display of America, Inc. Made in China. Video Display of America, Inc. - 930 New Hope Rd., ste. 11-185, Lawrenceville, GA 30045 VDA and **my tab** are trademarks of Video Display of America, Inc. All rights reserved.

Table of Contents

Overview	3
Safety Precautions	4
Main Functions	7
Basic Operation	8
Home Screen	10
Videos & Images	12
Music	14
Settings	16
Connect to PC	17
Pairing with Bluetooth Device	18
Casting	19
Printing	20
USB OTG	22
Device Specifications	23
Common Issues	24

Overview



- 1 Front Camera
- 2 Reset
- 3 Charge Port
- 4 Headphone Jack
- 5 Power
- 6 Volume
- 7 HDMI USB

- 9 Micro SD Card Slot
- 10 Mic
- 11 Volume -
- 12 Recent Places
- 13 Home Screen
- 14 Previous Screen
- 15 Volume +

Included with this Product

- AC Adapter
- USB Cable
- USB OTG Cable
- Quick Start Guide
- Warranty

2

Safety Precautions

Please read these safety instructions before using your device and store them for possible future reference. Always follow these basic safety precautions when using your mobile device. Following these precautions reduces the risk of fire, electric shock, injury, and damage to the product.

- KEEP THIS DEVICE DRY. Do not expose to liquids, rain or moisture. Keep away from dripping or splashing liquids, and any objects containing liquid.
- Keep the device out of direct sunlight and away from heat sources. Always leave a minimum distance of 4 inches all around the unit to ensure sufficient ventilation.
- Keep this device away from open flame sources such as candles and burners.
- The device is intended for use only in a moderate temperature climate.
- Protect the power cord. Route power cords so that they are not likely to be walked on or pinched by items placed on or against them. Pay particular attention to where the cord attaches to the device.
- Use only the AC adapter included with the device. Using any other power adapter voids your warranty.
- Do not remove the cover. There are no user-serviceable parts inside.
- If the charger cord is damaged, have it repaired by the manufacturer, its servicer or a similarly qualified person in order to avoid any hazard.
- The charger is not intended for use by persons (including children) with reduced physical, sensory or mental capacity. Persons who have not read the manual, unless they have received explanations by a person responsible for their safety and supervision should not use this unit.
- Children should be monitored to ensure that they do not play with the charger. The device contains small parts that may present a choking hazard.
- CAUTION: Danger of explosion if battery is incorrectly replaced or not replaced by the same type or equivalent.
- The battery should not be exposed to excessive heat such as direct sunlight, fire or similar elements
- Use caution when using headphones. Loud volumes for prolonged period of time can damage your hearing.

COMPLIANCE WITH FCC REGULATIONS

Attention: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Additional Safety Precautions:

SW ITCH OFF IN RESTRICTED AREAS Turn off the power when the use of the mobile device is not authorized or when it may cause interference or danger, for example; on board an aircraft, near medical equipment, fuel, chemicals or blasting sites.

ROAD SAFETY COMES FIRST Check the current laws and regulations in the area where you drive, regarding the use of mobile devices such as this mobile device.

- Do not hold this mobile device while driving.
- This device emits Radio Frequency (RF) which can affect certain electronic systems in your car, such as the audio-stereo system or security equipment.
- An airbag inflates with great force. Do not store the mobile device or any of its accessories in the area above the bag or in its deployment area.

RADIO FREQUENCY This mobile device conforms to guidelines for exposure to radio frequency. Your mobile device is a radio transmitter and receiver. It was designed to meet the limits recommended by international guidelines on the exposure to radio-waves. These guidelines were developed by an independent scientific organization, the ICNIRP, and include safety margins designed to assure the protection of all, regardless of their age or state of health.

Radio frequency emissions from electronic equipment can interfere with other electronic equipment and can cause malfunctions. Although this mobile device has been designed, tested and manufactured in accordance with the EU regulations on radio frequency emissions, the mobile device's wireless transmitter and electrical circuits can cause interference with other electronic equipment. We recommend that you take the following precautions:

AIRPLANE: Wireless equipment can cause interference in aircraft.

- Turn off the mobile device before boarding a plane
- Do not use on the runway without the crew's permission.

VEHICLES: Telephone radio frequency emissions can affect a motor vehicle's electronic systems. With regards to your vehicle, check with the manufacturer or dealer.

Medical Implants: To avoid any interference with the medical device, manufacturers of medical devices recommend a minimum distance of 6 inches between wireless equipment and a medical implant such as a pacemaker or defibrillator. The following is recommended to people who have such devices:

- •Always keep the wireless device at a distance of over 6 inches from the medical device.
- Do not carry the wireless device in a breast pocket.
- \bullet Hold the wireless device at the ear opposite the medical device
- Turn off the wireless device if there is any suspicion of interference occurring.
- \bullet Follow the instructions provided by the manufacturer of the medical implant.

If you are fitted with a medical implant and have any questions regarding the use of wireless equipment, consult your doctor.