

 Sleepace 享睡 深圳市迈迪加科技有限公司	产品部件	M8701W中英文说明书	日期	变更记录		设计师	审核人
	文件名称	M8701W中英文说明书_V1.0_20210723	2020.04.26	建立		李芳	
	料号	602292112011	2020.04.29	修改文案		李芳	胡德和
			2021.07.23	增加FCC Warning		冯丹	

[CMF说明]

部件	说明书	
颜色	背景底色	白色
	字符图案	黑色
材质	128g铜版纸	
工艺	骑马钉	
表面效果	无	
尺寸	60 *110 mm	页数 32
字体	思源黑体CN	
备注	所有色号以承认样品为准	

Sleep Tracker

User Manual

01 产品介绍

本睡眠监测器，具有睡眠数据实时监测和记录、睡眠报告生成、睡眠异常提醒等功能。产品由主监测垫和扩展监测垫两部分组成，可分为单人版（只有主监测垫）、单人加长版/双人版（带扩展监测垫），用户可根据不同的使用场景进行选择。

电源接口

指示灯

电源键

扩展垫接口

主监测垫

扩展监测垫

01

02 安装指南

第一步：根据床厂家提供或者实际测量的床宽度尺寸，参考安装位置要求选取合适的位置进行安装（各个版本的安装位置请参见图1-3），注意监测垫需固定于离床头50-60cm的位置，且有LOGO的一面朝上。

单人版安装示例(图1)

单人加长版安装示例(图2)

双人版安装示例(图3)

单人加长版安装示例(图4)

双人版安装示例(图5)

02

03 App使用指南

在应用商店搜索“SleepNote”或扫描下方二维码下载安装SleepNote App。
支持的手机系统版本：Android 4.4及以上，iOS 9.0及以上。
按照App提示添加和使用设备。

04 指示灯说明

开机

绿灯长亮

关机

红灯亮起3秒后熄灭

网络中断

红灯闪烁

固件升级

绿灯闪烁

03

05 产品参数

电源	
电源输入	DC 5V 1A
额定功率	5W
蓝牙	
规格	V4.2 BR/EDR+BLE
频率范围	2.4 GHz ~ 2.5 GHz
Wi-Fi	
规格	802.11 b/g/n
频率范围	2.4 GHz ~ 2.5 GHz
工作环境	
工作温度	0°C~40°C
储存温度	-10°C~50°C
湿度环境	5%~90% RH

05

06 重要须知

- 请牢记本产品并非医疗设备或者防止猝死的设备，使用者不应该完全依赖而忽略对被监测者的照顾。对于既有疾患的使用者，家人应不时地亲自检查被监测者的情况。
- 此产品不适用于佩戴心脏起搏器的人群，请牢记！此产品不适用于幼儿、儿童、发育中的青少年的睡眠监测。

06

07 安全事项

- 请勿将产品接触高温设备，请勿和电热毯等设备一起使用。
- 当电源适配器插入电源插座时，不要触碰电源适配器的金属端。
- 如长期使用本产品，请关机并拔下电源适配器。
- 本产品不具备防水功能，请勿使设备进水，否则会损坏设备。

07

08 三包凭证

三包凭证

客户姓名	
电子邮箱	
联系电话	
邮政编码	
联系地址	
维修记录	
送修日期	
故障现象	
受理日期	
维修员签字	

08

09 免责声明

迪加将不承担任何责任。

因用户不接或不严格依照本产品说明书指引使用本产品所造成的一切损失，由用户自己承担，迈迪加将不承担任何损失赔偿责任。

在遵从法律法规的情况下，迈迪加享有对本文档和本产品说明书的最终解释权。迈迪加有权在不事先通知的情况下，对本文档进行更新、修改或终止。本说明内容受著作权法律保护，未经公司书面许可的情况下，严禁以任何形式复制、传播、分发和使用本手册中的任何内容。

本声明于2019年11月1日生效。

09

10 认证信息

认证信息

CMIT ID:2018DP2467

CE RoHS

10

01 Product Introduction

Please read this manual carefully before using the product and keep it properly.
The product has the functions of real-time sleep monitoring, sleep data recording, sleep report, abnormal reminder, etc. The product is composed of a main monitoring pad and an extended monitoring pad. It can be divided into a single bed version (with main monitoring pad only), or a single bed extended version/double bed version (with extended monitoring pad). Users can choose according to different usage scenarios.

Power Port

Indicator light

Power Button

Extended Monitoring Pad Port

Main Monitoring Pad

Extended monitoring pad

15

02 Installation Instruction

Step 1: Acquire the bed width from the bed manufacturer or the actual measurement of the bed width, then refer to the installation location requirements and select the appropriate location for installation (see Figure 1-3 for the installation location of each version), please note that the monitoring pad needs to be fixed at 50 ~ 60cm away from the bed head position, with the LOGO facing up.

Single Bed Version Installation(Figure 1)

Single Bed Extended Version Installation (Figure 2)

Double Bed Version Installation (Figure 3)

16

03 App

Search "SleepNote" in the App Store or Google Play to download and install the SleepNote App. Supported mobile phone system versions: Android 4.4 and above, iOS 9.0 and above. Add and use the devices as the App prompts.

04 Indicator Light

Power On	Green light is on
Power Off	Red light is on and turns off in 3 seconds.
Network Disconnected	Red light is blinking
Firmware Upgrading	Green light is blinking

22

04 Specifications

Power Supply	
Power Input	DC 5V 1A
Rated Power	5W
Bluetooth	
Specification	V4.2 BR/EDR+BLE
Frequency Range	2.4 GHz ~ 2.5 GHz
Wi-Fi	
Specification	802.11 b/g/n
Frequency Range	2.4 GHz ~ 2.5 GHz

23

05 Precautions

Please note, this device is not a medical device and cannot be used to prevent sudden death. This product is not suitable for people who wear pacemakers, please notice! This product is also not suitable for sleep monitoring of toddlers, children, developing teenagers

06 Precautions

- Please keep the product away from high-temperature equipment, and do not use the product when using an electrical blanket.
- Do not touch the metal end of power plug when plugging into power socket.
- Please power the device off if for a long term non-using.
- Do not let the device come in contact with liquids. It is not waterproof.

24

07 Safety Notice

product solely for legitimate purposes and agree to abide by these terms and any other relevant policies or guidelines that may be specified by Medica. You understand and agree that if you do not use this product in accordance with the requirements of this product manual, Medica will not be able to provide you with after-sales service. When using this product, please strictly observe and implement the requirements including but not limited to the instructions, disclaimers, important notices and safety matters. Any personal injury, accident, property or other loss and related legal disputes caused by any violation of this product manual and safety instructions or due to force majeure, and all other adverse events that may cause conflicts of interest shall be borne by the user. Medica will not be responsible for any related liabilities and losses. Due to the user's failure to follow or strictly follow the instructions in this product manual, all losses caused by the use of this product shall be borne by the user. Medica shall not be liable for any losses.

08 warranty

Please contact your dealer for warranty service. For more information about the product, warranty or service, please go to www.sleepace.com

25

09 Disclaimer

To protect your legal rights, please read the instructions, disclaimers, important notices and safety items provided with this product before using this product to understand your legal rights, responsibilities and safety precautions. Otherwise, it may bring you property damage, personal safety hazards or accidents. Shenzhen Medica Technology Development Co., Ltd. (Medica) reserves the right to update this document. Please be sure to operate this product in accordance with the instructions and safety instructions. Once using this product, you are deemed to have understood, approved and accepted all terms and conditions of the product's instructions, disclaimers, important notices and safety matters, and have undertaken to be responsible for your actions and consequences arising therefrom. The user must also undertake to use the

08 Disclaimer

The contents of this manual are protected by copyright laws and regulations. It is strictly forbidden to copy, transmit, distribute and use any of the contents of this manual in any form without the written permission of the company. This disclaimer statement became effective on November 1, 2019.

26

10 FCC Warning:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate

09 Disclaimer

The contents of this manual are protected by copyright laws and regulations. It is strictly forbidden to copy, transmit, distribute and use any of the contents of this manual in any form without the written permission of the company. This disclaimer statement became effective on November 1, 2019.

27

11 radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

10 FCC Warning:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate

28

12

13

14