

UV Sterilizer Box with Wireless Charging manual

Tips:

Please read the instruction manual of this product carefully before use and keep it properly.

Precautions:

1. When turning on the germicidal lamp, do not look directly at the germicidal lamp, otherwise it will cause a slight burn than the eyes.
2. Please place it more than 1M away from the computer and electronic equipment to prevent signal interference from the integrated module.
3. Do not open the repair or modification equipment by yourself, tear the warranty label, and consider it as man-made damage not covered by the warranty.
4. This device is not waterproof, avoid liquid splashing, please do not store the product in a humid environment.
5. Do not charge the product near or near the heat source.
6. When charging, a certain amount of heat will be generated. This is normal and will not affect the performance of the product. However, if you feel that the cell phone battery or sterilization box is too hot, disconnect the power supply to the sterilization box and wait for it to cool before attempting to charge it.

During the warranty period, due to the failure or damage caused by the quality of this product, free maintenance service is provided; if the product is damaged due to accidents, unstable voltage and irresistible factors, it is not covered by the warranty.

Technical Parameters:

1. Product model: P16
2. Aromatherapy power: 1W
3. Wireless charging power: 10W
4. Disinfection power: LED-2W
5. UV lamp bead power: 2W
6. Number of UV lamp beads: 6
7. Input voltage / current: 5V / 2A 9V / 2A
8. Output voltage / current: 9V / 1.1A
9. Transmission distance: 2-6mm
10. Charging efficiency 80%
11. Packing size: 23.2 * 13 * 5.6cm
12. Product weight: 0.42kg
13. Power supply method: USB power supply
14. Charging status indication: When standby, blue light is always on;when charging, blue light is breathing and blue light is off after fully-charged;When it's abnormal, blue light flashes quickly.
15. Wavelength: 270-280NM

Mobile phone wireless charging instructions:

1. After connecting the UV Sterilizer Box with Wireless Charging to the power adapter and energizing, the blue indicator light breathes.
2. To charge a Qi-compatible smartphone, please put the phone on the lid.
3. After charging, remove the smartphone from the UV Sterilizer Box with Wireless Charging.

Instructions for disinfection function:

Short press the disinfection switch button to start the disinfection mode.

Short press the button, the green light is on, indicating that the disinfection mode is in progress, you will hear a beep. (Can kill 99.9% of *Staphylococcus aureus* and *E. coli*).

3. During disinfection, when the lid is opened, in order to prevent slight burns to the eyes, the disinfection lamp will go out. When the lid is closed, the disinfection process will resume.

4. When the disinfection time reaches 5 minutes, you will hear three "beep" sounds, the indicator light flashes three times and then goes out, indicating that disinfection is complete.

Aromatherapy function instructions:

If you want to add a pleasant fragrance to the item, you can add a drop of liquid aroma to the aroma distribution point in the wireless charging sterilization box before disinfection. (Liquid aromatherapy must be purchased separately)

Features:

1. Sterilization effect: 99.99%
2. The product has long life and strong durability
3. Exquisite and compact, easy to carry, does not occupy space
4. Aviation aluminum industry design, strong sense of technology
5. Comprehensive disinfection and sterilization, side cross ultraviolet disinfection and sterilization, 360 degrees circulation without dead angle
6. Optional mobile phone wireless charging function, which can be sterilized at the same time during the charging process.
7. Aromatherapy function.
8. Large capacity and multi-function, can sterilize mobile phones, masks, jewelry watches, etc.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The distance between user and products should be no less than 20cm.