



QUICK START GUIDE

# Congratulations!

You now have the world at your feet!  
Read on to find out how Lechal will take  
you places.

# Download The App.



Get our app from :



Scan QR code to register :



DARE TO MOVE THE LECHAL WAY!

# Charge Pods.



Open the dock by sliding the cover clockwise.



Insert pods into the dock, and close the cover.



Plug in USB cable and charge for two hours before first use. The LED light will blink slowly to indicate that the charging process is on, and glow solid to indicate that charging is complete.

---

# Insert Pods.

For Insoles.

Slide pod into slot from the top.



To remove the pod, bend insole slightly and slide pod out.



# Insert Pods.

For Shoes.

Lift flap and slide pod into the slot.



To remove the pod, lift flap and bend slightly to slide pod out.



# Sizing Your Insole.

Place your feet on the insole, mark the outline of the front of your foot with a pen.

Remove your foot and cut along the outline.

For your convenience, the insole already has certain size guidelines marked.



# Taking Care

## Of Your Electronics.



Charge pods for 2 hours before the first use.

Don't submerge pods in water or other liquids.



Avoid using the pods near highly inflammable solids or liquids.

Charging dock cover must be closed during charging.





## DISPOSAL

Don't burn or dispose of electronic accessories such as charger and pods with your household waste.

Please contact your local authorities to discard these products in accordance with municipal regulations.

## LIMITED WARRANTY

This product has been created and crafted in keeping with the highest standards of quality.

However, in case of any defects in material or workmanship in the pods, the pods will be replaced at no charge within a period of 180 days from the date of purchase.

Please keep proof of purchase to claim warranty.

---

*This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.*

*Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:*

- 01. Reorient or relocate the receiving antenna.*
- 02. Increase the separation between the equipment and receiver.*
- 03. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.*
- 04. Consult the dealer or an experienced radio/TV technician for help.*

**Product Specs:**

Rechargeable Li-Pol Battery ; 3.7V, 0.6Wh; Operating Temperature : 0 DegC to +50 DegC;  
Storage Temperature : -20 DegC to +35 DegC



## CONTACT

Find out more about your Lechal footwear on our website or via our app.

LEARN MORE :  
[www.lechal.com/support](http://www.lechal.com/support)

CONTACT US :  
[support@lechal.com](mailto:support@lechal.com)

Lechal  
222B West Marredpally,  
Secunderabad - 500026  
Telangana, India

Ph : +91 40 27713000  
+91 40 27711700  
[www.lechal.com](http://www.lechal.com)  
[www.ducereotech.com](http://www.ducereotech.com)



© 2015 Ducere Technologies Pvt.Ltd., Telangana, India. All rights reserved.  
Ducere and Lechal are trademarks of Ducere Technologies.

Bluetooth is a trademark of Bluetooth SIG Inc. Apple and the Apple logo are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc. Google Play is a trademark of Google Inc.

This product IS NOT A MEDICAL DEVICE and should not be used to diagnose or treat any medical condition. Consult your doctor for prevention diagnosis and treatment. Visit [lechal.com/support](http://lechal.com/support) for further guidance.

