

# User Manual



## Turning on Your HeyDo Cup

The HeyDo Cup will boot automatically when you tear the screen protector off and place it somewhere bright.



## Charging Your HeyDo Cup

Wireless Charging Dock, USB Cable (You can connect the cable to your mobile charging adapter directly)

Charging Guide: adapter is required to charge the HeyDo cup. Please place the HeyDo on the center of the wireless dock to charge the HeyDo Cup.

Signal light: If the LED light turns RED, it means that your HeyDo Cup is charging. The LED screen will also show the charging progres



## User Guide

To check your water purity level (PPM Value), Temperature and Water Intake, you have to touch the sides of the cup marked in yellow for about one second. Touch again to switch the display content.



The default display interface (with Bluetooth and batter status).

Water Intake

Water Quality

Temperature

Water Intake Reminder

3 times Water Intake Reminder if user does not drink water at all

High Temperature Reminder



### 1. User Guide (While Connected to the HeyDo App)

**Coffee Density Measurement:** HeyDo App is able to detect the density and extraction rate of your coffee. (Please download the HeyDo App for more details)

**2 Foreign Object Detection:** HeyDo alerts you when the quality of your beverage has been compromised with any water soluble. This prevents unfortunate incidents, accidental or intentional, from happening.

**3. Cheers Invitation:** This icon will display when your friends and family invite you for a drink

4. Open Lid Notification: While in safe mode, this icon will be displayed when you open the lid of your HeyDo Cup. (Only available in S1-X model)



Weight Loss Program Reminder: This icon will display if you are using the weight loss program in the HeyDo app.

Medicine Consumption Reminder System: This icon will display if you have set a reminder to consume medicine in the HeyDo app.

Alarm Clock: This icon will display if you have set up an alarm clock in the HeyDo app.

APP (Connect with your HeyDo App)

HeyDo cup is able to function without using the HeyDo app. However, we highly recommend that you download the HeyDo App to fully experience all the functionalities that comes with your HeyDo Cup. (App QR code can be found at the back cover page)

**FCC Caution:**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.