

# Comper

Smart Weight Scale User Guide

（首页由设计组设计）

# Use Your Own App

1. Search “Comper Woman” or “Comper Health” in Google play or App store.(配两个 app 的 icon)

## **Comper Woman :**

Designed for pregnant or preconception woman.

It saves, records and charts your weight data, guides you following the weight gain standard during your pregnancy, with the coolest nutrition and fitness sections.

## **Comper Health:**

Designed for whole family members.

It records and charts weight data, calculates the BMI for further health analysis, is able to set and drive you to your goal weight.

2. Download and install the app on your phone, follow the prompts to set up the App.
3. Choose the weight display unit (kg, pound) on app.

# First-time Use

1. Open the battery cover, put 4 AA batteries to power on the scale. (配图)
2. Place the scale on the hard, flat surface, step on until you see “HEY” appears on the display. (配图)
3. The measurement is completed when your weight number becomes stable from fluctuating. (配图)

# Icon Declaration

1. The batteries need to be changed when you see the following icon. (配图)
2. “OL” means the measurement is over the limit. (配两张图)

## Product Contents

1. One Smart Weight Scale
2. One User Guide

## Basic Parameters

Equipment Name: Comper Smart Weight Scale

Model: SWS1

Range: 5 kg - 150 kg (11 lb – 330 lb)

Units: kg/lb (set by app)

Accuracy: 0.1 kg(0.2 lb)

Resolution: 0.1 kg/lb

Power: 4\*1.5V AA battery

Product Size:  $\phi$  368 mm x 28 mm

Net Weight: 2.4 kg (5.07 lb)

Communication: Ultra Low Power Bluetooth 4.0

Work frequency: 2402~2480MHz

Radio power: 2dBm

### Usage Environment

Temperature: +5°C - +40°C (41°F – 104°F)

Humidity: ≤80%

**Storage Environment**

Temperature: -10°C - +40°C (14°F – 104°F)

Humidity: ≤85%

**Manufacturer:** Comper Chuangxiang (Beijing) Technology Co. Ltd.

**Factory Address:** Room 102-103 1st Floor, Building 4, No.1 Kangding Street, Daxing District, Beijing 100176, China

# Notice

Please use or maintain the scale according to below contents. The company shall not be liable for any damage to persons or articles arising from the operations not in accordance with below contents or the original purpose of the product.

1. Do not use the scale in flammable environment, due to possibility of fire or explosion.
2. Do not disassemble, destruct, heat or force the scale into a fire, due to possibility of circuit explosion.
3. Keep out of children. Adult supervision recommended during child use, to avoid injury.
4. Do not put the scale on the wet floor, and ensure feet are dry prior to stepping on the weight panel, due to possibility of slipping.
5. Do not place the scale in a wet area, due to possibility of product failure.
6. Avoid strong impact, including falls from height, due to possibility of product breakage.
7. Do not immerse the scale in water, due to possibility of product failure.
8. Do not disassemble, repair or retrofit the scale, due to the possibility of measuring errors or causing damage to it.
9. Please use the batteries correctly, to avoid damage to the circuit.
10. Please buy the batteries in formal channels.

# Maintenance

- Please use dry and soft cloth to wipe the scale's surface.
- **DO NOT** use volatile agents, thinner, gasoline, alcohol etc. to remove the dirt.

# Product Warranty Information

Comper warrants the smart weight scale against defects in quality when used normally in accordance with user guide and ONE (1) YEAR from the date of original retail purchase by the end-user purchase (purchase invoice required):

The following will void the warranty:

1. Product damage caused by negligence of produce specification notice.
2. Self-repair, disassembly, man-made damage, natural disasters and irresistible force.
3. Use more than 1 year.

Please visit Comper official website for more service: [www.comper.com](http://www.comper.com)

# **Federal Communications Commission (FCC) Statement**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1) This device may not cause harmful interference and
- 2) This device must accept any interference received, including interference that may cause undesired operation.

## **15.21**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

## **15.105(b)**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## **FCC RF Radiation Exposure Statement:**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

# RED Declaration of Conformity

**We, Comper Chuangxiang (Beijing) Technology Co., Ltd, Room 102-103 1st Floor,  
Building 4, No.1 Kangding Street, Daxing District, Beijing 100176, China**

declare under our sole responsibility that the product:

Product Name: Comper Smart Weight Scale

Product Model: SWS1

**to which this declaration relates is in conformity with the essential  
requirements and other relevant requirements of the Radio Equipment Directive,  
2014/53/EU.**

**The product is compliant with the following standards and/or other  
normative documents:**

SAFETY (art 3.1.a): EN 60950-1:2006+A11:2009+A1:2010+A2:2013

HEALTH(art 3.1.a): EN62479: 2010

EMC (art 3.1.b): ETSI EN 301 489-1 V2.1.1 Final draft, ETSI EN 301 489-17 V3.1.1 Final draft

SPECTRUM (art 3. 2): ETSI EN 300 328 V2.1.1 (2016-11) Published

The conformity assessment procedure referred to RED Article 3.1(a), 3.1(b) and 3.2  
has been followed with the involvement of the following Notified Body(ies):

**TUV SUD BABT, Octagon House, Segensworth Road, Fareham, Hampshire,  
PO15 5RL, UK**

Identification mark: **CE**

Signed:

Name:

Title:

Date:





Well-made for well-being

#### Legal Disclaimer

Comper Chuangxiang (Beijing) Technology Co. Ltd has the ownership and final interpretation of description of Comper app.

Comper App pursuits for perfect and excellent function, if there is any discrepancy with this specification, subject to the latest version of app.

Comper Chuangxiang (Beijing) Technology Co. Ltd owns the copyright of Comper app.

#### Copyright

Copyright is owned by Comper (Beijing) Technology Co., Ltd., the Company shall enjoy and reserve all exclusive authority of copyright. No part of the Manual shall be increased or decreased, excerpted, reproduced, altered or imitated without the prior written consent of the Company.

For the content of this Manual, the Company is not responsible for any explicit or implied warranty or guarantee liability. The content change caused by product improvements and technology updates could occur at any time without prior notice. The power of interpretation is vested by the Company.