

## **Instruction**

### **Structure**

1. Power button: power on / power off
2. Charging panel
3. Sensor module: photoelectric sensors, acceleration sensors, pressure sensors
4. Indicator light:

Pillow startup: fast alternating of the red and blue light

Low battery: fast flash twice of the red light, reminder on the APP side.

Charging: slow flashing of the red light

Charging completed: the red light is normally on

## **Usage**

1. Install APP "Sleep Tailor" on smart mobile equipment
2. Power on Tailor
3. Activate mobile equipment's Bluetooth and search TAILOR to bind with the product
4. Connect and then use to monitor sleep

## **Application**

Be applicable to mobile Bluetooth equipment of IOS 7.0 and Android 4.3 or later.

## **Note**

Using together with the Tailor Pillow case is recommended for best monitoring effects.

Please remember that this product is not a medical device or a device that can prevent sudden death. The user should not completely depend on this product and ignore the care for the monitored person. For the users with disorders, the family should inspect the condition of the monitored person frequently by themselves.

Using the pillow while charging is not recommended

Only the pillow case of the product needs to be washed on time. Please don't wash the pillow inner or put the pillow inner into water, this might cause damages to this product.

Please don't contact this product with high temperature devices.

Please don't bend this product excessively. There are sensor modules inside this product, excessive bending might damage the sensors.

When the power adapter is plugged into the socket, please don't touch the metal end of the power adapter.

## FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.