

Ossine smart watch

User manual

1. System & Hardware requirement

Android4.4 or above

iOS 8.0 or above

Bluetooth4.0

2. Use preparation

For first time use, please ensure the battery has enough power. If it can't turn on, please put the watch on the charger to charge. When charging, it will have charging indication on the screen.

Charge method:

Initial use to ensure adequate power. If it can't turn on, please charge. (Please check the following picture for how to charge)



3. Connection

Please confirm the mobile phone system is suitable for this device, then download the suitable APP.

Download APP:

Please search “ Wearfit ” in Apple store and Android APP store , click to download and install.

Binding:

Please ensure the phone bluetooth is on, open “ Wearfit ”, click the selection of Link bracelet to link watch, find the device name in the Bluetooth list and click it, then enter the main interface.

4. Start using

Once the device connected to the APP successfully, it will be sync the bound phone time , instantly record your movement data, heart rate, blood pressure and sleep quality.

Operation:

Slide vertically on the screen to update. In the top left corner, click the main menu to enter the sub menu interface.

Main menu	Function
Userinfo	Setting user information
Health Weekly	Data every Week
Shake photograph	Take a picture by shaking hand
Run	Running outside
Device Management	Connection management, Reminder, Smartphone anti-lost, Wrist activation, Hourly testing, Update
Setting	Setting personal info., health goals, reset watch, Connecting other APP.
About	About us, Q&A
Link & disconnect Watch	Connect or disconnect

Function Instruction

1. Time Mode:

Display time, battery, date

2. Sport record:

Automatically records the number of steps.

3. Message reminder:

Open the “Device Management/Intelligent reminder/SMS notification” function in APP, the watch will vibrate when the phone receives messages.

4. Heart rate monitor:

The device will automatic measure real time heart rate hourly, it also can be manually measure by APP, watch switch to heart rate mode will turn on the measurement. If no need measure this, please continue to switch. The watch shows the last measured data.

5. Blood oxygen monitor.

The device will automatic measure real time blood oxygen hourly, it also can be manually measured by APP, watch switch to blood oxygen mode will turn on the measurement. If no need measure this, Please continue to switch. The watch shows the last measured data.

6. Blood pressure monitor:

The device will automatic measure real time blood pressure

hourly, it also can be manually measured by APP, watch switch to blood pressure mode will turn on the measurement. If no need measure this, please continue to switch. The watch shows the last measured data.(About 150 seconds waiting for the measurement, the measured data will have difference with the real data if the watch sensor is far away from skin or the being tested skin has smudage .)

7. Sleep monitor: Automatically monitor daily sleep quality.
8. Call reminder: Open the “Device Management/Intelligent reminder/Calls reminder” function in APP, the watch will vibrate when the phone rings.

5. Q&A

1. Can't find device when pairing device?

Please ensure the phone Bluetooth is on and close the watch and try again, please confirm your phone system is IOS 8.0 above or Android 4.4 above .

2. After binding, show bluetiooth hasn't connect?

Please ensure the phone Bluetooth is on and watch have enough power, get close to watch, and the watch will automatic connect to phone if unbind, then rebind it.

3. APP no data?

The message data will display by timing and manual measurement. If not the timing automatic measurement, no new data display. If you want real time data, you can do manually measure. Please check the watch power and charge it in time, ensure the watch is connected to the phone.

4. Wrong time?

If the watch is low power, the displayed time may be wrong after charged. Please connect the phone again and the watch time will automatic update.

6. Specification

Screen size: 0.49"	Watch size: Dia.41.5mm
Bluetooth: 4.0 BLE	Strap size:230mm×22mm
Battery type: Polymer lithium battery	Material: Stainless stell
Battery capacity:55mAh	Waterproof: 3ATM
Packing List: Smart Watch, Strap, Charger&cable, user manual	

*The company reserves the right to make changes to the contents of the specification without notice. Some of the features in the corresponding software version is different, it is the normal situation.

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.