

User Manual

Wireless remote control BWR132



1、 Code matching



At the same time, press the head to open and close button for 3 seconds, and the background light will start flashing. The flashing time is 3 seconds, and the code matching is completed.

The code operation shall be completed within 2 minutes after the control box is energized, otherwise the control box shall be reenergized.

The control box is not allowed to check the code several times within 2 minutes. The code must be checked again after re-energizing.

2、 Human-computer interaction requirements

There is an indicator light on the control box, which is used to indicate the current state of the power supply.

3、 Key function description:



One-key reset: click the button head and foot to reset at the same time, and click stop reset again



Flashlight: click this button and the flashlight will turn on the bright white light. Click this button again and it will be turned off. If not, it will be turned off automatically after 3 seconds



Adjust the bed to the required setting position, and press the "foot on and off" button for 3 seconds. The background light will flicker. Press any memory button within 6 seconds to stop the flicker. At the same time, press the "turn on and off" button on the foot, and the light flashes for 6 seconds to restore the initial position.



Up arrow: press the head to open, release to stop opening
Down arrow: press the head to close, release to stop closing



Up arrow: press the foot to open, release to stop opening
Down arrow: press the foot to close, release to stop closing

4、 Power requirements:

- 1) the remote control USES 3pcs 7# batteries;
- 2) dc power supply of 20V~36V is used in the control box

5、 Control box function:

Reset:

- 1) press down the back and the foot to perform the reset action at the same time;
- 2) during the reset process, release the button and the operation stops; Press the reset button again to continue the reset action.

Power supply: connect DC 29V DC power supply

Foot: connect the foot actuator

Head: connect the head actuator

FCC Statement

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user' s authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.