

台灯说明书 100x140mm 双铜

Product Specs

LED Light Source

LED Cover

Pivot Point

Lamp Body

LED Display with Time Date Day(some models) Temperature

Display Controls

Motion Sensor Light

Connector

Connector Dock

Touch Sensitive Light Controls

Type C Connector

Buzzer

Internal Battery

Motion Sensor Switch

MIC

Power Input

USB Ports

Key Product Features

Motion Sensor Light. Lights up a dark room to make it easier to find where you are.

High Quality LED Light Source. 3 different Hues: Soft White, White & Yellow.

Touch Sensitive Light Adjustment. Easily select from 10 levels of intensity to fit any environment.

Extra USB Port. The lamp base contains 1 additional USB port for convenience.

Support wireless Bluetooth music play back with Hi Fi speaker.

Clock Time Sync with phone through Tuya App.

Supports typeC.

LED Display Operation

Temperature

Time/Alarm

Calendar

LED Screen Adjustment Buttons

Mode Set Up Down

M S ^ v

Operating and Setting the LED Screen

When powering on your Lumicharge you are put into "Standby" mode. From here you can set Time, Date and Alarm

In Standby mode, press the set button to cycle through the available functions:
Standby Mode> Hour> Minutes>Year>Month> Day> Exit.

To change the time standard between 12/24 hours, go into Standby mode , press Up button.

To change the temperature reading from C to F, go into Standby mode and press Down button

Setting the Alarm and snooze

- In the Standby mode,press Mode button to enter alarm mode, and the clock icon is off.
- In the alarm mode, press the SET button to enter the alarm mode, and press again to enter the Settings of the next option. The order of setting is:time - minutes - snooze - music - exit.
- Press the Up and Down keys to set.
- In the Alarm mode, press the Up and Down button to turn on and off the alarm and snooze function, press again to enter the Settings of the next functional markers.The order of setting is: turn on the alarm -- turn on the snooze -- turn off the alarm -- turn off the snooze.
- When it reaches the alarm time, the alarm will last for 1 minute, and when it reaches the snooze time, the alarm will ring again. Press the SET button or any button to stop the ringer.

The Wireless Charger

Wireless charging on/off button

Keep press to turn on/off Light ; Long press 3 seconds to turn on/off Bluetooth

Speaker

Speaker

Green/Red light

Wireless charging

Wireless Charging:Touch/Tap the wireless charging button,the red light is turned on,Place the mobile device with wireless charging function on the charging mat to charge your phone.

Green light is turned on when the phone is charging.

PLEASE MAKE SURE YOUR PHONE/DEVICE Can support wireless charging.

PS: Wireless charging may need the cell phone cover/case to be removed depending on the case thickness and material

MOTION SENSOR NIGHT LIGHT

When it is dark and LumiCharge detects a motion in the room night light will turn on and will stay on till there is on motion detected in the room.
Use the switch at the back to Turn ON/OFF this function/light.

LumiCharge®

Smart LED Lamp+Universal Phone Dock

Operating Manual

Model:LC3

Thank you for purchasing your Lumicharge Smart Lamp. Please read the manual carefully and keep for later use.
www.thelumicharge.com

Quick Start

AC 100-240V 50/60HZ

DC 12V

USB Port

Wireless Charging ON/OFF:Touch this key to turn on and off wireless charging.

Keep press to turn on/off Light ; Long press 3 seconds to turn on/off Bluetooth

Mode: Touch this key to change light hue

Clock display shading: Touch this key to high and low three adjustment

Increase: Touch this key to increase the light intensity. Long press for Fast Adjustment

Decrease: Touch this key to decrease light intensity. Long press for Fast Adjustment

Motion Sensor: When lights are off near the Lumicharge, the Motion Sensor will illuminate with movement (10'-15'). The Motion Sensor will stay illuminated about 15 seconds.

Connect to the "Tuya" APP

- Install "Tuya App" on your phone and register your account to log in, if you have an account, please login directly to enter
- After power on, long press the Mode key at the bottom of the LCD screen to reset the device, when the device emits a "beep beep" sound to indicate a successful reset, then you can start connecting to the new phone.

3.Open "Tuya App", click "Add Device",find the "Switch (Bluetooth)" icon to start adding devices.

4.Click on the next step

5.After the device is detected, click the "+" icon

6.The process of adding devices will show the progress of adding

7.Finally click "Finish"

8.After the device is added, Clock Time Sync and can turn on/off the lights,adjust the brightness and color temperature in the APP

Adjustment Capabilities

The Lumicharge lamp head and body can be adjusted for wide Angle lighting area coverage.

Lamp Head Angle Adjusment

- The lamp head has a 180° range of motion
- When adjusting the lamp head, be sure to holdthe base of the lamp for stability.

Lamp Body Forward and Backward Rotation

- The lamp body has a forward and backward range of motion of 100°
- When adjusting the lamp body, be sure to hold the base of the lamp for stability.

Lamp Head & Body Side Rotation

- The lamp body has a left and right range of motion of 60°
- When adjusting the lamp body, be sure to hold the base of the lamp for stability.

Warranty Card

This certificate extends the warranty for a period of 6 months from the date of purchase for Registered products. This warranty covers components and workmanship only. Replacement or Repair decision is at the discretion of the manufacturer. This certificate does not provide coverage for lost or damaged parts due to improper usage of the product. The warranty if not valid if we determine there was improper usage of the product.

Product Name
Product Color
Purchase Date

Product Registration Card

Thank You for your interest in our product. We are happy to have you as a valued customer. Please register your product with us for future communication with us. Please register your product at www.thelumicharge.com

Product Name/Color:
Purchased From:
Purchase Date:
Customer Name:
Contact Email:

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is Subject To the following two conditions:

- (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not explicitly approved by the party responsible for compliance could void the user's authority to operate this equipment.

Note: this equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and candidate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

For BT

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

For WPT

The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. During the operation of device a distance of 15 cm surrounding the device and 20 cm above the top surface of the device must be respected.