

## Wireless Charging Dock

### Disclaimers and Safety Precautions

Thank you for choosing planck O2 Smart Electric Toothbrush. In order to provide you with a better experience, please read this instruction carefully before using this product and keep it for future reference.

This product is for personal use, once used, it will be regarded as an approval and acceptance of the entire content of this statement. Please install and use this product in strict accordance with the manual, product instructions and relevant laws, regulations, policies and guidelines. In the process of using this product, users should undertake to be responsible for their own behaviors and all consequences arising therefrom. Shenzhen EVOWERA Technology Co., Ltd. will not bear any legal liability for any loss caused by improper use, installation or modification of the users.

### Important Safety Information

#### HAZARD

- Keep away from water when charging. Do not place or store this product in a place where it may fall into the sink.
- Do not immerse the charging cable in water or other liquids.
- After cleaning, keep USB and Type-C ports completely dry before connecting them to adapters or power outlets.

#### WARNINGS

- If there is any damage to this product , please stop using.
- DO NOT let children use, clean or maintain this product without supervision.
- Do not allow children to use, clean or maintain this product without supervision.
- Charge, use and store this product at a temperature between 10°C and 40°C.
- Keep this product away from fire and do not expose it to direct sunlight or high temperature.
- If this product is unusually hot, or smells, changes color or takes longer than usual to charge, please stop using and contact evowera.
- That it must only be supplied at safety extra low volt-age corresponding to the marking on the appliance.

### Product Introduction

planck O2 Smart Electric Toothbrush uses a dual-drive permanent magnet synchronous servo motor with features such as pressure sensor feedback, brushing force adjustment, and excessive force feedback to ensure efficient cleaning results with every use, effectively remove plaque, making teeth whiter and gums healthier.

### Product Components

Wireless Charging Dock

1. Wireless Charging Dock
2. Wireless Charging Protection Cover

### Get Started

1. Toothbrush Charging

Place the wireless charging dock protection cover on the charging dock, plug the USB cable into an adapter or power outlet that meets the rated input voltage/current of the device, and place the toothbrush handle on the charger, and the display of the toothbrush will indicate the charging status.

### Specification Parameter

Product name: Wireless Charging Dock

Model: E2252

Waterproof grade: IPX7

Rated voltage: 5V

Rated power: 3.5W

Rated input: 5V/1A

Manufacturer: This product is authorized by Shenzhen EVOWERA Technology Co., Ltd.

Address: 402, block C, Skyworth Building, No. 008, High-Tech South 1st Rd, Yuehai Street, Nanshan District, Shenzhen, China

#### **Warranty and Support**

The international warranty does not cover the following items:

1. Brush head.
2. Damage caused by the use of unauthorized device.
3. Damage caused by misuse, abuse, negligence, modification or unauthorized repair.
4. Normal wear and tear, including cracks, scratches, wear, color change or discoloration, etc.

The contents are subject to update without notice. Go to <https://www.evowera.com> for the latest version.

#### **Compliance Information**

##### **FCC Compliance Notice**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

##### **Caution**

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

##### **FCC Radiation Exposure Statement**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body

##### **EU Compliance Statement:**

Shenzhen EVOWERA Technology Co.,Ltd. hereby declares that this device is in compliance with the essential requirements and other relevant provisions of the RED Directive.

A copy of the EU Declaration of Conformity is available online at [www.evowera.com](http://www.evowera.com)

ROHS 