

MOOMI SLEEP

Quick start

1 INSTALL APP

Search for Moomi Sleep app at the App Store or Google Play Store.



2 TURN ON MOOMI TRACKER



Press the power button **on the side** for 3 seconds. You will hear a jingle indicating the tracker is on.

3 PAIR MOOMI TRACKER

Start Moomi Sleep App. Follow instructions to set up an account and pair your tracker.



4 WEAR IT

Insert tracker into the strap. Wrap the strap around your little one's arm or leg.



5 THAT'S IT!

Moomi Sleep automatically tracks your little one's sleep.



WARNING!

Moomi Sleep is not a medical device or a toy.



Moomi Sleep is not a toy. Do not let your child play with it when it is not worn by your child.

Moomi Sleep is not intended for use as a medical device or to replace a medical device.

Moomi Sleep is not intended for use in the diagnosis, cure, mitigation, treatment, or prevention of baby sleep disorders nor intended to affect the structure or any function of the body of a baby.

Moomi Sleep is not intended to replace you as a caregiver.

You are responsible for the health and well-being of your baby by following safe sleep, health, and care guidelines.

WARNING!

Moomi Sleep is not a medical device or a toy.



Store Moomi Sleep Tracker and Strap in the included storage bag.

Store in a dry area where your child cannot reach.

Store in a dry area with consistent temperature.

Do not store near any heating equipment.

Do not expose the tracker to direct sunlight for a long period of time.

Do not abuse Moomi Sleep Tracker mechanically by opening, destroying, or burning it.

MOOMI SLEEP INSTRUCTIONS

CHARGING MOOMI



INSERT CHARGER

Insert USB charger to any fitting power source.



ATTACH MOOMI

Bring the Moomi tracker close to the magnetic charging end, it will attach automatically.



BLUE LIGHT = CHARGING

Once attached, a blue light blinks indicating it is charging. When the blue light goes off, charging is complete.

COMPLETE INSTRUCTIONS

Find more at MoomiSleep.com.

MOOMI SLEEP INSTRUCTIONS

ABOUT MOOMI



QUALITY MATERIALS

The strap of Moomi Sleep is made of cotton and quality materials.



WASHING

The strap can be machine-washed warm. Remove the tracker before washing.



STORAGE BAG

Storage bag is water proof. It can be cleaned with a damp cloth.



TRACKER

Avoid liquid spills on the tracker. If the tracker is dirty, wipe it with a damp cloth.



APP

Both iOS and android apps are available for download. We offer personal assistance if needed. A demonstration video is also included in the app for your convenience.

COMPLETE INSTRUCTIONS

Find more at MoomiSleep.com.

MOOMI SLEEP INSTRUCTIONS

STRAP WASHING INSTRUCTIONS



WASH BEFORE USE.



COLOR MAY TRANSFER WHEN NEW.



WASH WITH LIKE COLORS.



MACHINE WASH WARM.



DON'T BLEACH.



DO NOT TUMBLE DRY.



DO NOT IRON.

COMPLETE INSTRUCTIONS

FCC Compliance Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and; (2) This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates—and can radiate—radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the equipment does not cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and the receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The provided shielded USB cable must be used with this unit to ensure compliance with the class B FCC limits.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.