

wave
**SOUND THERAPY
EYE MASK**
WITH BUILT-IN SPEAKERS



IMPORTANT SAFETY INSTRUCTIONS DO NOT DESTROY

1. Read and follow all operating instructions prior to using this product.
2. Stop using this product immediately if it becomes damaged or is found to be defective.
3. Do not attempt to disassemble the battery unit if the battery unit is broken, cracked, or ruptured. If it is broken, avoid contact with skin and discard immediately. In the event of contact with skin, mouth, or eyes, flush immediately with cold water and consult a physician.
4. Discontinue use immediately if infrared heating elements become uncomfortably hot.
5. Keep out of reach of children.

6. Do not use this product if the battery unit, temperature controller or heating elements will be directly exposed to water or wet conditions.
7. This device contains a lithium-ion battery. The battery must be recycled or disposed of properly. Contact your local waste management office for information on battery recycling or disposal.

PRODUCT SPECIFICATIONS

Size:	19.6" x 4.7" x 1.1"
Weight:	0.3 lb
Charger Input:	100-240V, 50/60Hz
Output:	DC 5V 1A
Battery Type:	Lithium-ion 350mAh 3.7V
Battery Life:	4-8 hours
Battery Charge Time:	Approximately 1 hour
Material:	Micromink

INTRODUCTION


Thank you for purchasing the Wave Sound Therapy Eye Mask with Built-In Speakers from Pure Enrichment. This luxurious eye mask effectively blocks out light while providing soothing sounds to lull you to sleep.

PRODUCT FEATURES

We designed the Wave Sound Therapy Eye Mask with several features that make it a calming and comforting solution to enhance your sleep and relaxation. These include:

- Easy Touch Controls
- Built-In Battery
- Adjustable Fit
- Removable Cover
- Bluetooth Connectivity
- 3 Nature Sounds: Rain, Stream, and Ocean

CONTROL PANEL DIAGRAM



- | | |
|---------------------------|---------------------------|
| 1. Power Button | 5. Music Indicator Light |
| 2. Charging Light | 6. Volume Decrease Button |
| 3. Volume Increase Button | 7. Power Light |
| 4. Music Button | |

USING THE EYE MASK

Turn On/Off Power

To turn on: Press and hold the Power Button until the blue Power Light comes on. **To turn off:** Press and hold the Power Button until the blue Power Light turns off.

Turn On Sound

Press the Music Button. The blue Music Indicator Light will turn on:

- 1st press - Nature Sound #1
- 2nd press - Nature Sound #2
- 3rd press - Nature Sound #3
- 4th press - Bluetooth Mode (use to stream music or podcasts)

NOTE: Wave is designed with soft speaker technology to help you relax. It is best used to play soft, soothing sounds.

Pairing Bluetooth

1. Disconnect phone or other electronic device from other Bluetooth devices.
2. Turn on the eye mask's sound and enter Bluetooth Mode.
3. Access Bluetooth pairing in phone or other device.
4. Select the Bluetooth device named "PESDEYE-G" and connect to it.

Answering or Making Phone Calls

There is no phone call setting built into this device. Please make and answer calls directly from the smartphone paired to the device.

Adjusting Volume

- Press the (-) Volume Decrease Button to turn down the volume
- Press the (+) Volume Increase Button to turn up the volume

Low Power Warning

When the eye mask is low on power, you will hear a reminder sound. Please charge the device with the included charger. While the device is charging, the Charging Light is red. When the battery is fully charged the Charging Light turns off.

CARE & MAINTENANCE

To prolong the life of your Wave eye mask, proper care and cleaning are essential. Follow these instructions to preserve the softness of the fabric and protect the electrical components.

1. Always unplug the eye mask from the electrical outlet, connecting cable, and battery before cleaning.
2. Remove the outer cover.
3. Spot clean with a damp cloth or hand wash in cold water with mild detergent. Do not place it in the washing machine.
4. Hang dry.

WARRANTY

The Wave Sound Therapy Eye Mask comes with an industry-leading 5 Year Warranty that begins on the date of purchase.

The warranty applies to the sound therapy eye mask and necessary parts and labor relating thereto. The warranty does not apply to damage resulting from failure to follow the operating instructions, accidents, abuse, alterations, or disassembly by unauthorized individuals.

PRODUCT REGISTRATION

To ensure your full warranty and to receive product updates and streamlined customer support, remember to register your product at:

pureenrichment.com/productregistration

PRODUCT SUPPORT

We've got you covered with a hassle-free warranty and friendly product support that responds within 1 business day.

help@pureenrichment.com
(657) 275-3737

(Available Monday-Friday, 8am-5pm PST)

FCC NOTICE

Model: Wave Sound Therapy Eye Mask (PESDEYE-G)

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Pure Enrichment
5985 Schaefer Ave.
Chino, CA 91710
pureenrichment.com

The product is protected against unauthorized use. DO NOT modify it without the authorization of the manufacturer, or the user's authority to operate could be voided.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

