

afang

The UV radiation symbol:

"UV light", or equivalent text
"Possible skin or eye damage" or
equivalent text
Disconnect power before servicing"
or equivalent text

UVC-AF018

MULTI-FUNCTION MINI STERILIZER
WITH WIRELESS CHARGING
User Manual

Thank you for purchasing our products . Please read this manual carefully before using the product and keep it well for future reference.

PRODUCT STRUCTURE

Disinfection button /
indicator light

Wireless
charging area

Type-C charging port

Notes : The pictures of product are subject to practicality

ACCESSORIES

Sterilizer-----1PCS
Charging Cable-----1PCS
User Manual-----1PCS
Dropper-----2PCS

SPECIFICATION

Brand : AFANG
Name : UV Sterilizer Magbox
Model : UVC-AF018
Color : White
Weight : about 360g
Material : ABS + PC
Size : 210 * 120 * 62mm
Input : 5V---2A 9V---2A
Wireless Output : 10w (Max)
UV light Output : 2W (Max)
Wireless Charging Conversion Rate , 73%
Wireless Charging Sensing Distance : < 6mm

FUNCTION INSTRUCTION

WIRELESS CHARGING MODE

① After powered on , the product will enter into wireless charging mode by default , and the indicator light is red , if no device is detected (no-load state) , the light will turn off and enters into stand-by mode after 30s.

② After powered on , make sure that the products lid is closed . Put phone / earbuds with wireless charging function on wireless charging area , phone / earbuds will automatically enter into charging mode.

③ If device is picked up during charging process , the charging will stop ; wireless charging and sterilization functions can work at the same time.

DISINFECTION FUNCTIONS

① Put items need to be sterilized into the box and close the lid

② Disinfection mode in 18 minutes : short press the disinfection button once , you will hear voice prompt di " , and the indicator light is green , then enter 18-minute sterilization mode

③ Disinfection mode in 30 minutes : short press the disinfection button once , you will hear prompt " di " , and the indicator lights green ; short press the disinfection button once again , you will hear prompt " didi " , and the indicator light will be blue , then start to enter 30-minute sterilization mode

④ When hear voice prompt " dididi " , which means the finish of sterilization , you can take out the items

⑤ In the process of disinfection , if you need to stop the disinfection , please long press the disinfection button for 3s , afterhear voice prompt di " , and the indicator light will be off , which means the stop of sterilization , you can take out the items

AROMATHERAPY FUNCTION

Before disinfection , use the dropper to drip 2 or 3 drops of perfume into the aromatherapy hole in the box for aromatherapy process

INDICATOR LIGHT STATUS PROMPT

Mode	Indicator light
Stand-by mode (no load after power on)	The red light turns off after 30s
Wireless charging mode	The red light keeps on
18-minute disinfection mode	The green light keeps on
30-minute disinfection mode The blue light keeps on	The blue light keeps on
Wireless charging & 18-minute disinfection mode work in sync	The light is red + green
Wireless charging & 30-minute disinfection mode work in sync	The light is red + bluet

ATTENTION (TYPICAL SITUATIONS)

Please read the following attentions carefully before using this product , Incorrect use or incompatible equipment may damage our device or this product

① This product has no power storage function , so it needs connect the power supply during the whole working process

② When the product is working , it will auto close ultraviolet light if open the lid , in order to prevent harm to human body and eyes , when close the lid , it will auto turn on ultraviolet light for sterilization!

③ Do not drip excessive aromatherapy liquid , do not use alcoholic aromatherapy liquid (such as Florida water) to avoid adverse effects on mobile phone made of silicone ;

④ During the charging process , the wireless charging area

cannot contain metal materials , such as iron plates , metal protective cases , etc

⑤ Do not use this product in high temperature / humid environment , keep away from fire / water

⑥ Please do not scratch the surface of the product with sharp objects ; do not throw , shake , press forcibly or attempt to disassemble the product

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different

from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

CE FC

Warranty Card

Thanks for choosing AFANG products ! This product machine body warranty is 1 year since the selling date , accessories not included in warranty . Normal use within warranty , if the goods have quality problem , we will responsible for fixing it.

Below situation not included in warranty

1. Have no valid buying certification and warranty card

2. Shell damage or physical damage by man-made

3. Fall , extrusion , soaking , damp or other human-caused damage

4. Damage by natural disasters like flood , fire , lightning stroke

No:		Date of Purchase:	
Customer:		Dealer:	
Address:			
Tel:			
Batch Number:			

afang

UVC-AF018

无线充消毒盒
用户使用说明书

感谢您购买我公司产品,使用本产品之前请认真阅读手册并妥善保存,以备查阅

产品结构

除菌键/
工作指示灯

无线充感应区域

Type-C充电口

说明书涉及图片均为示意图,最终产品以实物为准

内含

无线充消毒盒-----1PCS
充电线-----1PCS
说明书-----1PCS
滴管-----2PCS

规格参数

品牌:AFANG
名称:无线充消毒盒
型号:UVC-AF018
颜色:白色
重量:约360g
材质:ABS+PC
尺寸:210*120*62mm
输入:5V---2A 9V---2A
无线充输出:10W(Max)
紫外线输出:2W(Max)
无线充转化率:73%
无线充感应距离:≤6mm

功能介绍

无线充电

①产品通电后,默认进入无线充电模式,指示灯亮红色,若未检测到待充电产品(即空载状态),灯亮30秒后即熄灭待机

②产品通电后,确保产品上盖处于闭合状态,将支持无线充电功能的手机/耳机对准充电标志放下,手机/耳机将自动进入充电模式

③充电过程中如设备被拿起,则充电中止,无线充电可与除菌功能同时进行

除菌

①将需要除菌的物品放入除菌盒,盖上盖子

②18分钟除菌模式:短按除菌键一次,“嘀”声提示,且指示灯亮绿色,即开始进入18分钟除菌模式

③330分钟除菌模式:短按除菌键一次,“嘀”声提示,且指示灯亮绿色,再短按除菌键一次,“滴滴”两声提示,且指示灯亮蓝色,即开始进入30分钟除菌模式

④连响“滴滴滴”三声,代表除菌结束,可开盖取物

⑤如需要临时中止除菌,长按除菌键3秒,“嘀”声提示,且指示灯熄灭,则除菌中止,可开盖取物

香薰

除菌前,使用配备的吸管,将2-3滴香薰液滴入盒内香薰孔,即可在除菌的同时,对盒内物品进行香薰除味

指示灯状态提醒

模式	指示灯
待机模式(通电后空载状态下)	指示灯亮红色30秒后熄灭
无线充电模式	指示灯长亮红色
18分钟除菌模式	指示灯长亮绿色
30分钟除菌模式	指示灯长亮蓝色
无线充电&18分钟除菌模式同时进行	指示灯长亮红绿混色
无线充电&30分钟除菌模式同时进行	指示灯长亮红蓝混色

注意事项(典型但不完全)

请仔细阅读以下内容再使用本产品,错误的使用方法或者不兼容的设备有可能损坏你的产品或导致本产品受损.

①本产品无充电功能,所有工作需全程接通电源;

②除菌盒工作时,开盖后自动关闭紫外线灯,防止为人体及眼睛产生伤害,闭合后自动打开紫外线灯继续除菌;

③请勿滴入过量香薰液;请勿使用含酒精的香薰液(如花露水),以免对硅胶材质的手机产品不良效果;

④充电过程中,无线充感应区域不能带有金属物质,如铁片、金属保护壳等;

⑤请勿在高温/潮湿环境中使用本产品,远离火源/水源;

⑥请不要用尖锐物体刮擦本产品外壳表面,请勿抛掷、摇晃、强压或试图拆卸本产品。

产品保修卡

真诚地感谢您选择产品!本品自购买之日起, 主机保修为一年, 配件损坏不在质保范围内, 在保修期内凡属正常使用情况下, 由于产品本身质量问题引起的故障, 均负责维修。

以下情况恕不免费保修:

1、无有效购机凭证或三包凭证;

2、由于人为原因造成外壳及物理损坏, 不在免费维修范围内;

3、由于坠落、挤压、浸水、受潮及其他人为造成的损坏;

4、由于火灾、火灾、雷击等自然灾害造成的损坏。

型号:		购买日期:	
用户姓名:		购买商号:	
地址:			
电话:			
生产批号:			

CE FC