



## USER MANUAL

### UVClean Tabletop Sterilizer™ 120w

Model: PT2120C

Please read instructions carefully before using and keep instructions for reference before each use.

A germ-free environment is crucial for the safety and wellness of customers, patients, employees, and family members. UVClean Tabletop Sterilizer™ uses the century-long proven 254nm ultraviolet light to irradiate objects from deadly viruses without employing laborious scrubbing or the use of chemicals.

#### Operating the UVClean Tabletop Sterilizer™ 120w

1. Plug the Lamp into your wall socket.
2. To turn on the bacterial lamp, press any timer button. Selections are 15, 30, 45 and 60 minutes.
3. Leave the room once you hear the “beep” that indicates the lamp timer cycle has begun. Once you hear a solid “beep”, the lamp will turn on in 15 seconds and begin sterilizing.
4. The motion deactivation sensor will stop sterilization operation when humans or animals are present in the considered harmful area and reactivate 25 seconds after departure.
5. When the pre-set time is complete, the lamp will automatically shut off.
6. You may enter the room after the lamp has been turned off and the timed cycle is complete.

**Warranty:** Product is covered under a 6-month replacement warranty against manufacturing defects. Warranty is null and void if the product is damaged physically by the consumer; the product is repaired, maintained, modified, and disassembled.

#### Wireless Remote Use

1. Download the App from the Apple Store or Android Play Store. Follow the setup instructions by search UVClean.
2. Use either Bluetooth or Wifi to begin the sterilization cycle. Choose 15, 30, 45 or 60 minutes. Your selection will turn GREEN.
3. Leave the room once you hear the “beep” that indicates the lamp timer cycle has begun. Once you hear a solid “beep”, the lamp will turn on in 15 seconds and begin sterilizing.
4. When the pre-set time is complete, the lamp will automatically shut off.

#### Product Specifications

Model:	PT2120C
Wattage:	120W
Dimensions:	6 x 8 x 28”
Weight:	4.4 lb, 2 kg
Color:	Silver
Material:	Aluminum
Bulb Lifespan:	8,000 hours
Power Supply:	100-240V, 50/60Hz
UV Wavelength:	253.7 nm
Sterilizing Area:	1300 sqft (36 x 36ft); 120 sqm (11x11m)
Control:	On/Off Buttons, Remote Control via Bluetooth and WiFi

Disclaimers: Germicidal ultraviolet lamps pose imminent danger if used without taking the proper precautions. You MUST avoid exposure to direct or reflected germicidal ultraviolet rays, since they cause painful eye irritation and reddening of the skin. Under no circumstances should any direct germicidal UV-C unit be permitted to operate with humans, animals or plants present in the operation area.

For Safety Instructions and Warranty Policy information go to:  
[www.patriotuvclean.com](http://www.patriotuvclean.com)

**FCC Statement:**

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try correct the interference by one or more of the following measures:

- Reorient the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into and outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

The distance between user and products should be no less than 20cm