golo carcare plus Instruction



1 Turn on Bluetooth

Enable Bluetooth on your phone from phone settings menu:
-Go to "settings"
-Click "bluetooth"
-Tap the toggle switch to turn it on



2 Download golo car APP

Search "golo car" in Google Play Store, this App is completely free for download.



3 golo car App Registration

Open the app, click "No Account?".

Enter the user name, email address and verification code of the email, then enter the password. Click "NEXT", App registration is completed.



4 Find your golo carcare plus S/N Pick up your golo carcare plus dongle and find a 12-digit number on the OBD connector, each S/N corresponds to a unique golo carcare plus dongle.



Model: G1106 FCC ID: 2AZ5VG1106

EΝ

5 Find OBDII port

Vehicle OBDH port is typically located on the driver-side underneath the dashboard and above the pedals. Below are the most common five locations. After plugging in the OBDH dongle, the red LED is always on to indicate that it is working.



6 Bluetooth Connection

Click on "Please pair golo carcare plus with your car", on the app homepage, find golo carcare plus dongle S/N under Bluetooth available devices, which name is the 12-digit S/N, click it to connect.





7 Start to Use Your golo carcare Device

After the bluetooth connection, you can use below functions which are completely free, such as OBD diagnostic, full system inspection, battery test, data recorder. You also can purchase special functions software in the mall.



8 Full system inspection

Perform comprehensive fault diagnosis for full system of vehicle, read DTCs and Data stream of each system of the vehicle and generate inspection reports. Support the function of One-key Clear DTCs. Support more than 40 brands. Support KWP 2000, ISO 9141-2, ISO 15765-4, ISO 15031 and other protocols.







10 Battery test standard OBD system full-function diagnosis. Read OBD system DTCs and various data, support the function of Onc-key Clear DTCs and generate diagnostic reports. Sepport most brands on the market, support NWP 2000, SAU, 1979 and other protocols.













Battery test

plot of a 4T connects to professional hastery testing design to a factor can be designed in the connect and the

is communicating with the phone.

*Warranty Cart

*In the device is guaranteed for a period of one year.

*I. The device is guaranteed for a period of one year.

*I. Refere replacement, please ensure complete packaging:

*Before replacement/repair, please call the service number

to get the shipping address.

*I. Product warranty starting date is based on the activation

date.

*Contact us
Customer Service Email: service@goldslds.com
Official Wesletie: https://www.goldslds.com
Shenzhen Gold halte-Connecting Data Technology Co., Ltd.
Address Lunder Leduriti Path, Service Walle Avenue,
Bantsegang, Longgang, Shenzhen

Ay Changes or modifications not expressly approved by the party Apr Changes or modifications not expressly approved by the party the copilines could will be user's such totally to question the copilines. This device complete with part of the feet Challes. Operation is subject this device may be used that I art of the Challes. Operation is subject to the copilines of the copilin