

SAMRT WATCH USER MANUAL

Smart watches

Smort watches
Thank you for choosing our smartwatch. You can read this manual to
fully understand the use of the device, this device is mainly through
Bluetooth connection to the mobile phone for adaptation, provides a
variety of practical functions and services to facilitate your operation
of the mobile phone, and developed a lot of functions for furnant movenement and health. The Company reserves the right to make charge
set to the contests of this manual whitch prior notice without prior
- so the "contests of this manual whitch prior notice without prior

to the second sec

Basic parameters

- 1.91*, resolution of 240x296 2.5D full touch screen

Product configuration: User Manual X1, Smart Watch X1, Silicon Strap X1, Charging line X1.

Operating instructions



Switch button: long press to turn on, Short press to enterlexit the menu, double-click to switch menu style Rotate encoder, switch dial and slide menu

Main Function Introduction:

Left Stroke: Shortcut Function

Using magnetic charging mode, support computer USB or mobile phone 5V standard charger, as shown in the following figure:

IIPS:
Please use a charger that meets international safety standards for charging, other chargers can charge, there may be problems such as slow charging, heating, etc. please use with custion. The magnetic suction charging head contains a magnet inside, which prohibits long-term contact with high temperatures, and

The mobile phone system requires Android 5.1 (inclusive) or above, ISS 9.0 (inclusive) or above. The permissions during the installation process require all the optional consent, otherwise it may affect the use of the function.

connect Blaetooth, first open "NouPro APP" and open the phone Bluetooth, NouPro APP will have a notification prompt to enable, dick "OK". Clack "Scan Device" on the APP device page, search for the Bluetooth address or Bluetooth name of the watch, select an

Some Android mobile phone systems need to open the mobile phone GPS to search for the Bluetooth name of the watch.

Charging instructions

Tips:

- Phone dialing: connect to call Bluetooth, dial from the watch, you can make a call on the watch side; there are contacts and call records in the dial interface, and frequently used contacts need to add settings in the APP.

- to odd settings in the APP.

 Owd sester, the function needs to be connected to the "FRASF" ope on the mobile phone to query the third-porty program messages that set the message redictions, and an ord quality from a program of the mobile phone to the property of the program o
- Blood pressure: When testing, please lay your hands flat, the blood pressure value will be displayed within one minute.
- Blood oxygen: enter the blood oxygen function, press start to enter the test, the normal blood oxygen saturation is about 94-99%.
 Outdoor sports: a variety of outdoor sports, you can monitor your exercise.
- userCise

 Indoor exercise: A variety of indoor exercises can monitor your dexercise at a more accurately. At the same time, the heart rate monitoring will be turned on, and the aption of stopping or pausing can be set on the exercise mode interface.
- Bluetooth camera: You need to enter the camera function in the APP, shake the watch back and forth several times to remotely control the camera.
- the camera.

 Bluetooth music: After connecting and calling Bluetooth, you can playand control the music in the phone. Pair the connection

 1. use the mobile prime to download the APP "CD-III" to the mobile prime and individually have work.

 The mobile prime was a series of the mobile that the mobile from the regist two-dimensional code through the mobile from between or some the mobile from between code through the mobile from between code through the prime file brower opens the download.

 2. If the work that sup for the first the work, the first through the prime file through through the prime file through the prime file through the prime file through the prime file through through the prime file through
 - Weather: After connecting the mobile phone to synchronize data, you can check the weather of the day.
 - Settings: Carry out various local settings of this machine, including brightness, rest screen duration, hand-up on screen, do not disturb made, sound and whatotin, language switching, mobile phone QR code connection, watch password, shutdown, factory reset, this machine Information etc.

Warm tips: If the WeChot desktop version is online at the same time, the mobile phone terminal will not receive the latter notification. Some mobile phones also need to add "\noutro" APP' to the power-soving whitelist to avoid being turned off by the phone when the battery is low.

Warranty instructions

When this product is in normal use, if there is a product quality problem caused by manufacturing, moterial, design and other reason, from the date of purchase, the motherboard has a free warranty within one year, the battery, charger warranty for half a year.

- 2. Due to the failure caused by the user's personal, the free Warranty is not provided, as follows:
- Unouthorized disassembly, modification of watches, etc.caused by malfunctions.
- 2) Failure caused by accidental fall during use.

All man-made damage or due to the fault of a third party,misuse (
 such as: host water ingress, external force cracking, scratch damage
 of peripheral components, etc.), is not cove-red by the warranty.

When requesting free warranty, please provide a warranty card with the date of purchase and the seal of the place of purchase.

FCC Caution:
This device comples with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undested operation.

Any Changes or madifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

the eaginment.

Note: This equipment has been tested and found to comply with the limits for of data 8 oligical devices, pursuant to part 15 of the ICC Relate. These limits are designed to provide recommoding protection against. These limits are designed to provide recommission against a provide recommendation of the provided recommendation of the secondary and a secondary and a