

M1 Translator Device

Product Manual

Bluetooth BLE mode

①Enter Bluetooth pairing mode

Slide the bottom mouse button to the far right to switch to Bluetooth mode.

The first connection requires pairing,while holding down the left and right mouse buttons,the blue light flashes and the mouse enters pairing mode.

②Pairing and connecting with a computer

Open the device options in the computer settings interface,click on "Add Bluetooth or other device",find "AI Mouse" and click on pairing connection.

Software installation method

Mac OS operating system

Method for obtaining software installation package

①Mac OS users can directly download and installMicLink Pro by searching for it in the App Store.

② Manually enter website address <http://www.miclink.net/boeleo> Open the driver download page and click the Mac OS driver download button to download the software.

windows operating system

Method for obtaining software installation package

①Long press the middle mouse button to pop up a download window.

② Manually enter website address <http://www.miclink.net/boeleo> Open the driver download page and click the Windows driver download button to download the software.

Function Introduction

1.Voice typing

Long press the "voice button" on the mouse to start speaking, then release it to achieve voice typing.

2.Voice translation and typing

Long press the "translation button" on the mouse to start speaking. After speaking, release the "translation button" to achieve voice translation and transfer the translated content to the input box for typing.

3.Screenshot translation

Click the "Translate" button on the mouse, hold down the left mouse button and drag the selection box. After adjusting the area to be translated, click the "Translate" icon on the left side of the pop-up window to translate the text.

4.Word translation

1. Open the Ai Mouse software, in the "Device Settings" interface, select the "Voice Key" or "AI Key" and set the click function to "Word Translation".
2. In the "Intelligent Settings" interface, find the "Word Translation" function area to set the source text language and target language.

Usage: Hold down the left mouse button and swipe a paragraph of text. Click the button to set "stroke translation" to start stroke translation.

5.Personal command words

Open the Ai Mouse software, on the "Cloud Command Settings" interface, click "Add Command", enter the command word and select the corresponding control function (open folder, file, website, fixed text).

6.Enter/Send

Open the Ai Mouse software, in the "Device Settings" interface, select any key click function and set it to "Enter/Send".

7.AI intelligent creation

Click the "AI key" on the mouse to open the "AI Intelligent Creation" page, where you can start using AI functions through voice typing or keyboard input.

(This function is an optional feature, please refer to the actual model)

8.AI PPT

Click the "AI button" on the mouse to open the "AI PPT" interface, where you can use AI to generate PPT content. It supports modifying content and layout, and can be exported with just one click for presentation.

(This function is an optional feature, please refer to the actual model)

9.AI painting

Click the 'AI' button on the mouse to open the 'AI Painting' interface, enter keywords, and the AI will generate high-quality images based on the description.

(This function is an optional feature, please refer to the actual model)

Precautions for use

① Due to its ultra-low standby power consumption, there is no need to deliberately turn off the mouse when used in a fixed location. It is recommended to keep the mouse turned off when carrying it out.

Special Reminder

① Intelligent voice mice equipped with rechargeable batteries should avoid exposure to sunlight or storage in hot cars. Do not disassemble the mouse's casing or parts at will.

② The external surface of rechargeable batteries may cause accidental explosions or fires under certain pressure or local forces. If you need to carry them out, it is best to keep the mouse product in the closed state.

③ The temperature of the mouse in contact with the environment should not exceed 60 degrees Celsius, otherwise the rechargeable battery will accelerate aging.

④ The optimal temperature range for charging the intelligent voice mouse is 0-45 degrees Celsius.

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following

measures:

--Reorient or relocate the receiving antenna.

--Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

·Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.