400mm 50mm time display area " \ \" is always on. At this time, you can play music from your phone. If there is no connection for a long time, the device will automatically enter standby mode, and the time display area " \ \" indicator will turn off at this time. Press and hold "\(\text{\texi}\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\tex{ Volume adjustment bar 10-10
Swipe up to make the sound louder. Swipe up continuously, and the sound continues to increase. The screen also displays current volumelevel.
Swipe down to reduce the sound. Swipe down continuously, and the sound decreases continuously. The screen also displays current volume level. Product Introduction 2 Product use Specifications Pro duct model illuminating screen Product dimensions 190x84x235mm Brightness adjustment bar \*—\*
Swipe up to brighten the brightness. Swipeup continuously, and the brightness brightens continuously. The screen also displays the current brightness level.
Swipe down to dim the brightness. Continuously sliding downward, the brightness continuously dims The screen also displays the current brightness evel. Product material ABS+PC Power on/ off
Press and hold the switch key for 2s to power on/o ff. 3 Specifications Speaker specifications 3W\*2 Bluetooth distance <10m UZZ. 87mm Manufacturer:Guangzhou Sleep Beauty Technology Co., Ltd Switch key or down. Tap (click) key to confirm Click to close the front illuminating screen; Click again to turn off the illuminating screen; Click again to tumor the front and rear illuminating screens. Cycle inturn Manufacturer Address: Room 614-616, Block 3, Merchants Land, No. 26 Guilan North Road, Guicheng Street, Nanhai District, Foshan City Website: www.uzz.audio Pat area 
Tap (click) to switch through multiple lightmodes in a Press and hold the switch key for 2s to power on/off. Click 5 times in a row to re-enter the time setting. cycle.
Double tap, turn on/out, night light.
Press and holdfor 2s to quickly turn on/exit the sunset sleep mode. Turning it on and using it before be dtime can helpyou adjust your sleep rhythmand help you fall Control key (1) Click to play/pause thecurrent music. Press and hold for 2s to turn on the Bluetooth connection signal. The prompt sounds, and the indicator light 11 in the time display area flashes. Please turn on your phoneand find the device with the Bluetooth name Uzz SleepAura Che in the Bluetooth connection list. adeep better when the alarm clock is set in the APP, when the alarm goes off, pressand hold for 2s to tumoff the alarm clock. If the alarm clock has a snooze setting, tap (click) to enter sno oze mode. 使用产品削请仔细阅读产品使用说明 Switch keys Control keys 制 造 商:广州睡美科技有限公司 制造商地址:像山市南省区柱城街道村 混北路26号招商置 地3座614-616室 网 址:www.uzz-tech **60**m When the Routine program is launched in the APP, tap (click) to exit the Routine executor and enter the next scenari o mode Click to select and pair automatically, after successful pairing, there wil be a prompt sound to prompt that the connection is successful, and the indicator light of the UZZ SleepAura One USER MANUAL APP 连接 本产品支持 APP 连接使用,接入 APP 使用该产品可解 产品保修卡 1 产品介绍 ② 产品使用 同时会显示当前音量档位。 4 注意事项 5 产品中有害物质成分及含量表 6 产品保修说明书 向下滑动声音减小。连续向下滑动,声音连续减小。屏幕 本产品售后服务严格依据《中华人民共和国消费者权益 保护法》、《中华人民共和国产品质量法》实行售后三包 购买时间 用户名称 同时会显示当前音量档位。 1、请勿长时间在阳光直射或高温的地方使用、存放本 连接电源 拍一拍区域 有害物质 联系电话 邮政编码 请使用随机标配的电源适配器与本产品连接电源使 亮度调节条 ※ ——※ 部件 名称 至 录 第 六价倍 多硼煤苯 多进二苯醌 [Pb] [Hg] (Cd) (C (M)) [PBB) [PBDE] 服务,服务如下 发票号码 产品型号 2、请勿在离磁卡、磁记录媒体或精密仪器太近的地方 用,请勿使用其他电源适配器进行连接,避免损坏产 向上滑动亮度变亮。连续向上滑动,亮度连续变亮。屏幕 一、保修政策  $\mapsto$ 联系地址 \_\_ 同时会显示当前亮度档位。 9級件 0 0 0 0 0 3、请勿自行分解或改 \_本产品, 向下滑动亮度变暗。连续向下滑动,亮度连续变暗。屏幕 1、自您签收次日起7日内,本产品出现《产品性能故障 经销单位(盖章生效) 合格证 已检验 开机 / 关机 4、请将本产品远离水或其他液体, 5、如果您想清洁本产品,请先断开电源, 同时会显示当前亮度档位。 表》所列性能故障的情况,经由几光售后服务中心检测 长按开关按键 2s,开机 / 关机。 金属件 0 0 0 0 0 确定,可免费享受退货或换货服务。 开关按键 ⑩ 6、产品工作环境温度范围为0~45℃; 2、自您签收次日起8日-15日内,本产品出现《产品性能 电路板 X O O O O 单击,关闭前发光屏幕;再次单击,关闭后发光屏幕, 首次使用时,会自动进入时间设置。时间设置顺序 7、请勿放置在超过6°的倾斜面上使用, 8、无线电发射设备型号核准代码标注在产品上, 故障表》所列性能故障的情况,经由几光售后服务中心 再次单击,开启前后发光屏幕。依次循环。 1 2/ 24 小时制显示选择→小时位时间设置→分钟位时间 ③ 规格参数 发光 主体 X O O O O O 检测确定,可免费享受换货或者维修服务。 长按开 关键 25,开机/关机。 设置→设置完成。 9、请使用获得CCC认证并满足标准要求的电源适配 连续单击 5 次,重新进入时间设置。 本表格依据SJ/T 11364的规定编制。 O;表示该有害物质在该部件所有均质材料中的含 二、产品性能故障表 滑动"音量调节条 叫──叫》"或"亮度调节条☆ ──米" 产品型号:BLA1 进行上下调节。轻拍(单击) 🔴 确定。 控制按键 ① 电源输入:1 2V == 1. 8A 产品尺寸:1 90×84×23 5mm 量在GB/T 26572规定的限量要求以下。 X:表示该有害物质至少在该部件的某均质材料 单击,播放/暂停当前音乐。 长按 2s,开启蓝牙连接信号,提示音响起,时间显示区域 "↓】"指示灯闪烁。 拍一拍区域 🖱 产品材质:ABS+PC 中的含量超出GB/T 26572规定的限量要求。 轻拍(单击)切换多种灯光模式循环切换。 蓝牙版本:5.3 因结构或材料因素造成的外壳裂损 喇叭无法正常播放出声 • 请打开您的手机,在蓝牙连接列表中找到蓝牙名称为 喇叭规格:3 W×2 双击,开启/退出,小夜灯。 亮度调节条 长按 2s, 快速开启 / 退出日落伴睡模式。在睡前打开使 UZZ SleepAura One 的设备,点击选中并自动进行配对, 配对成功后,会有提示音提示连接成功,此时时间显示 三、非保修条例 用该模式,辅助您调节入睡节奏,更好入睡。 1、未经授权的维修、误用、碰撞、疏忽、滥用、进液、事故、 区域" 【】"指示灯为常亮。此时可播放手机里的音乐。 当在 APP 设置闹钟后,闹钟响起时,长按 2s 关闭闹钟。 改动、不正确的使用非本产品配件而导致产品故障和损坏 • 如果长时间没有配对连接,设备会自动进入待机状态, 若闹钟程序设有贪睡设置,轻拍(单击)进入贪睡。 2、已经超出三包有效期; 3、不符合《产品性能故障表》所列性能故障的情况, 此时时间显示区域 当在 APP 启动 Routine 程序, 轻拍(单击)退出 "【】"指示灯熄灭。再次长按"①"激活连接信号。 4、因人为原因导致本产品产生《产品性能故障表》所列 · 当蓝牙已连接时,长按 2s,切换音频。