

FULLY CHARGE THE SMARTWATCH AND EARBUDS | CHARGING T

Before initiating the setup process, ensure that your smartwatch and earbuds are fully charged—avoid overcharging. The earbuds have gold contacts on the back of the case that will magnetically connect. If you need to store the earbuds, wrap the cable around the case and plug into a charging port.



Note: Charging may take up to 2 hours for the smartwatch and 60 minutes for the earbuds.

CH | CHARGING THE EARBUDS | DOWNLOAD THE ARMITRON CO

with the
watch; they will
resistance, flip
wall charger
screen will

Insert the charging cable into the charging port. The
charging indicator light will blink red to show that the
earbuds are charging. Once the light is illuminated
blue, the earbuds are fully charged.

Scan the **QR** code using your smartphone camera to
access and download our free **ARMITRON CONNECT**
mobile app to set up your smartwatch and earbuds.

Power
button
ARMITRON
the app
Device
Note:



on your smartwatch (press and hold the **W** for 5 seconds), then open the **TRON CONNECT** app. Tap the watch icon's bottom bar to start pairing. Select "Add" to

for 5 seconds), then open the **TRON CONNECT** app. Tap the watch icon's bottom bar to start pairing. Select "Add

“e” and choose “Boom.”

Activate Bluetooth on your phone, and on your watch using the mobile app.

GETTING UP YOUR EARBUDS

Open Bluetooth on your smartphone and remove the earbuds from the case. The left earbuds will start glowing red to begin pairing. Choose “**BOOM AUDIO**” from the device list.

choose **BOOKWRIGHT** from the device list.

FCC REGULATORY COMPLIANCE

Caution: The user is cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee

FCC REGULATORY COMPLIANCE (cont.)

that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC REGULATORY COMPLIANCE (cont.)

This equipment complies with the FCC's RF radiation exposure limits for an uncontrolled environment. The end user must follow the specific operating instructions to satisfy RF exposure compliance.

This device and its accompanying software are not meant for medical use, including diagnosing, treating, mitigating, or preventing diseases or conditions, or for any other medical purpose.

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

LIABILITY

ARMITRON CONNECT cannot be held liable for material damage or personal injury caused by incorrect handling or non-compliance with safety instructions.

This device and its accompanying software are not meant for medical use, including diagnosing, treating, mitigating, or preventing diseases or conditions, or for any other medical purpose.

FCC ID:

SMARTWATCH: 2BFC0421009B0M
EARBUDS: 2AEE-SW-T18

Operating temperature: 4° to 122°F
Non-operating temperature: -4° F to 140°F

Product: Armitron Connect Boom Smartwatch and Earbuds

Electrical products, batteries & accumulators should not be disposed of in the household waste.

If you cannot reuse or recycle your article, it should be disposed of at a civic amenity site or a local authority recycling facility. Do not dispose of your

ARMITRON CONNECT product with household waste. Disposal of the packaging & your

ARMITRON CONNECT product should be done in accordance with local regulations. Batteries are not to be disposed of in municipal waste & require separate collection.

DISPOSAL OF GOODS

ARMITRON CONNECT cannot be held liable for material damage or personal injury caused by incorrect handling or non-compliance with safety instructions.

This device and its accompanying software are not meant for medical use, including diagnosing, treating, mitigating, or preventing diseases or conditions, or for any other medical purpose.

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

PRODUCT INFORMATION

ARMITRON CONNECT

BOOM
SMARTWATCH + EARBUDS

Quick Start Guide

