

Quick Guide



① Multi-function keys	③ Charging interface
② Cue light	④ MIC
⑤ Volume Up +	⑥ Volume Down -

Instructions

First use: Power on-Open the phone's settings-BT- B33

Power on/off	Press 2/3s	Phone Assistant	Double click
Pause/Play	Single click	Answer/Hang up	Single click
Volume Up	+ Single click	Volume Down	-Single click
Next Song	+ Press 2s	Last Song	- Press 2s

Note: To reject an incoming call, double click the multifunction key

Specifications

Music Time	≈6 hour
Charging Time	≈2 hour
Standby Time	≈7 day
Connection Distance	10 m
Speaker Type	Bone Conduction

Tips

1. Dear users, for your better experience with this product, please fully charge it before use.
2. Please use a DC5V charger and a computer to charge the headset. Do not use DC9V, DC12V, DC24V to charge the headset.
3. This product has been idle for a long time, please recharge it within 2 months to ensure good battery performance.
4. After wearing this product, it is recommended to use a dry towel to clean the sweat and water stains on the surface of the product, and leave it for 2 hours to ensure that the charging port is dry before charging the headset to prevent the short circuit of sweat during charging and affecting the service life of this product.
5. Long-term high-volume music may cause discomfort. Please try to use a medium or so volume to avoid listening at high volume for a long time.
6. Do not throw, press the headset or submerge it in water. Stay away from fire, water and high pressure equipment.

   

Made in China



NAME: Bone conduction
Headphones
CHECKED DATE: Check12

快速指引背面