

Available on the **App Store**

Available on **Google play**

**Bluetooth®** smart

Sync your program  
with your smart  
smart ready device  
Bluetooth® compatible  
for more info

① Before installing OKOK App, kindly check if the phone or tablet meets following

Compatible with iOS7.0 and above with Bluetooth 4.0 and above

100

A diagram of a mobile phone. A small rectangular box is positioned on the screen, containing a small circle and a small square.

OKOK from App Store/Google Play to install App.

1/ Switch on Bluetooth  
2/ Phone or Tablet connects to Net (WiFi, 3G or 4G)

Open APP, begin to Register as a user Complete personal

[Get the Book Now](#)
[Sign Up](#)
[Sign Up](#)
[Sign Up](#)

Enter into "Dynamic Weight" interface

Page 10 of 10

**Step 6** View the test result

Display: All data displayed when power on  
Capacity: 3kg-180kgs

Standby current:  $\leq 10\mu A$   
Overload indication: overload more than 2.5kgs, total 182.5kgs display "Err"  
Best working temperature: 5-35°C  
Storage temperature:  $\pm 10\sim 60^{\circ}C$

**Instruction for OKOK App**

- Instantly weighing

- Instantly weighing  
Open the OKOK APP, it will remind you to switch on Bluetooth. Turn Bluetooth on and the auto-pair process completed automatically. User begin weighing, the weight data

The user can type weight data into ASP to keep a track

Including weekly report, monthly report and quarterly report, indicating the changes of weight through curves.

Management of scale including two parts: scale management and connection management

- **Account and user**
  - Including account management and user management

Managing user information, including nickname, birthday, height, gender...etc, also managing family member account and information (under the same registration account).

1. Please keep the scale away from wet floor, don't use the scale if the glass is wet in case of slip.

4. The Bluetooth scale is not waterproof. Keep the surrounding environment dry, do not submerge it in water.

5. Use soft cloth with neutral cleaning liquids to clean the surface, keep away

1. Please stand on the scale in the right direction.
2. Please stand on the scale no less than 10 seconds if you measure body fat.

**FCC Statement:**  
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.